## Applied Classical and Modern Control System Design

#### **Richard Tymerski**

Portland State University Department of Electrical and Computer Engineering Portland, Oregon, USA

#### Frank Rytkonen

Oregon Institute of Technology Department of Electrical Engineering and Renewable Energy Wilsonville, Oregon, USA

### Acknowledgements

The authors would like to express their sincere gratitude to a number of former students who have greatly contributed to making this book possible. Of particular note, Clint Lieser and Andrew Chuinard ... (To be expounded upon.)

# Preface

This is the preface.

iv

# Contents

	Ackr	nowledgements	l					
Ι	Cla	assical Control 1						
1	Intr	ntroduction						
	1.1	Basic Feedback Configuration	5					
	1.2	Stability - Absolute and Relative	-					
	1.3	Stability Analysis Example	5					
		1.3.1 Matlab Code	<u>.</u>					
	1.4	Appendix: Routh-Hurwitz Stability Analysis	1					
<b>2</b>	Bod	le Plots 19	)					
	2.1	Simple Gain	)					
	2.2	Pole at Zero	)					
	2.3	Zero at Zero						
	2.4	Pole at $\omega_o$	1					
	2.5	Zero at $\omega_o$	1					
	2.6	Right Half Plane Zero at $\omega_o$	5					
	2.7	Complex Pole Pair with Resonant Frequency at $\omega_o$	:					
	2.8	Complex Zero Pair with Resonant Frequency at $\omega_o$	:					
	2.9	Composite Transfer Functions	:					
	2.10	Summary of Bode Plots 30	I					
3	Con	npensator Design 33	į					
	3.1	Design Procedure	5					
		3.1.1 Introduction	5					
		3.1.2 Uncompensated System	:					
		3.1.3 Proportional Compensated System	1					
		3.1.4 Dominant Pole Compensated System	I					
		3.1.5 Dominant Pole Compensated System with zero 41						
		3.1.6 Dominant Pole Compensated System with zero, improved						
		$\begin{array}{c} \text{pnase margin} \\ \text{subset} \\ sub$	1					
		5.1.7 Lead Compensated System	,					
3.1.8 Lead Compensated System with integrator and zero								

		3.1.9       Summary       59         3.1.10       MATLAB       Code       62						
4	<b>Moo</b> 4 1	Ielling - Introduction     67       Introduction     67						
5	4.1 The	System 69						
	0.1 5.0	The Plant: Buck Convertor 7(						
	0.2	The Flant. Duck Converter $\dots \dots \dots$						
		5.2.1 Introduction $$						
	5 9	Dulce width Meduleten     70						
	0.0 5.4	ruise-width Modulator						
	0.4	Summary						
6	Sing	the Loop Voltage Mode Control 83						
	6.1	Introduction						
	6.2	Buck Converter System Models						
		6.2.1 General Model						
		6.2.2 Simplified System Model						
		6.2.3 Design Targets						
		6.2.4 Buck Converter Model Analysis						
	6.3	Uncompensated System						
	6.4	Dominant Pole Compensation						
	6.5	Dominant Pole Compensation with Zero						
	6.6	Lead Compensation						
	6.7	Dominant Pole with Lead Compensation						
		6.7.1 Design 1: Zero $f_1 = 500$ Hz 109						
		6.7.2 Design 2: Zero $f_1 = 150$ Hz						
	6.8	Extended Bandwidth Design						
	6.9	Conclusion						
		$6.9.1  \text{Compensator Circuits}  \dots  \dots  \dots  \dots  \dots  \dots  124$						
	6.10	MATLAB Code						
7	Dro	op and Multi-Loop Control 129						
	7.1	Introduction						
	7.2	Design						
		7.2.1 Passive Droop Compensation						
		7.2.2 Active Droop Compensation						
		7.2.3 Voltage Mode Compensation						
	7.3	Summary						
	7.4	MATLAB Code						
II	II Modern Control 165							
8	Intr	oduction 167						

vi

#### CONTENTS

9	System Analysis						
	9.1 The Ćuk Converter						
	9.2 The Ćuk Converter Model						
		9.2.1 Analysis of Inductors with Mutual Coupling					
		and Equivalent Series Resistances	173				
		9.2.2 The State Space Averaged Model	174				
		9.2.3 Component Values	177				
	9.3	Čuk Converter Open Loop Performance	177				
	9.4	Controllability and Stabilizability	181				
	9.5	Observability and Detectability	181				
	9.6	Controlling the Cuk Converter	182				
		9.6.1 Time Domain Specifications	182				
		9.6.2 Frequency Domain Specifications	182				
		9.6.3 Control Effort Constraints	183				
	9.7	MATLAB Code	185				
10	Dala	Bleesment	100				
10	10.1	Placement	100				
	10.1	Cuk Converter with State Foodback Componsator	190				
	10.2	MATLAB Code	195				
	10.0	MATERD Code	150				
11	Inte	gral Action	199				
	11.1	Adding Integrators	199				
	11.2	Ćuk Converter with State Feedback and Integral Compensator .	201				
	11.3	MATLAB Code	205				
10	Q1-1	F-1:	207				
14	5tat	E Estimation	207				
	12.1	Full-Order State Estimators	207				
	12.2	Reduced Order State Estimators	200				
	12.0	Reduced Order Estimators Based Componenter	212 915				
	12.4	MATIAB Code	210				
	12.0	MATLAD Code	215				
13	Line	ear Quadratic Optimal Control	<b>227</b>				
	13.1	Linear Quadratic Regulators	227				
	13.2	Ćuk Converter with LQR Compensator	228				
	13.3	Linear Quadratic Gaussian Regulators	231				
	13.4	Ćuk Converter with LQG Compensator	232				
	13.5		224				
	10.0	Control with LQG/LTR Compensators	204				
	13.6	Control with LQG/LTR Compensators       MATLAB Code         MATLAB Code	234				
14	13.6	Control with LQG/LTR Compensators	237				
14	13.6 Con	MATLAB Code	234 237 243				
14	13.6 Con 14.1	MATLAB Code	<b>23</b> <b>23</b> <b>243</b> 243 243				
14	13.6 Con 14.1 14.2	Control with LQG/LTR Compensators       MATLAB Code         MATLAB Code       MATLAB Code         npensator Order Reduction         Model Reduction of the LQGI/LTR Compensator         A Reduced-Order LQGI/LTR Compensator         MATLAB Code	234 237 243 243 243 247				

15 Compensator Implementation	<b>259</b>	
15.1 MRLQGI/LTR Compensator Construction	. 259	
15.2 MRROLQGI/LTR Compensator Construction $\dots \dots \dots \dots$	. 260	
16 Power Electronic Circuit Simulation		
16.1 Simulating the Controlled Ćuk Converter in PECS $\ldots$	. 265	
17 Conclusion	269	

viii

# Part I Classical Control

## Chapter 1

# Introduction

#### 1.1 Basic Feedback Configuration

The standard single loop feedback block diagram configuration is shown in Figure 1.1. There are three basic blocks G(s),  $G_c(s)$  and H(s), the plant, compensator and feedback transfer functions, respectively. These are discussed below. But first a straightforward analysis leads to the overall input to output transfer function of this configuration:



Figure 1.1: Feedback System Block Diagram

$$\frac{Y(s)}{U(s)} = \frac{G(s)}{1 + G(s)H(s)}$$
(1.1)

$$= \frac{1}{H(s)} \frac{G(s)H(s)}{1 + G(s)H(s)}$$
(1.2)

The product G(s)H(s) (more strictly, -G(s)H(s)) is termed the loop gain as it is the product of the gains around the feedback loop. Equation (1.3) is termed the closed loop gain of the system. The advantages that feedback provides is derived from the fact that as long as the magnitude of the loop gain is large, that is,  $|G(s)H(s)| \gg 1$ , then the closed loop gain is determined by H(s). However, the price to be paid for this is the possibility that the denominator polynomial, known as the characteristic polynomial, i.e. 1 + G(s)H(s) may vanish at some frequency resulting in the closed loop gain becoming unbounded, that is unstable. The purpose of the compensator  $G_c(s)$  therefore is to provide loop shaping to avoid this instability condition.

From this discussion we can therefore summarize the purpose of each of the three blocks: G(s) is the plant, which implements the operational function that is desired; the feedback block H(s) (under the condition of high loop gain) sets the value of closed loop gain

$$\frac{Y(s)}{U(s)} \approx \frac{1}{H(s)}$$
 for  $|G(s)H(s)| \gg 1$ 

and the compensator  $G_c(s)$  block improves the stability and performance of the closed loop system.

The performance of the closed loop system will be assessed by examining the response to step inputs. Specifically, with reference to figure 1.2 we will look at the rise time, settling time and percentage overshoot. Rise time,  $t_r$ , is defined as the time it takes for the step response to go from 10% to 90% of the final value. Settling time,  $t_s$ , refers to the time it takes for the response to remain in a band of  $\pm 5\%$  of the final value. The percentage overshoot (OS) is determined by the following formula

$$OS = \frac{B-A}{A} \times 100 \tag{1.3}$$

where A and B represent the largest overshoot value and final value, respectively.

#### **1.2** Stability - Absolute and Relative

As discussed above, the question of absolute stability of a closed loop system, that is whether it is stable or not, can be answered by whether a frequency exists for which satisfies the characteristic equation:

$$1 + G(s)H(s)|_{s=i\omega} = 0 \tag{1.4}$$

These frequencies are the 'poles' of the closed loop system. The locations of pole frequencies can be mathematically determined by a root finding procedure. Stability can be subsequently assessed by examining whether all of these complex valued quantities have a negative real parts. If so, the system is said to be absolutely stable.

#### 1.2. STABILITY - ABSOLUTE AND RELATIVE

Once absolute stability is assessed, then the question of how stable the system is, that is, its relative stability may be asked. In this regard, the gain (GM) and phase margins (PM) are used. This is generally done in the context of Bode plots, which show the magnitude and phase response of the loop gain over a range of frequencies which include the  $-180^{\circ}$  phase crossover frequency and the unity gain crossover frequency, as shown in figure 1.3. As a rule of thumb, a gain margin of > 10 dB and phase margin of between 45° to 60° are deemed desirable.

Note also that (under certain mild assumptions concerning the loop gain) the phase margin may be used to determine the stability of the closed loop system. The phase margin test for absolute stability requires that

Phase Margin Test for Stability:  $PM > 0 \implies$  stability (1.5)

The gain margin does enter into the absolute stability consideration. This may be seen as rather unusual and so an example will be presented in the next section demonstrating this as well as tying up a number of other concepts presented here.

It should be emphasized that the stability of the closed loop system which has transfer function  $\frac{G}{1+GH}$  can be assessed by looking at a property the loop gain which has transfer function GH, specifically the phase margin.

The design of compensators may be approached in several ways. In this book the use of Bode plots to shape the loop and obtain desirable gain and phase margins is demonstrated.

The design of the compensator may be approached several ways. In this book the use of Bode plots to shape the loop is demonstrated



Figure 1.2: Step Response



Figure 1.3: Gain and Phase Margins

#### 1.3 Stability Analysis Example

Consider a system with the following loop gain

$$T(s) = A \frac{\left(1 + \frac{s}{\omega_z}\right) \left(1 + \frac{s}{\omega_1}\right)}{s^3}$$

where A = 300,  $\omega_z = 40 rad/s$ , and  $\omega_z = 1 rad/s$ 

Using the methodology that has been developed to this point, the loop gain, T(s) will be analyzed to determine whether the system is stable.

The stability analysis begins by constructing an asymptotic bode plot of the given system, as shown in Figure 1.4.



Figure 1.4: Bode Plot: System Loop Gain

#### 1.3. STABILITY ANALYSIS EXAMPLE

Using the asymptotic bode plot, the phase margin is calculated by utilizing the magnitude to determine the crossover frequency:

$$\frac{A}{\omega_c^2} = 1$$
 or  $\omega_c = \sqrt{A} = 17.3 rad/s$ 

With the crossover frequency defined, the margin is calculated by inserting the frequency value into the loop gain phase equation:

$$PM = 180^{\circ} - 270^{\circ} + \tan^{-1}\left(\frac{\omega_c}{\omega_z}\right) + \tan^{-1}\left(\frac{\omega_c}{\omega_1}\right)$$
$$PM = 180^{\circ} - 270^{\circ} + \tan^{-1}\left(\frac{17.3}{40}\right) + \tan^{-1}\left(\frac{17.3}{1}\right) = 20^{\circ}$$

To determine the gain margin, the phase equation is used to determine the frequency in which the phase is  $-180^{\circ}$ .

$$-180^{\circ} = -270^{\circ} + \tan^{-1}\left(\frac{\omega_m}{\omega_z}\right) + \tan^{-1}\left(\frac{\omega_m}{\omega_1}\right)$$

Solving the phase equation for  $\omega_m$ ,  $\omega_m = 6.32 rad/s$ 

Inserting the computed value of  $\omega_m$  into the magnitude equation, the gain margin is calculated as follows:

$$|T(j\omega_m)| = \frac{A}{\omega_m^2} = \frac{300}{6.32^2} = 7.5$$
$$GM = -20\log_{10}(7.5) = -17.5dB$$

Using MATLAB to verify the asymptotic bode plot, Figure 1.5 confirms the phase and gain margin analysis, with a gain margin and phase margin error of 1.1% and 6.1% respectively, due to the approximations of the asymptotic magnitude plot.

With a positive phase margin, and a negative gain margin, additional criterion are necessary to determine if the system is stable. Another method used to determine the stability of a system is the Routh-Hurwitz stability criterion.

Before the Routh-Hurwitz criterion can be applied to the presented system, a closed loop transfer function must be derived for the system loop gain. One possible realization of the closed loop system is presented in Figure 1.6.



Figure 1.5: Matlab Analysis of phase and gain margin



Figure 1.6: Closed-Loop realization of  $T_s$ 

From Figure 1.6, the closed-loop transfer function is derived as follows:

$$T_{cl}(s) = \frac{1}{1+T(s)}$$
$$T_{cl}(s) = \frac{1}{\frac{s^3 + A\left(1 + \frac{s}{\omega_z}\right)\left(1 + \frac{s}{\omega_1}\right)}{s^3}}$$
$$T_{cl}(s) = \frac{s^3}{s^3 + \frac{A}{\omega_z \omega_1}s^2 + A\left(\frac{1}{\omega_z} + \frac{1}{\omega_1}\right)s + A}$$

ī.

With the system defined in a closed-loop form, the denominator polynomial can be used to determine system stability as shown in Figure 1.7

$$\begin{array}{c|c|c} s^{3} & 1 & A\left(\frac{1}{\omega_{z}} + \frac{1}{\omega_{\lambda}}\right) \\ s^{2} & \frac{A}{\omega_{1}\omega_{z}} & A \\ s^{1} & \frac{A(\omega_{1}+\omega_{z})}{\omega_{z}\omega_{1}} - \omega_{z}\omega_{1} \\ s^{0} & A \end{array}$$

Figure 1.7: Routh Hurwitz analysis of closed loop system



Figure 1.8: Routh Hurwitz Values

Applying the system parameters, Figure 1.8 confirms that no sign changes are present in the first column. This confirms that the system is stable, while having negative gain margin.

With the system confirmed as stable, the next item to explore is the possible parameter shifting in the system that could cause the system to become unstable. From the derivations shown in Figure 1.7, the only term that could cause a sign change in the first column is the  $s^1$  term. Setting this term to zero and solving for A:

$$\frac{A(\omega_1 + \omega_z)}{\omega_1 \omega_z} - \omega_1 \omega_z = 0$$
$$A = \frac{1}{\omega_z + \omega_1} = 39.024$$



Applying the shifted A parameter to the asymptotic bode plot of Figure 1.4, the updated bode plot is shown in Figure 1.9.

Figure 1.9: Bode Plot: System Loop Gain with parametric shift

Applying the new value of A to the magnitude equation,  $\frac{A}{\omega_c^2} = 1$  or  $\omega_c = \sqrt{A} = 6.25 rad/s$ . With this frequency, the phase margin is calculated to be  $-0.2^{\circ}$ .

As a confirmation of the above margin estimate due to parametric value shift, Figure 1.10 confirms the analysis, with a phase margin of  $-8.82 \cdot 10^{-5}$ .



Figure 1.10: Matlab Analysis of phase and gain margin with parametric shift

#### Summary

This chapter has shown the reader how to apply asymptotic bode plots to determine the stability of a system. The reader has also learned that in some scenarios it may be necessary to use asymptotic bode plot analysis in conjunction with the Routh-Hurwitz stability criterion to determine the stability of a system.

1.3.1 Matlab Code

```
1 clear all;
2 close all;
3
4 f = logspace (-3, 3, 10000);
5 w = 2*pi*f;
6 \, s = tf('s');
7
s A = 300;
9 w1 = 1;
10 \text{ wz} = 40;
11
13 %System Loop Gain
15 sys = A * (1+s/w1) * (1+s/wz) / (s^3);
16
17 figure(1)
18 [mag, phase] = bode(sys,w);
19 margin(mag, phase, w)
20
h = gcr;
22 xlim([10^-2 10^3]);
23 h.AxesGrid.TitleStyle.FontSize = 16;
24 h.AxesGrid.XLabelStyle.FontSize = 12;
25 h.AxesGrid.YLabelStyle.FontSize = 12;
27
^{28}
30 %Plot Marginal Stability Per Routh Hurwitz
32 A=39.024;
33
34 sys = A*(1+s/w1)*(1+s/wz)/(s^3);
35
36 figure(2)
37 [mag, phase] = bode(sys,w);
38 margin(mag, phase, w)
39
40 h = qcr;
41 xlim([10^-2 10^3]);
42 h.AxesGrid.TitleStyle.FontSize = 16;
43 h.AxesGrid.XLabelStyle.FontSize = 12;
44 h.AxesGrid.YLabelStyle.FontSize = 12;
```

#### 1.4 Appendix: Routh-Hurwitz Stability Analysis

To determine if a system is stable, it is necessary to determine if the system denominator polynomial has right half-plane roots. For polynomials of a higher order than two, the quadratic formula is insufficient to determine stability.

A widely used method of determining the number of RHP roots for higher order systems is the Routh-Hurwitz test. The Routh-Hurwitz test is a numerical procedure for determining the numbers of RHP and imaginary axis (IA) roots of a polynomial.

Consider the following polynomial:

$$p(s) = a_n s^n + a_{n-1} + \dots + a_1 s + a_0$$

The coefficients of the polynomial are arranged as follows in Figure 1.11:

Г

$s^n$	$a_n$	$a_{n-2}$	$a_{n-4}$	
$s^{n-1}$	$a_{n-1}$	$a_{n-3}$	$a_{n-5}$	
$s^{n-2}$	$b_1$	$b_2$	$b_3$	
$s^{n-3}$	$c_1$	$c_2$	$c_3$	
$s^{n-4}$	$d_1$	$d_2$	$d_3$	
÷				
$s^0$				

Figure 1.11: Routh Hurwitz analysis

The system is considered stable if there are no sign changes in the first column. The coefficients populated in Figure 1.11 are calculated as follows:

$$b_{1} = \frac{-\begin{vmatrix} a_{n} & a_{n-2} \\ a_{n-1} & a_{n-3} \end{vmatrix}}{a_{n-1}} = \frac{a_{n-1}a_{n-2} - a_{n}a_{n-3}}{a_{n-1}}$$
$$b_{2} = \frac{-\begin{vmatrix} a_{n} & a_{n-4} \\ a_{n-1} & a_{n-5} \end{vmatrix}}{a_{n-1}} = \frac{a_{n-1}a_{n-4} - a_{n}a_{n-5}}{a_{n-1}}$$
$$c_{1} = \frac{-\begin{vmatrix} a_{n-1} & a_{n-3} \\ b_{1} & b_{2} \end{vmatrix}}{b_{1}} = \frac{b_{1}a_{n-3} - b_{2}a_{n-1}}{b_{1}}$$
$$c_{2} = \frac{-\begin{vmatrix} a_{n-1} & a_{n-5} \\ b_{1} & b_{3} \end{vmatrix}}{b_{1}} = \frac{b_{1}a_{n-5} - b_{3}a_{n-1}}{b_{1}}$$

An example to illustrate the Routh-Hurwitz method is presented with the polynomial below:

$$p(s) = 4s^{4} + 3s^{3} + 10s^{2} + 8s + 1$$

$$b_{1} = \frac{-\begin{vmatrix} 4 & 10 \\ 3 & 8 \end{vmatrix}}{3} = -\frac{2}{3}$$

$$b_{2} = \frac{-\begin{vmatrix} 4 & 1 \\ 3 & 0 \end{vmatrix}}{3} = 1$$

$$b_{3} = \frac{-\begin{vmatrix} 4 & 0 \\ 3 & 0 \end{vmatrix}}{3} = 0$$

$$c_{1} = \frac{-\begin{vmatrix} 3 & 8 \\ -\frac{2}{3} & 1 \end{vmatrix}}{-\frac{2}{3}} = \frac{25}{2}$$



Figure 1.12: Routh Hurwitz analysis worked example

The two sign changes in the left column indicate that  $p\left(s\right)$  has two RHP roots.

## Chapter 2

## Bode Plots

#### Introduction

In the following we will present magnitude and phase asymptotic approximations to a number of basic transfer functions. The value of these asymptotic approximations is that simplified mathematical expressions may be used to precisely describe the asymptote. In the case of the magnitude characteristic the magnitude is generally displayed in a plot dB versus frequency presented on a log scale. When plotted using these scales the plot can be well approximated using straight line asymptotic segments. It is these segments that exact formulas may be presented. Note however that annotations on the magnitude plot use the absolute value rather than the relative value which the dB value represents.

Magnitude in dB is obtained by:

$$|H(s)|_{dB} = 20 \log [H(s)]|_{s=i\omega}$$
 (2.1)

The phase plot is represented by phase angle in degrees versus log frequency. The phase plot of a transfer function is obtained by setting  $s = j\omega$  where  $j = \sqrt{-1}$ , and where  $\omega$  represents the angular radian frequency. In sections of this book, we will prefer to use  $f = \frac{\omega}{2\pi}$  when dealing with actual frequencies.

$$\angle H\left(s\right) = \angle H\left(s\right)|_{s=i\omega} \tag{2.2}$$

#### 2.1 Simple Gain

The simplest transfer function is that of constant gain which we will denote as A, so that the transfer function is given as:

$$H\left(s\right) = A \tag{2.3}$$

In this case the asymptotic and exact magnitude and phase characteristics are the same and are shown in figure 2.1. As just mentioned above, note that the magnitude line is annotated with its absolute value, rather than its dB value.



Figure 2.1: Simple Gain

#### 2.2 Pole at Zero

The next transfer function considered is that of a single pole at zero frequency, as given by:

$$H\left(s\right) = \frac{A}{s} \tag{2.4}$$

This transfer function is that of an integrator. The case of a finite pole frequency different than zero is tackled below. The asymptotic magnitude and phase plots are shown in figure 2.2. With reference to this figure, we can interpret the parameter A as the gain of the transfer function at the angular frequency of  $\omega = 1$ .



Figure 2.2: Pole at Zero

Alternatively, this same transfer function may be represented as  $H(s) = \frac{\omega_o}{s}$  where  $\omega_o = A$ . With reference to figure 2.3, we see that  $\omega_o$  may be interpreted as the value of frequency for which the transfer function has a gain of unity.



Figure 2.3: Pole at Zero

#### 2.3 Zero at Zero

The next transfer function considered is that of a single zero at zero frequency, as given by:

$$H\left(s\right) = As\tag{2.5}$$

This transfer function is that of a differentiator The case of a finite zero frequency different than zero is tackled below. The asymptotic magnitude and phase plots are shown in figure 2.4. With reference to this figure, we can interpret the parameter A as the gain of the transfer function at the angular frequency of  $\omega = 1$ .



Figure 2.4: Zero at Zero

Alternatively, this same transfer function may be represented as  $H(s) = \frac{s}{\omega_o}$ where  $\omega_o = \frac{1}{A}$ . With reference to figure 2.5, we see that  $\omega_o$  may be interpreted as the value of frequency for which the transfer function has a gain magnitude of unity.



Figure 2.5: Zero at Zero

#### 2.4 Pole at $\omega_o$

The next transfer function considered is that of a single zero at a frequency of  $\omega_o$ , as given by:





Figure 2.6: Pole at  $\omega_o$ 

#### **2.5** Zero at $\omega_o$

The next transfer function considered is that of a single zero at a frequency of  $\omega_o$ , as given by:

$$H(s) = A\left(1 + \frac{s}{\omega_o}\right) \tag{2.7}$$



Figure 2.7: Zero at  $\omega_o$ 

#### **2.6** Right Half Plane Zero at $\omega_o$

The next transfer function considered is that of a single right half plane zero at a frequency of  $\omega_o$ , as given by:



Figure 2.8: Right Half Plane Zero at  $\omega_o$ 

(2.9)

#### 2.7 Complex Pole Pair with Resonant Frequency at $\omega_o$

The next transfer function considered is that of a complex pole pair with resonant frequency at  $\omega_o$ , as given by:



Figure 2.9: Second Order Complex Pole at  $\omega_o$ 

#### 2.8 Complex Zero Pair with Resonant Frequency at $\omega_o$

The next transfer function considered is that of a complex zero pair with resonant frequency of  $\omega_o$ , as given by:

$$H(s) = A\left(1 + \frac{s}{Q\omega_o} + \left(\frac{s}{\omega_o}\right)^2\right)$$
(2.10)

#### 2.9 Composite Transfer Functions

Having just presented the asymptotic Bode plots for some basic transfer function we will next demonstrate how these may be used in constructing asymptotic Bode plots for more complicated transfer functions. This then will allow forming simplified mathematical expressions for magnitude and phase which will be used in compensator design.



Figure 2.10: Second Order Complex Zero at  $\omega_o$ 

As an example we present the following transfer function:

$$T(s) = \frac{T_o}{\left(1 + \frac{s}{\omega_1}\right)\left(1 + \frac{s}{\omega_2}\right)\left(1 + \frac{s}{\omega_3}\right)}$$
(2.11)

where

$$T_o = 250, \omega_1 = 2\pi (10), \omega_2 = 2\pi (100), \omega_3 = 2\pi (300)$$

Somewhat arbitrarily we can identify three constituent basic transfer functions which when multiplied together form the composite transfer function.

$$T(s) = \frac{T_o}{\underbrace{\left(1 + \frac{s}{\omega_1}\right)}_{T_a(s)}} \underbrace{\frac{1}{\left(1 + \frac{s}{\omega_2}\right)}}_{T_b(s)} \underbrace{\frac{1}{\left(1 + \frac{s}{\omega_3}\right)}}_{T_c(s)}$$
(2.12)

We will first construct the magnitude plot. Figure 2.11a shows the asymptotic response for each of the components. Note that the magnitude annotations are given in absolute terms so that the composite magnitude is simply the product of the constituent magnitudes in the relevant frequency interval. In contrast, the slopes expressed in dB are simply added together. The result of the composite magnitude is shown in figure 2.11b.

Similarly the constituent phase response is shown in figure 2.12a; and composite phase plot is shown in figure 2.12b.

The final form of the asymptotic Bode plot is given in its customary form with magnitude response place above the phase response, shown in figure 2.13.



Figure 2.11: a) Asymptotic magnitude plots for the constituent transfer functions, b) Asymptotic magnitude plot for the composite transfer function



Figure 2.12: a) Asymptotic phase plots for the constituent transfer functions, b) Asymptotic plot for the composite transfer function


Figure 2.13: Final constructed asymptotic Bode plot showing, a) asymptotic magnitude response, b) asymptotic phase response

H(s) = A	H(s)  = A
Simple Gain	$/H(s)$ — $0^{\circ}$
$H(s) = \frac{A}{s}$	$H(s) = \frac{\omega_o}{s} \qquad \qquad$
	$ \begin{aligned} & \omega_o = A \\ & H(s) \end{aligned} \qquad \begin{array}{c} A & \omega_o = A \\ & \omega_o = A \\ & \omega_o = \omega_o \end{array} \end{aligned} \qquad \begin{array}{c} \omega_o = A \\ & \omega_o = \omega_o \end{array} \end{aligned} $
Pole at Zero	H(s) -90°
H(s) = As	$+20 dB/dec / H(s) = \frac{s}{\omega_o} +20 $
	$  H(s)  \qquad \qquad$
Zero at Zero	$/H(s) \qquad \xrightarrow{\omega = 1} \qquad \qquad \omega = \omega_o$
$H(s) = \frac{A}{1 + \frac{s}{\omega_o}}$	$ \begin{array}{c c} A & & & \\ \hline H(s) \end{array} \begin{array}{c} A & & & \\ \hline \hline & & \\ \hline \\ \hline$
	$\omega_o = \frac{\omega_o}{10}$ Maximum Error @ $\omega_o \approx 10 \omega_o = 5.7^o$
	$ \begin{array}{c} -45^{\circ} \\ H(s) \end{array} \qquad $
Pole at $\omega_o$	$\frac{-45^{\circ}/\text{dec}}{\omega_o} \xrightarrow{-90^{\circ}} \qquad \text{Approx. These.} = 45 \ tog_{10} \left(\frac{1}{\omega_o}\right), \\ \frac{\omega_o}{10} \le \omega \le 10\omega_o$
$H(s) = A\left(1 + \frac{s}{\omega_o}\right)$	$H(s) \xrightarrow{3dB} \xrightarrow{4\omega} Maximum Error @ \omega_o = 3dB$
	$A \longrightarrow 0^{\circ} \phi^{\circ} $
	$H(s) \qquad \qquad$
Zero at $\omega_o$	$\begin{array}{c c} 0^{\circ} & & & \\ \hline \\ \hline$
$H(s) = A\left(1 - \frac{s}{\omega_o}\right)$	$H(s) A = \frac{A\omega}{\omega_o} \qquad \text{Maximum Error } @ \omega_o = 3 \text{dB}$
	$\begin{array}{c c} & \underline{\omega_o} \\ & \underline{\omega_o} \\ & \underline{10} \end{array} \end{array} \qquad $
	$H(s)$ Exact Phase: $-tan^{-1}\left(\frac{\omega}{\omega_o}\right), \forall \omega$
Right Half Plane	$-45^{\circ}/\text{dec} \qquad -45^{\circ}/\text{dec} \qquad \text{Approx. Phase:} -45^{\circ}log_{10}\left(\frac{10\omega}{\omega_{o}}\right),$
Zero at $\omega_o$	$\frac{\omega_o}{10} \le \omega \le 10\omega_o$

### 2.10 Summary of Bode Plots



## Chapter 3

## **Compensator Design**

### 3.1 Design Procedure

#### 3.1.1 Introduction

In this chapter we will demonstrate a procedure for designing frequency compensators for the standard feedback configuration shown in Figure 3.1. G(s), as before, represents the plant transfer function; H(s) represents the feedback gain and is used to set the closed loop gain and  $G_c(s)$  represents the compensator.



Figure 3.1: Feedback System Block Diagram

To demonstrate the design procedure, in the sequel we will use a plant and feedback gain with the following transfer functions:

$$G(s) = \frac{G_o}{\left(1 + \frac{s}{\omega_1}\right)\left(1 + \frac{s}{\omega_2}\right)\left(1 + \frac{s}{\omega_3}\right)}$$
(3.1)

$$H\left(s\right) = k \tag{3.2}$$

where  $G_o = 500$ ,  $\omega_1 = 2\pi (10)$ ,  $\omega_2 = 2\pi (100)$ ,  $\omega_3 = 2\pi (300)$ , and k = 0.5.

The compensators considered in the sequel are the following: 1) Proportional (P) compensator:

$$G_c\left(s\right) = k_p \tag{3.3}$$

2) Dominant pole (I, integrator) compensator:

$$G_c\left(s\right) = \frac{\omega_I}{s} \tag{3.4}$$

3) Dominant pole with zero (PI, proportional plus integrator) compensator:

$$G_c(s) = \frac{\omega_I}{s} \left( 1 + \frac{s}{\omega_z} \right) \tag{3.5}$$

4) Lead compensator:

$$G_c(s) = G_{c_o} \frac{1 + \frac{s}{\omega_z}}{1 + \frac{s}{\omega_p}}, \qquad \omega_z < \omega_p$$
(3.6)

5) Lead with integrator and zero compensator

$$G_{c}(s) = \frac{\omega_{I}\left(1 + \frac{s}{\omega_{z_{1}}}\right)\left(1 + \frac{s}{\omega_{z_{2}}}\right)}{s\left(1 + \frac{s}{\omega_{p}}\right)}$$
(3.7)

The first three compensators may be considered to be members of the three term controller, PID (proportional, integral, derivative), family of compensators. We will see that as the complexity of the compensator increases the performance also increases. The performance measures used are the rise time, settling time and percentage overshoot of the step response. For the simpler compensators, i.e. proportional and dominant pole compensators, only one design parameter is needed to be found. For the most involved compensator, the lead with integrator and zero compensator, there are a total of four design parameters to be determined.

#### 3.1.2 Uncompensated System

We start our evaluation with the uncompensated loop gain  $T(s) = kG_c(s)G(s)$ , where  $G_c(s) = 1$ . The loop gain is given as

$$T(s) = \frac{T_o}{\left(1 + \frac{s}{\omega_1}\right)\left(1 + \frac{s}{\omega_2}\right)\left(1 + \frac{s}{\omega_3}\right)}$$
(3.8)

where

$$T_o = G_o k = 500 \cdot 0.5 = 250$$

#### 3.1. DESIGN PROCEDURE

$$\omega_1 = 2\pi (10), \omega_2 = 2\pi (100), \omega_3 = 2\pi (300)$$

We construct the Bode plot of the loop gain, shown in Figure 3.2. Using this constructed plot we can easily determine simplified (approximate) expressions for the  $f_c$ , the unity gain crossover frequency, and PM, the phase margin:

$$\frac{T_o f_1 f_2 f_3}{f_c^3} = 1 \implies f_c = \sqrt[3]{T_o f_1 f_2 f_3}$$
(3.9)

$$PM = 180 - \arctan\left(\frac{f_c}{f_1}\right) - \arctan\left(\frac{f_c}{f_2}\right) - \arctan\left(\frac{f_c}{f_3}\right)$$
(3.10)

Equations (3.9) and (3.10) result in  $f_c = 422$  Hz and  $PM = -40^{\circ}$ .

In a similar fashion we can also determine  $f_{GM}$ , the frequency at which the phase reaches  $-180^{\circ}$ , and subsequently the gain margin:

$$-180 = -\arctan\left(\frac{f_{GM}}{f_1}\right) - \arctan\left(\frac{f_{GM}}{f_2}\right) - \arctan\left(\frac{f_{GM}}{f_3}\right)$$
(3.11)

$$GM = -20\log\left(\frac{T_o f_1 f_2}{f_{GM}^2}\right) \tag{3.12}$$

Evaluating 3.11 and 3.12 results in  $f_{GM} = 184$  Hz and GM = -17.3 dB, respectively.

Figure 3.3 is a Matlab Bode plot of the uncompensated loop gain produced using the 'margin' command. Matlab uses the unapproximated transfer function models and so is able to accurately determine the margins and associated frequencies:  $f_c = 385$  Hz,  $PM = -36.1^{\circ}$ ,  $f_{GM} = 184$  Hz and GM = -14.8 dB.

The phase margin test indicates that the uncompensated system is unstable. A Matlab time domain simulation of the step response of the uncompensated system is shown in Figure 3.4. The output quickly becomes unbounded for the unit step input indicative of an unstable system. So compensation is needed to make the system stable and further to improve the performance.

#### 3.1.3 Proportional Compensated System

In our first compensator design we will access the efficacy of using a proportional compensator:

$$G_c\left(s\right) = k_p \tag{3.13}$$

 $k_p$  simply represents a constant gain. Note that the effect of varying the value of  $k_p$  to raise and lower the magnitude Bode plot while keeping the phase Bode



Figure 3.2: Bode Plot: Uncompensated System

plot unaffected. So the value of  $k_p$  can be set to obtain unity gain crossover frequency  $(f_c)$  which results in an acceptable phase margin.

Generally the design procedure would require that asymptotic Bode plots for the now compensated loop gain be constructed, however, in the case of a



Figure 3.3: Matlab Analysis of Uncompensated System

proportional compensator, since the shape of the plots (magnitude and phase) are unchanged we need simply to replace any occurrences of the To with  $k_p To$  in Figure 3.3 and precede accordingly.

As a general rule of thumb, to obtain an acceptable phase margin (generally  $45^{\circ} \leq PM \leq 60^{\circ}$ ) one usually sets the unity gain crossover frequency  $(f_c)$  to occur in the segment of the asymptotic magnitude plot that has a slope of -20 dB/dec. From the constructed magnitude plot we find

$$\frac{k_p T_o f_1}{f_c} = 1 \implies f_c = k_p T_o f_1 \tag{3.14}$$

We can substitute the above equation for  $f_c$  into the phase margin equation shown next to determine the required value of  $k_p$ .

$$PM = 180 - \arctan\left(\frac{f_c}{f_1}\right) - \arctan\left(\frac{f_c}{f_2}\right) - \arctan\left(\frac{f_c}{f_3}\right)$$
$$= 180 - \arctan\left(k_p T_o\right) - \arctan\left(\frac{k_p T_o f_1}{f_2}\right) - \arctan\left(\frac{k_p T_o f_1}{f_3}\right) \quad (3.15)$$

With a desired value of phase margin of  $PM = 45^{\circ}$  equation (3.15) evaluates to  $k_p = 0.0311$  and  $f_c = 77.65$ .



Figure 3.4: Matlab Analysis of Uncompensated System

Using the obtained value of  $k_p$  an evaluation of the compensated loop gain with the unapproximated transfer functions was performed by Matlab and is shown in Figure 3.5 where we see that the obtained phase margin is 55°. This value, due to the approximate nature of our design equations, turns out to more than required, but nonetheless an acceptable. Had it not been so, one could simply iterate.

A step response simulation of the proportional compensated closed-loop system is shown in Figure 3.6. A summary of all the performance results are given in the table below. There we see in particular that the overshoot, rise-time, settling-time and steady-state error values are 20%, 2.9 ms, 15.4 ms and -11%, respectively.

<b>Proportional Compensation</b>		
Characteristics	Value	
Overshoot	20~%	
Rise time	2.9 ms	
Settling time	$15.4 \mathrm{\ ms}$	
Steady-state error	-11 %	
$\operatorname{Bandwidth}$	63 Hz	
Phase margin	$55^{\circ}$	
Gain margin	15 dB	



Figure 3.5: Matlab Proportional Compensated Loop Gain Bode Plot



Figure 3.6: Step Response of Proportional Compensated Closed-Loop System

#### 3.1.4 Dominant Pole Compensated System

The next form of frequency compensation to be discussed is the dominant pole compensation. As the name suggests a pole is inserted in the loop gain which dominates the dynamics of the loop. That is to say that the frequency response of the loop gain up to the unity gain crossover frequency is mainly determined by the dominant pole. To achieve this the pole needs to placed at a frequency much lower (usually a decade or so) than the lowest pole or zero of the uncompensated loop gain. This requirement unfortunately reduces the loop bandwidth and subsequently the speed of response. However, compensator design is simplified and good stability margins may be easily obtained. If the pole is placed at the zero frequency then this represents an integrator which may result in obtaining a zero steady state error characteristic.

In our design that follows, an integrator is employed such that the compensator transfer function is given as:

$$G_{c}\left(s\right) = \frac{\omega_{f}}{c}$$

where  $\omega_I = 2\pi \cdot f_I$  is an appropriately chosen design constant. Figure 3.7 shows the Bode plot asymptotes for the magnitude and phase of this compensator.



Figure 3.7: Bode Plot: Dominant Pole Compensator

Design of the compensator now consists of selecting an appropriate compensator parameter,  $f_I$ .

Figure 3.8 shows the graphical construction of the phase asymptotes for the loop gain with the compensator. Note that because the plant's transfer function is third order, it contributes a phase shift of  $-270^{\circ}$  at high frequencies and a shift of exactly  $-45^{\circ}$  at  $f_1$ . Furthermore, the compensator contributes its own  $-90^{\circ}$  phase shift and does so for all frequencies. Consequently, the total phase shift

of the compensated open loop transfer function is  $-135^{\circ}$  at the dominant pole frequency (first pole),  $f_1$ . For this reason it is prudent to design this frequency  $f_1$  to be the cut-off frequency of the overall system, so that we get a  $+45^{\circ}$  phase margin.

Figure 3.9 shows how the plant and compensator transfer functions combine to produce the gain of the compensated open loop. To achieve a phase margin that is +45°, we require the magnitude at  $f_1$  to equal 1 (0dB), therefore  $f_c = f_1$ .

$$\frac{f_I T_o}{f_1} = 1$$
$$f_I = \frac{f_1}{T_o} = \frac{10}{250} = 0.04$$

The dominant pole compensator in this case is:

$$G_c\left(s\right) = \frac{\omega_I}{s} = \frac{2\pi \cdot 0.04}{s}$$

Figure 3.10 shows resulting gain and phase asymptotic construction of the Bode plot. We next run the full unapproximated compensated loop transfer function through the Matlab 'margin' command to verify the design results. Figure 3.11 shows the results obtained. In particular, a phase margin of  $PM = 45.9^{\circ}$  with a unity gain crossover frequency  $f_c = 7.84$  Hz was obtained, which compares favorably with the design values of  $PM = 45^{\circ}$  and  $f_c = f_1 = 10$  Hz.

Figure 3.12 shows the unit step response of the dominant pole compensated closed loop system. It is clearly seen that zero steady state response has been attained but not without going through significant overshoot first. The features of the closed loop system are summarized in the table below.

Dominant Pole Compensation			
Characteristics	Value		
Peak amplitude	22.2% overshoot		
Rise time	$24.7 \mathrm{ms}$		
Settling time	$134 \mathrm{\ ms}$		
Steady-state error	0 %		
Bandwidth	7.84 Hz		
Phase margin	$45.9^{\circ}$		
Gain margin	18.2 dB		

#### 3.1.5 Dominant Pole Compensated System with zero

The dominant pole compensator of the previous section, while stable and featuring zero steady state error performance, exhibits several undesirable characteristics which include a large overshoot and long settling time.



Figure 3.8: Dominant Pole: Phase Construction

The reason is that when we compensate to make the system stable, we have sacrificed the bandwidth of the system. Unfortunately, the lower the bandwidth,



Figure 3.9: Dominant Pole: Magnitude Construction

the slower the response. Thus, we need to increase the bandwidth to speed up the response.



Figure 3.10: Dominant Pole Compensated System

This can be done by adding a zero to the compensator that will cancel the lowest pole of the system that occurs at a very low frequency. By doing that,



Figure 3.11: Matlab Analysis of Dominant Pole Compensated System

the next higher pole at 100Hz now becomes the dominant pole that we will compensate for. Thus we will be able to extend the bandwidth by a decade.

The transfer function for the compensator in this case is chosen to be

$$G_{c}\left(s\right) = \frac{\omega_{I}}{s}\left(1 + \frac{s}{\omega_{z}}\right)$$

where

$$\omega_z = \omega_1$$

The loop gain  $T(s) = kG_c(s)G(s)$  for this compensator now becomes:

$$T(s) = \frac{T_o \omega_I}{s \left(1 + \frac{s}{\omega_2}\right) \left(1 + \frac{s}{\omega_3}\right)}$$

The magnitude and phase Bode plots using the asymptotic construction procedure is shown in Figure 3.14. Using the low frequency magnitude asymptote we see that at the unity gain crossover frequency  $f_c$ 

$$\frac{f_I T_o}{f_c} = 1$$



Figure 3.12: Step Response of the Dominant Pole Compensated System

$$\implies f_c = T_o f_I$$

The general expression for  $\phi_f$ , the phase response at an arbitrary frequency f is given by:

$$\phi_f = -90 - \arctan\left(\frac{f}{f_2}\right) - \arctan\left(\frac{f}{f_3}\right)$$
 (3.16)

Consequently the phase margin is given by:

$$PM = 180 + \phi_{f_c}$$
  
= 90 - arctan  $\left(\frac{f_c}{f_2}\right)$  - arctan  $\left(\frac{f_c}{f_3}\right)$   
= 90 - arctan  $\left(\frac{T_o f_I}{f_2}\right)$  - arctan  $\left(\frac{T_o f_I}{f_3}\right)$  (3.17)

With a design value of  $PM = 45^{\circ}$  the required value of  $f_I$  is solved using Equation (3.17) to yield  $f_I = 2\pi$ (??) = 1.6.

To verify the design procedure the unapproximated loop gain transfer function is run through the Matlab 'margin' command which produces the plot shown in Figure 3.15. The obtained phase margin and bandwidth are seen to be  $PM = 51^{\circ}$  and  $f_c = 56$  Hz. The bandwidth has been greatly improved.



Figure 3.13: Dominant Pole with Zero Magnitude Construction

The unit step response of the closed loop system is shown in Figure 3.16. A summary of the performance using this compensator is shown in the following



Figure 3.14: Dominant Pole with Zero Compensated System

table.



Figure 3.15: Loop Gain and Phase Response of the Dominant Pole Compensated System with Zero

Dominant Pole with Zero Compensation				
Characteristics	Value			
Overshoot	22.2%			
Rise time	$3.05 \mathrm{\ ms}$			
Settling time	16.7 ms			
Steady-state error	0 %			
$\operatorname{Bandwidth}$	62.3 Hz			
Phase margin	46.3 degree			
Gain margin	14.5 dB			

# 3.1.6 Dominant Pole Compensated System with zero, improved phase margin

The addition of the zero to dominant pole compensation has allowed us to increase the speed of response by extending bandwidth. This is manifested in the time domain response by a substantial decrease in the rise and settling times. However, the overshoot, while slightly improved, may be seen as overly large. Nevertheless, it too may be reduced by appreciating the fact that overshoot and phase margin are inversely related. So we will increase the phase margin to reduce the overshoot.



Figure 3.16: Step Response of the Dominant Pole with Zero Compensated System

Using the same compensator as in the previous section, we will now redesign it to achieve a phase margin of 60°. The zero frequency is left unchanged, so that  $\omega_z = \omega_1$ , but a new value of  $\omega_I$  will be determined to achieve the desired 60° phase margin. Solving equation (3.17), now with PM = 60 we see the required value of  $f_I = 1.6$  so that  $\omega_I = 2\pi f_I = 1.6$ .

To verify the design the Bode plot of the loop gain was produced using the 'margin' command in Matlab. This plot is shown in figure 3.17. We see that a phase margin of  $62^{\circ}$  was achieved with a bandwidth of 37.9 Hz. Of course the extension in phase margin is necessarily accompanied by a reduction in bandwidth

The step response of the closed loop system is shown in figure 3.18. The resulting performance characteristics are tabulated in the table below. There we see that the overshoot has been reduced to 6%. Recall that a phase margin of  $45^{\circ}$  had previously resulted in a 17% overshoot. This reduction in overshoot has been attained at the expense of an increase in rise time. However, the settling time has been slightly reduced.



Figure 3.17: Matlab Analysis of Dominant Pole Compensated System with Zero (Improved Margin)

Dominant Pole with Zero Compensation (Improved Margin)				
Characteristics	Value			
Overshoot	4.46 %			
Rise time	5.81 ms			
Settling time	16.5 ms			
Steady-state error	0			
Bandwidth	35.1 Hz			
Phase margin	64 degree			
Gain margin	20.6 dB			

#### 3.1.7 Lead Compensated System

Next we consider the case of using a lead compensator, the transfer function of which is given by:

$$G_c(s) = G_{c_o} \frac{1 + \frac{s}{\omega_z}}{1 + \frac{s}{\omega_p}}, \qquad \omega_z < \omega_p$$
(3.18)

Tee design of this compensator requires the appropriate determination of the three variables,  $G_{c_o}$ ,  $f_z$  and  $f_p$ , the low frequency gain, zero frequency and pole



Figure 3.18: Step Response of the Dominant Pole with Zero Compensated System (Improved Margin)

frequency, respectively. Note in particular that the zero frequency is required to be at a lower value than the pole frequency. This constraint exists so that the phase response, first starting at zero at low frequencies, becomes positive, i.e. leads, as the frequency increases before returning to zero at high frequencies. In essence, the lead compensator provides a phase boost that is adjustable based on the pole and zero frequencies. The maximum phase boost  $\phi_{max}$  possible is  $\phi_{max} = 90^{\circ}$  and occurs at a frequency  $f_{\phi_{max}}$  which is the geometric mean of the zero and pole frequencies of the compensator. The geometric mean of two numbers represents the midpoint between these numbers when represented on a logarithmic scale.

$$f_{\phi_{max}} = \sqrt{f_z f_p} \tag{3.19}$$

The compensator also provides a gain boost at higher frequencies so that with proper design is can both extend loop bandwidth while increasing the phase margin. Proper design of the compensator requires that the frequency of maximum boost afforded by this compensator is set to the unity gain crossover frequency,  $f_c$ . The asymptotic Bode plot of the lead compensator is shown in Figure 3.19.

When the compensator is placed in the loop, the loop gain of the system now becomes:



Figure 3.19: Bode Diagram: Lead Compensator

$$T\left(s\right) = \frac{T_{o}G_{co}\left(1 + \frac{s}{\omega_{z}}\right)}{\left(1 + \frac{s}{\omega_{p}}\right)\left(1 + \frac{s}{\omega_{1}}\right)\left(1 + \frac{s}{\omega_{2}}\right)\left(1 + \frac{s}{\omega_{3}}\right)}$$

The construction of the asymptotic magnitude response from the constituent parts is shown in Figure 3.20. Both the resulting magnitude and phase asymptotic responses of the loop gain are shown in Figure 3.21. As for previous compensators, the annotations on these plots are used in the design procedure. The exact expression for the phase  $\phi$  is given by:

$$\phi_f = \arctan\left(\frac{f}{f_z}\right) - \arctan\left(\frac{f}{f_p}\right) - \arctan\left(\frac{f}{f_1}\right) - \arctan\left(\frac{f}{f_2}\right) - \arctan\left(\frac{f}{f_3}\right)$$
(3.20)



Figure 3.20: Lead Compensation Magnitude Construction

Consequently the phase margin is given by:

$$PM = 180 + \phi_{f_c}$$
  
= 180 + arctan  $\left(\frac{f_c}{f_z}\right)$  - arctan  $\left(\frac{f_c}{f_p}\right)$  - arctan  $\left(\frac{f_c}{f_1}\right)$   
- arctan  $\left(\frac{f_c}{f_2}\right)$  - arctan  $\left(\frac{f_c}{f_3}\right)$  (3.21)



Figure 3.21: Lead Compensated System

As mentioned previously, we will set the unity gain crossover frequency  $f_c$  to the maximum phase boost frequency  $f_{\phi_{max}}$  so that using equation (3.19) we

have:

$$f_c = f_{\phi_{max}}$$
$$= \sqrt{f_z f_p}$$
(3.22)

In order to minimize the effect on the phase margin of the phase lag due to the compensator pole we will set this pole frequency an order of magnitude above the crossover frequency:

$$f_p = 10f_c \tag{3.23}$$

Equation (3.23) together with equation (3.22) results in a constraint between the zero and pole frequencies of the compensator:

$$f_p = 100 f_z \tag{3.24}$$

We can use the zero frequency of the compensator to cancel the pole frequency  $f_2$  of the plant, so that  $f_z = f_2$ . This together with equations (3.24) and (3.21) may be used to determine the unity gain crossover frequency,  $f_c$  for a given desired phase margin. For a desired phase margin of 60° we find  $f_c = 164$  Hz.

From the magnitude asymptote we see that

$$\frac{T_o G_{c_o} f_1}{f_c} = 1 \tag{3.25}$$

so that for a given  $f_c$  we can solve for the required compensator low frequency gain  $G_{c_c}$ :

$$G_{c_o} = \frac{f_c}{T_o f_1} \tag{3.26}$$

For our design we obtain a value of  $G_{c_o} = ??$ .

To verify our design we produce the plot using the Matlab 'margin' command on the unapproximated transfer functions of the compensated loop. This is show in figure 3.22. There we find that the obtained phase margin is  $PM = 62^{\circ}$ with  $f_c = ???$ , which validates our design procedure.

The unit step response of the closed loop system with this compensation is shown in figure 3.23. The features of the step response are presented in the table below. We see, due to the extended bandwidth, that the speed of response, represented by the rise and settling times is quite good. Percentage overshoot is also relatively low due to the 60° phase margin employed. However, as there is no longer an integrator in the forward path, the steady state error is now non-zero. This will be remedied in the next and final compensator design.

56



Figure 3.22: Matlab Analysis of Lead Compensated System

Lead Compensation					
Feature	Value				
Overshoot	4.23~%				
Rise time	$2.25 \mathrm{\ ms}$				
Settling time	$6.29 \mathrm{\ ms}$				
Steady-state error	10%				
Bandwidth	83.8 Hz				
Phase margin	71.2°				
Gain margin	$19.3 \mathrm{~dB}$				

#### 3.1.8 Lead Compensated System with integrator and zero

In this final compensator design, we will augment the lead compensator of the previous section with an integrator and zero. The integrator is added to provide the closed loop system with a zero steady state error performance. This is contrasted with the approach previously discussed where the integrator was primarily used to as the dominant pole. In the present case by canceling lower frequency poles, we're able to extend the unity gain bandwidth of the loop gain to obtain quick closed loop response. The zero is added to leave the high frequency magnitude and phase response unchanged from the lead compensator case.



Figure 3.23: Step Response of the Lead Compensated System

The transfer function of the compensator considered here is given by:

$$G_{c}(s) = \frac{\omega_{I}\left(1 + \frac{s}{\omega_{z_{1}}}\right)\left(1 + \frac{s}{\omega_{z_{2}}}\right)}{s\left(1 + \frac{s}{\omega_{p}}\right)}$$
(3.27)

The parameters  $\omega_{z_2}$  and  $\omega_p$  correspond to  $\omega_z$  and  $\omega_p$  of the lead compensator design, which leaves  $\omega_I$  and  $\omega_{z_1}$  to be determined.  $\omega_{z_1}$  can be simply set to  $\omega_1$ . The low frequency gain of the lead compensator of the previous section was denoted  $G_{c_o}$ . This was the value of the loop magnitude at  $f_1$  (in particular, and below this frequency, in general). To maintain this value of gain at  $f_1$  we will adjust  $\omega_I$  to achieve this. The low frequency magnitude asymptote is given by  $\frac{f_I}{f}$  so that at  $f_1$  we have

$$\frac{f_I}{f_1} = G_{c_o} \implies f_I = G_{c_o} f_1 \tag{3.28}$$

This completes the design of this compensator. To verify our design we produce the plot using the Matlab 'margin' command on the unapproximated transfer functions of the compensated loop. This is show in figure 3.24. There we find that the obtained phase margin is  $PM = 60^{\circ}$  with  $f_c = 164$  Hz, which very closely agrees with the results obtained for the lead compensator.

Next, we exam the step response of the closed loop system which is shown in 3.25. It is clear that now we have zero steady state error. Further performance features are given in the table below.



Figure 3.24: Matlab Analysis of Lead Compensated System with integrator and zero

Lead Compensation with integrator and zero			
Feature	Value		
Overshoot	4.23~%		
Rise time	$2.25 \mathrm{\ ms}$		
Settling time	$6.29 \mathrm{\ ms}$		
Steady-state error	10%		
$\operatorname{Bandwidth}$	83.8 Hz		
Phase margin	71.2°		
Gain margin	19.3 dB		

#### 3.1.9 Summary

The following table shows the summary of all of the results.



Figure 3.25: Step Response of the Lead Compensated System with integrator and zero  $% \mathcal{A}$ 

where $G_o = 500, \ \omega_1 = 2\pi (10), \ \omega_2 = 2\pi (100), \ \omega_3 = 2\pi (300), \ \text{and} \ k = 0.5.$								
$G_c(s)$	$G_c(s)$ parameters	$\begin{array}{c} f_c \\ (\mathrm{Hz}) \end{array}$	$\phi_{PM}$ (deg)	GM (dB)	OS (%)	$t_r$ (ms)	$t_s$ (ms)	ERR (%)
$1 \ (uncompensated)$	none	385	-36	-15	na	na	na	$\infty$
$k_p$	$k_p = 0.03$	63	55	15	20	2.9	15.4	-11
$\frac{\omega_I}{s}$	$\omega_I = 0.25$	7.8	46	18	22	25	137	0
$\frac{\omega_I}{s}\left(1+\frac{s}{\omega_z}\right)$	$\omega_I = 1.62$ $\omega_z = 2\pi(10)$	56	51	16	17	34	18	0
$\frac{\omega_I}{s} \left( 1 + \frac{s}{\omega_z} \right)$	$\omega_I = 1.03$ $\omega_z = 2\pi(10)$	38	62	20	6	5.3	16	0
$G_{c_o} \frac{1 + \frac{s}{\omega_z}}{1 + \frac{s}{\omega_p}}$	$G_{c_o} = 0.075$ $\omega_z = 2\pi (100)$ $\omega_p = 2\pi (10,000)$	164	64	35	8.1	1.3	3.9	-5
$\frac{\omega_I \left(1 + \frac{s}{\omega_{z_1}}\right) \left(1 + \frac{s}{\omega_{z_2}}\right)}{s \left(1 + \frac{s}{\omega_p}\right)}$	$\omega_I = 4.71$ $\omega_{z_1} = 2\pi(10)$ $\omega_{z_2} = 2\pi(100)$ $\omega_p = 2\pi(10,000)$	164	60	35	8.3	1.3	4	0

Table 3.1: Summary of Compensators  $G(s) = \frac{G_o}{\left(1 + \frac{s}{\omega_1}\right)\left(1 + \frac{s}{\omega_2}\right)\left(1 + \frac{s}{\omega_3}\right)}$ 

$$-\frac{s}{\omega_1}\left(1+\frac{s}{\omega_2}\right)\left(1+\frac{s}{\omega_3}\right)$$

$$H\left(s\right)=k$$

0 (100)  $2\pi$  (200) and k = 0.5- $\mathbf{O}$  (10)

```
3.1.10 MATLAB Code
```

```
1 function compensators
2
3 clear all;
4 close all;
5
6 t = linspace(0, 0.35, 10000);
7 f = logspace(-1, 4, 1000);
8 w = 2*pi*f;
9 s = tf('s');
10
11 Go = 500;
12 fl = 10;
13 f2 = 100;
14 f3 = 300;
15
16 w1 = 2*pi*f1;
17 w2 = 2*pi*f2;
18 w3 = 2*pi*f3;
19 k = 0.5;
20 To = Go*k;
21 yf = 2;
^{22}
23
  <u>%______</u>
25 % UNCOMPENSATED
27
28 G = Go/((1+s/w1)*(1+s/w2)*(1+s/w3));
29
30 titl = 'Uncompensated System';
31 Gc = 1;
32
x1mt = [0.325 0.35];
34 disp(titl)
35 analysis(Gc, G, k, w, titl, t, xlmt, yf)
36
37 %
         RiseTime: 0.0031
38 %
     SettlingTime: 0.3500
39 %
      SettlingMin: -9.9007e+79
40 응
      SettlingMax: -8.9587e+79
41 응
       Overshoot: 0
42 응
       Undershoot: 55.0478
         Peak: 9.9007e+79
43 응
44 %
        PeakTime: 0.3500
^{45}
46 %-----
47
  <u>}_____</u>
48 % Proportional Compensation
49 %-----
50
51 fn = @(kp) 135 - atan2d(To*f1*kp, f1) - atan2d(To*f1*kp, f2) ...
             - atan2d(To*f1*kp, f3);
52
53 kp = fzero(fn, 0) % kp = 0.0311
54 fc = To*fl*kp
```

```
55
56 titl = 'Proportional Compensation';
57 Gc = kp;
58
59 xlmt = [0 0.035];
60 disp(titl)
61 analysis(Gc, G, k, w, titl, t, xlmt, yf)
62
         RiseTime: 0.0029
63 %
64 %
      SettlingTime: 0.0154
65 %
       SettlingMin: 1.6011
66 %
       SettlingMax: 2.1341
67 %
        Overshoot: 20.4502
        Undershoot: 0
68 %
  Ŷ
            Peak: 2.1341
69
70 %
         PeakTime: 0.0068
71
73 %_____
74 % Dominant Pole Compensation
_____
76
77 titl = 'Dominant Pole Compensation';
           % 0.2513
78 WI = W1/TO
79 Gc = wI/s;
80
s_1 x lmt = [0 0.3];
82 disp(titl)
83 analysis(Gc, G, k, w, titl, t, xlmt, yf)
84
85 %
          RiseTime: 0.0245
86 %
      SettlingTime: 0.1365
       SettlingMin: 1.8000
87 %
       SettlingMax: 2.4440
  00
88
89
  8
         Overshoot: 22.2103
90 %
        Undershoot: 0
91 🖇
          Peak: 2.4440
         PeakTime: 0.0580
92 응
93
96 % Dominant Pole With Zero Compensation
98
99 titl = 'Dominant Pole With Zero Compensation';
100
101 fn = @(fI) 45 - atan2d(To*fI, f2) - atan2d(To*fI, f3);
102 fI = fzero(fn, 0)
103
             % 64.58
104 fc = To*fI
105 wI = 2*pi*fI % 1.623
106 Gc = wI/s*(1+s/w1);
107
108
109 xlmt = [0 \ 0.030];
110 disp(titl)
111 analysis(Gc, G, k, w, titl, t, xlmt, yf)
```

```
112
113 %
         RiseTime: 0.0034
114 %
      SettlingTime: 0.0175
       SettlingMin: 1.8012
115 %
116 %
       SettlingMax: 2.3496
117 %
         Overshoot: 17.4798
        Undershoot: 0
118 %
119 %
          Peak: 2.3496
         PeakTime: 0.0079
120 %
121
124 % Dominant Pole With Zero Compensation (Improved Phase Margin)
126
127 titl = 'Dominant Pole With Zero Compensation (Improved PM)';
128
129 fn = @(fI) 30 - atan2d(To*fI, f2) - atan2d(To*fI, f3);
130 fI = fzero(fn, 0)
131
132 fc = To*fI
                     8 40.88
133 wI = 2*pi*fI
                     8 1.0276
134 Gc = wI/s \star (1+s/w1);
135
136 xlmt = [0 \ 0.03];
137 disp(titl)
138 analysis(Gc, G, k, w, titl, t, xlmt, yf)
139
140 %
          RiseTime: 0.0053
141 %
      SettlingTime: 0.0159
142 %
       SettlingMin: 1.8014
143 %
       SettlingMax: 2.1219
144 %
         Overshoot: 6.0951
  2
        Undershoot: 0
145
146 응
          Peak: 2.1219
147 %
         PeakTime: 0.0113
148
<u>%_____</u>
150
151 % Lead Compensation
152 %=======
153
154 fz = 100
             % = f2
155 fp = 100*fz
156 fn = @(fc) 120 + atan2d(fc, fz) - atan2d(fc, f1) ...
             - atan2d(fc, f2) - atan2d(fc, f3) - atan2d(fc, fp);
157
158 fc = fzero(fn, 0)
                    8 187
159 Gco = fz*fc/(To*f1*f2) % 0.0749
160 wz = 2*pi*fz;
161 wp = 2*pi*fp;
162
163 titl = 'Lead Compensation';
164 Gc = Gco*(1+s/wz)/(1+s/wp);
165
166 \text{ xlmt} = [0 \ 0.008];
167 disp(titl)
168 analysis(Gc, G, k, w, titl, t, xlmt, yf)
```
```
169
170 %
          RiseTime: 0.0013
171 %
        SettlingTime: 0.0039
172 🖇
        SettlingMin: 1.7192
        SettlingMax: 2.0517
173 %
174 %
          Overshoot: 8.0633
175 %
         Undershoot: 0
176 %
           Peak: 2.0517
          PeakTime: 0.0027
177 %
178
180 %-----
181 % Combined Compensation
182 %------
183
184 titl = 'Combined Compensator';
185 % fc, unity gain xover frequency: same value as for lead compensator
186 wI = 2*pi*fc/To % 4.7
187 wz1 = w1;
188 wz2 = w2;
189 % wp: use the same value as for lead compensator
190 Gc = wI*(1+s/wz1)*(1+s/wz2)/(s*(1+s/wp));
191
192 xlmt = [0 \ 0.008];
193 disp(titl)
194 analysis(Gc, G, k, w, titl, t, xlmt, yf)
195
196 응
          RiseTime: 0.0013
        SettlingTime: 0.0040
197
   8
198
   2
        SettlingMin: 1.8121
   ę
        SettlingMax: 2.1662
199
   응
          Overshoot: 8.3110
200
201 🖇
         Undershoot: 0
   Ŷ
              Peak: 2.1662
202
           PeakTime: 0.0027
203 %
204 end
205
206
207 function s = analysis(Gc, G, k, w, titl, t, xlmt, yf)
208
209 % loop gain
210 L = Gc*G*k;
211
212 figure
213 [mag, phase] = bode(L,w);
214 margin(mag, phase, w);
215
216 h = gcr;
217 h.AxesGrid.Xunits = 'Hz';
218 h.AxesGrid.TitleStyle.FontSize = 12;
219 h.AxesGrid.XLabelStyle.FontSize = 12;
220 h.AxesGrid.YLabelStyle.FontSize = 12;
221
223
224 % closed loop gain
225 Gs = 1/k \star L/(1+L);
```

```
226
227 % Plot of Step response results
228 figure
229 yout = step(Gs, t);
230 plot(t, yout);
231 grid on;
232 title(titl,'FontSize',12);
233 xlabel('Time (sec)','FontSize',12);
234 ylabel('Magnitude','FontSize',12);
235 xlim(xlmt);
236
237 % Time Domain Analysis Parameters
238 s = stepinfo(yout,t);
239 ss_error = (yout(end)-yf)/yf * 100
240 end
```

66

# Chapter 4

# Modelling - Introduction

## 4.1 Introduction

In the following chapters we will present a simple practical system to which we will apply precise control. This system is a dc-to-dc power converter for which we desire to have accurate control of the output voltage as it will function as a voltage regulator subject to input voltage and output load variations.

thus we start with a plant which is given as a circuit configuration for which we need to derive a model, which in the case of the classical control design approach we will be applying, will need to be a transfer function model. Using this model a compensator transfer function will be designed and subsequently the closed loop performance will be simulated.

To fully verify the practical design a number of extra steps will need to be undertaken. This involves actual realization of the compensator transfer function into an appropriate circuit which is then used in a circuit level simulation to assess the performance achieved. If deemed not satisfactory then this process may be iterated. This procedure is represented in the flow chart shown in Figure 4.1.



Figure 4.1: Design Flow Diagram

# Chapter 5

# The System

# 5.1 Introduction

In this chapter, the parameters for an example control system will be defined and derived. From the parameters of this example system, subsequent chapters will be devoted to applying control design techniques to optimize system performance parameters.

A control system begins with a model for plant, that has at least one particular parameter to be controlled. To control the plant, the parameter to be controlled is compared to a stable reference value and the difference is input to an error amplifier. The error amplifier then commands the plant, controlling the desired plant parameter. A basic diagram illustrating this architecture is shown in Figure 5.1.



Figure 5.1: Feedback System Block Diagram

### 5.2 The Plant: Buck Converter

#### 5.2.1 Introduction

The fundamental item in every control system is the plant, the item that is to be controlled. In this section, the plant will be defined as a buck converter, a switched mode DC power supply.



Figure 5.2: Buck Converter Circuit System Diagram

The buck regulator, which is shown complete in Figure 5.2 including circuit losses and feedback compensation, is a basic switched mode power supply. The buck regulator acts to reduce the steady state output voltage based on an applied duty cycle of applied input voltage. The duty cycle is switched at a frequency higher than the resonant frequency LC tank on the output. The output filter allows the circuit to convert the input voltage to a lower output voltage with minimal circuit losses.

The complete system block diagram for the buck regulator is shown in Figure 5.4. The output voltage of the system is fed back to a reference (reduced by H(s)), and the difference (error signal) is fed to a compensator which drives a pulse-width modulator to control the output voltage. Additionally, this model includes disturbance inputs in terms of step loading and input voltage variation for design characterization.

#### 5.2.2 Transfer Function Derivations

To model the plant based on the diagram of Figure 5.4, three transfer functions are required to be derived. The transfer function are the control to output  $G_{vd}(s)$ , input voltage to output  $G_{vg}(s)$ , and the output current to output



Figure 5.3: Simplified System Diagram



Figure 5.4: Generalized Power System Model

voltage, or open loop output impedance  $Z_{out}(s)$ . Additional transfer functions will be derived in the section, such as the control to inductor current  $G_{id}(s)$ , output current to inductor current  $G_{ii}(s)$ , and the input voltage to inductor current  $G_{ivg}(s)$ . These transfer functions will be utilized in following chapters.

Using the state space analysis approach, the complete set of transfer functions will be derived for the buck converter shown in Figure 5.5.

### $G_{vd}(s)$ Analysis

To analyze the small signal control to output transfer function of the buck converter, an output load change is modeled with a current source, as shown in Figure 5.5. In terms of the state space analysis, this additional source will be modeled as another input variable to the system.



Figure 5.5: Buck Converter Circuit with Non-Ideal Circuit Elements

Listed below are the fundamental equations for state space analysis. x defines the state variables of the system and the u variables define the inputs. The number of states is defined by the number of storage elements in the system. For the buck converter, there are two states. The output voltage of the converter is the voltage across the capacitor and the corresponding parasitic resistance.

$$x = \begin{bmatrix} i \\ v \end{bmatrix}$$
$$u = \begin{bmatrix} v_g \\ i_o \end{bmatrix}$$
$$\dot{x} = Ax + Bu$$
$$y = Cx + Eu$$

Applying the principles of superposition to the buck converter, the capacitor current and inductor voltage equations are found and summarized below for both switch positions.

During DTs,

$$L\frac{di_{L}}{dt} = -(r_{l} + r_{c} || R)i_{L} - \frac{R}{R + r_{c}}V_{c} + V_{g} + I_{o}(R || r_{c})$$
$$C\frac{dV_{c}}{dt} = \frac{R}{R + r_{c}}i_{L} - \frac{1}{R + r_{l}}V_{c} + 0V_{g} - \left(\frac{R}{R + r_{c}}\right)I_{o}$$
$$V_{out} = (r_{c} || R)i_{L} + \frac{R}{R + r_{c}}V_{c} + 0V_{g} - (R || r_{c})I_{o}$$



Figure 5.6: Buck Converter Superposition Analysis: DTs

During D'Ts,

$$L\frac{di_{L}}{dt} = -(r_{l} + r_{c} || R)i_{L} - \frac{R}{R + r_{c}}V_{c} + 0V_{g} + I_{o}(R || r_{c})$$
$$C\frac{dV_{c}}{dt} = \frac{R}{R + r_{c}}i_{L} - \frac{1}{R + r_{l}}V_{c} + 0V_{g} - \left(\frac{R}{R + r_{c}}\right)I_{o}$$
$$V_{out} = (r_{c} || R)i_{L} + \frac{R}{R + r_{c}}V_{c} + 0V_{g} - (R || r_{c})I_{o}$$

With the circuit defined over the two subintervals, the A, B, C, and E matrices can be defined as shown below:



Figure 5.7: Buck Converter Superposition Analysis: D'Ts

$$A_{1} = A_{2} = A = \begin{bmatrix} -\frac{(r_{c} || R + r_{l})}{L} & -\frac{R}{(R + r_{c})L} \\ \frac{R}{(r_{c} + R)C} & -\frac{1}{(r_{c} + R)C} \end{bmatrix}$$
$$B_{1} = \begin{bmatrix} \frac{1}{L} \\ 0 \end{bmatrix}$$
$$B_{2} = \begin{bmatrix} 0 \\ 0 \end{bmatrix}$$
$$B_{2} = \begin{bmatrix} 0 \\ 0 \end{bmatrix}$$
$$B = \begin{bmatrix} \frac{D}{L} \\ 0 \end{bmatrix}$$

$$C_1 = C_2 = C = \begin{bmatrix} (r_c || R) & \frac{R}{R + r_c} \end{bmatrix}$$
  
 $E_1 = E_2 = E = \begin{bmatrix} 0 & -(r_c || R) \end{bmatrix}$ 

With the state space matrices defined, the control to output transfer function can be calculated as  $G_{vd}(s) = C(sI-A)^{-1}Bd + Ed$ , where  $B_d = (A_1 - A_2)X + (B_1 - B_2)U$  and  $E_d = (C_1 - C_2)X + (E_1 - E_2)U$ . Applying basic matrix manipulation techniques,  $G_{vd}(s)$  is calculated below.

$$X = -A^{-1}BU = \begin{bmatrix} \frac{DVg}{R+r_l} - Io\left(\frac{R^2}{(R+r_c)(R+r_l)} - \frac{Rr_c}{(R+r_c)(R+r_l)}\right) \\ I_o\left(\frac{R^2r_c}{(R+r_c)(R+r_l)} + \frac{R(Rr_c+Rr_l+r_cr_l)}{(R+r_c)(R+r_l)}\right) + \frac{DRV_g}{R+r_l} \end{bmatrix}$$
$$B_d = (A_1 - A_2)X + (B_1 - B_2)U = \begin{bmatrix} \frac{V_g}{L} \\ 0 \end{bmatrix}$$
$$E_d = (C_1 - C_2)X + (E_1 - E_2)U = 0$$

$$G_{vd}(s) = C(sI - A)^{-1}Bd + Ed = \frac{V_g \left(1 + sRC\right)}{\frac{r_c + R}{R}s^2LC + s\left(\frac{L}{R} + \left(r_l + r_c + \frac{r_c r_l}{R}\right)C\right) + \frac{(R + r_l)}{R}}$$

### $G_{ii}(s)$ Analysis

When calculating the output load to inductor current transfer function, it can be noticed that the inductor voltage and capacitor current equations will be identical to those used in calculating  $G_{vd}(s)$  above. Using this fact, only the output equation is needed to be derived to find the C and E matrices.

$$y = i$$

$$C_1 = C_2 = C = \begin{bmatrix} 1 & 0 \end{bmatrix}$$

$$E_1 = E_2 = E = \begin{bmatrix} 0 & 0 \end{bmatrix}$$

Using the values found above, the output load to inductor current function is equal to  $G_{ii}(s) = -(C(sI - A)^{-1}B + E)$ , with the negative sign due to the defined current direction.

$$G_{ii}(s) = C(sI - A)^{-1}B + E = \frac{\left(\frac{R - r_c}{R + r_l} + sr_cC\right)}{\frac{r_c + R}{R}s^2LC + s\left(\frac{L}{R} + \left(r_l + r_c + \frac{r_cr_l}{R}\right)C\right) + \frac{(R + r_l)}{R}}$$

 $G_{id}(s), G_{vv_g}(s), \text{ and } G_{iv_g}(s)$  Analysis

To calculate  $G_{id}(s)$ , the control to inductor current transfer function,  $G_{vv_g}(s)$ , the input voltage to output voltage transfer function and  $G_{iv_g}(s)$ , the input voltage to inductor current transfer function, the same parameters derived above can be used to solve each equation.

$$\begin{aligned} G_{id}(s) &= C(sI-A)^{-1}Bd + Ed = \frac{V_g}{R} \frac{(1+s\left(R+r_c\right)C\right)}{\frac{r_c+R}{R}s^2LC + s\left(\frac{L}{R} + \left(r_l+r_c+\frac{r_cr_l}{R}\right)C\right) + \frac{(R+r_l)}{R}} \\ G_{vvg}(s) &= C(sI-A)^{-1}B + E = \frac{D\left(1+sr_cC\right)}{\frac{r_c+R}{R}s^2LC + s\left(\frac{L}{R} + \left(r_l+r_c+\frac{r_cr_l}{R}\right)C\right) + \frac{(R+r_l)}{R}} \\ G_{ivg}(s) &= C(sI-A)^{-1}B + E = \frac{\frac{D}{R}\left(1+s\left(R+r_c\right)C\right)}{\frac{r_c+R}{R}s^2LC + s\left(\frac{L}{R} + \left(r_l+r_c+\frac{r_cr_l}{R}\right)C\right) + \frac{(R+r_l)}{R}} \end{aligned}$$

### $Z_o(s)$ Analysis

To calculate the output impedance of the Buck converter, it is possible to use state space analyses techniques. However, due to the input voltage connection of the Buck converter we can take advantage of the fact that the impedance of the buck on the output looks the same regardless of the switch location.



Figure 5.8: Ideal Buck Converter Circuit

$$Z_o(s) = SL \|\frac{1}{sC}\|R = \frac{sL}{1 + s\frac{L}{R} + s^2LC}$$



Figure 5.9: Buck Converter Circuit with Non-Ideal Circuit Elements

One way to incorporate losses into the impedance function is to replace the energy storage element in the impedance equation with the sum of the element and its non-ideal resistive component. Starting with the inductor, every instance of sL is replaced with  $sL + r_l$  in  $Z_o(s)$ .

$$Z_o(s) = \frac{sL + r_l}{1 + \frac{r_l}{R} + s\left(\frac{L}{R} + r_lC\right) + s^2LC}$$

Assuming  $\frac{r_l}{R} \ll 1$ 

$$Z_o(s) = \frac{sL + r_l}{1 + s\left(\frac{L}{R} + r_lC\right) + s^2 LC}$$

Now, adding the ESR of the capacitor:

$$sC \Rightarrow \frac{sC}{1+SR_c}$$
$$Z_o(s) = \frac{(sL+r_l)\left(1+sr_cC\right)}{1+s\left(\frac{L}{R}+(r_l+r_c)C\right)+s^2\left(1+\frac{r_c}{R}\right)LC}$$

The complete output impedance of the Buck converter is found to be:

$$Z_{o}(s) = \frac{r_{l} \left(1 + s\frac{L}{r_{l}}\right) (1 + sr_{c}C)}{1 + s\left(\frac{L}{R} + (r_{l} + r_{c})C\right) + s^{2}LC}$$

Assuming  $\left(\frac{r_c}{R} << 1\right)$ .

To summarize the results of this section, Figure 5.10 shows the results of the state space analysis for the buck converter presented in this chapter. The results of the analysis will be leveraged throughout the text.

Buck Converter Transfer Functions			
	Ideal Case	Losses Included	
	$Q = \frac{R}{L}\sqrt{LC} \qquad r_l = 0$	$Q = rac{\sqrt{LC}}{(r_c + r_l)C + rac{L}{R}}$ $r_l  eq 0,  rac{r_l}{R} << 1$	
	$\omega_0 = rac{1}{\sqrt{LC}}$ $r_c = 0$	$\omega_0 = rac{1}{\sqrt{LC}}$ $r_c  eq 0,  rac{r_c}{R} << 1$	
	$\triangle(s) = 1 + \frac{s}{\omega_0 Q} + \left(\frac{s}{\omega_0}\right)^2$		
$G_{vd} \triangleq \frac{\hat{v}}{\hat{d}}$	$rac{V_g}{ riangle(s)}$	$\frac{V_g(1+sr_cC)}{\triangle(s)}$	
$G_{vv_g} \triangleq \frac{\hat{v}}{\hat{v_g}}$	$rac{D}{ riangle(s)}$	$rac{D(1+sr_cC)}{ riangle(s)}$	
$Z_{out} = G_{vi_o} \triangleq \frac{\hat{v}}{\hat{i_o}}$	$rac{sL}{ riangle(s)}$	$\frac{r_l \left(1 + \frac{sL}{R}\right) (1 + sr_c C)}{\triangle(s)}$	
$G_{id} \triangleq \frac{\hat{i}}{\hat{d}}$	$\frac{\frac{Vg}{R}}{\bigtriangleup(s)}$	$\frac{\frac{V_g}{R}(1{+}sRC)}{\triangle(s)}$	
$G_{iv_g} \triangleq \frac{\hat{i}}{\hat{v_g}}$	$\frac{\frac{D}{R}(1+sRC)}{\triangle(s)}$	$\frac{\frac{D}{R}(1+sRC)}{\triangle(s)}$	
$G_{ii_0} \triangleq \frac{\hat{i}}{\hat{i_0}}$	$rac{1}{ riangle(s)}$	$\frac{(1+sr_cC)}{\triangle(s)}$	

Figure 5.10: Summary of Plant Transfer Functions

## 5.3 Pulse-width Modulator

With a complete model in place for the Buck regulator, the next item in the system diagram to derive is the pulse-width modulator.

From inspection of Figure 5.11, it can be approximated that the duty cycle can be represented by the following relationship:

$$d(t) = \frac{V_c(t)}{V_M}$$
 for  $0 \le V_c(t) \le V_M$ 

Rearranging,  $\frac{d(t)}{V_c(t)} = \frac{1}{V_M}$ . For a complete derivation confirming the PWM conversion gain can be approximated to this equation, refer to the analysis presented in [1].



Figure 5.11: PWM Conversion Diagram

# 5.4 Summary

Now that the basic system has been defined, the final block to be derived in the Buck converter system model is the compensator,  $G_c(s)$ . The compensator will be the primary topic of the next several chapters, as it will be leveraged to improve the closed-loop performance of the derived buck regulator system. The equations in this chapter will be heavily leveraged in the remainder of the text.

80

# References

[1] R. Middlebrook, "Predicting modulator phase lag in pwm converter feedback loops," in *Powercon*, 1981.

REFERENCES

82

# Chapter 6

# Single Loop Voltage Mode Control

This chapter develops a buck converter design example using different compensation methods to ensure closed loop stability and to optimize system performance. Various compensators are designed using asymptotic Bode plots based primarily on loop bandwidth and stability margins. Computer simulation results are included to show time domain step response behavior and to verify performance improvements.

### 6.1 Introduction

The buck converter is a switch mode, DC-DC, power supply. It accepts a source voltage,  $V_g$  and produces a lower output voltage, V with high efficiency. An important component of a practical buck converter is control feedback which assures a constant output voltage and attenuates unwanted disturbances. The feedback loop of a buck converter presents several challenges which are explored in the compensation examples.

In this paper we present a series of example buck converter feedback compensation approaches. The design of the buck converter circuit is kept constant to allow comparison of the effects of different compensation schemes. The primary tool that will be applied to evaluate the different compensation approaches are asymptotic Bode plots which are drawn based on corner frequencies of each block in the regulator system. This methodology provides a quick and efficient assessment of circuit performance and an intuitive sense for the trade offs for each compensation approach. Bode plots also directly illuminate the two critical loop stability characteristics, gain and phase margin (GM and PM respectively).

Additional analysis of each compensation approach is undertaken through computer simulation. The PECS [1] circuit simulator is used to evaluate the effects of  $V_g$  transients, a common problem in real power supply designs. A Matlab [2] simulation is also performed to validate the manual Bode analysis and to determine the exact gain and phase margin. Finally a closed loop Matlab simulation is used to show the ability of the feedback system to attenuate undesired effects as a function of frequency.

### 6.2 Buck Converter System Models

#### 6.2.1 General Model

Figure 6.1 is a block diagram of the system components of a buck converter with feedback. The converter power stage accepts  $V_g$  as its power source and the control input d(s) to produce the output voltage V. The feedback sensor H(s), monitors the converter output voltage which is then compared with a reference voltage  $V_{ref}$ . The difference output of these two voltages is provided to the feedback compensation circuit  $G_c(s)$  and then to the pulse width modulator (PWM) which produces the control waveform for the switching converter d(s). The resulting loop gain is thus given by

$$T(s) = G_c(s) \left(\frac{1}{V_M}\right) G_{vd}(s) H(s)$$
(6.1)



Figure 6.1: Generalized Power System Model

#### 6.2.2 Simplified System Model

The general buck converter block diagram provides a complete model for analysis of converter. However, for our analysis we will use a simplified model show in Fig. 6.2 which includes only the elements required for the analysis we will provide. We do not evaluate any source of disturbance except  $V_q$  transients.



Figure 6.2: Simplified System Diagram

### 6.2.3 Design Targets

To facilitate easy comparison between the selected compensation schemes, the design of the buck converter is fixed with specified values. These values are specified in Table 6.1.

Table 0.1. Specified values			
Name	Value	Description	
$V_g$	28V	Input Voltage	
V	15V	Output Voltage	
Iload	5A	Load current	
L	$50 \mathrm{uH}$	Buck inductor value	
C	$500 \mathrm{uF}$	Buck capacitor value	
$V_m$	4V	PWM ramp amplitude	
H(s)	1/3	Sensor gain	
$f_s$	100kHz	PWM frequency	

 Table 6.1: Specified values

### 6.2.4 Buck Converter Model Analysis

Figure 6.3 shows a schematic model for the power converter block. The LCR is a second order circuit with a transfer function described by equation (6.2). It has a resonant frequency value,  $\omega_o = 6.28 \text{k} \text{ rad/s}$  or  $f_o(=\frac{\omega_o}{2\pi}) = 1.0 \text{ kHz}$  from (6.3) and a Q of 9.5 from (6.4). The low frequency gain of the converter is equal to  $V_g$  which is specified to be 28V.

$$G_{vd}(s) = V_g \frac{1}{1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_0}\right)^2}$$
(6.2)

$$\omega_o = \frac{1}{\sqrt{LC}} \tag{6.3}$$



Figure 6.3: Converter Power Stage

$$Q = R\sqrt{\frac{C}{L}} \tag{6.4}$$

Consider the transfer function  $v(s)/v_d(s)$  of the low pass filter formed by the LCR network. The switching frequency  $f_s = 100$ kHz is much higher than the resonant frequency  $f_0 = 1$ kHz of the LCR network. During circuit operation, the switch toggles the LCR input between  $V_g$  and ground with a duty cycle D determined by the feedback loop. A Fourier analysis of the LCR input waveform includes an average DC component  $V = DV_g$  and an  $f_s$  fundamental component and its harmonics as typified by a rectangular waveform. The LCR acts as a low pass filter with a cut off frequency equal to  $f_o$ . It passes the DC component to the output but attenuates  $f_s$  and its harmonics.

## 6.3 Uncompensated System

It is instructive to start our evaluation by examining the uncompensated loop gain, that is with a  $G_c(s) = 1$ . The loop gain is then given from (6.1) as

$$T(s) = \frac{T_o}{1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_o}\right)^2}$$
(6.5)

where

$$T_o = \frac{V_g H(0)}{V_m} \tag{6.6}$$

To construct a Bode plot we use the values from equations (6.2)-(6.4) to establish the shape of the Bode magnitude plot. The low frequency gain given by (6.6) has a value of 2.33. The magnitude around  $f_o$  peaks due to the resonant Q of 9.5. At frequencies above  $f_o$  the gain declines at -40dB/decade.

The Bode phase plot is determined only by  $G_{vd}(s)$ . It has a low frequency phase shift of 0°. At  $f_o 10^{-\frac{1}{2Q}}$  or 886Hz ( $\approx$  900Hz), the phase turns negative and at  $f_0$  the phase has reached  $-90^{\circ}$ . The phase continues to become more negative until it reaches  $-180^{\circ}$  at  $10^{\frac{1}{2Q}}$  or 1129Hz ( $\approx$  1.1kHz). At frequencies higher than 1.1kHz the phase remains at  $-180^{\circ}$ .



Figure 6.4: Uncompensated Gain and Phase Plot

From the Bode plot it can be determined that unity gain occurs at a frequency,  $f = f_c$  such that

$$T_o \left(\frac{f_o}{f_c}\right)^2 = 1 \tag{6.7}$$

which with  $T_o=2.33$  and  $f_o=1$ kHz, results in  $f_c=1.5$ kHz. At this frequency the phase is  $-180^{\circ}$  providing zero phase margin. The phase asymptotes show that phase does not cross the  $-180^{\circ}$  phase level (but is asymptotic to it) which implies that the gain margin is infinite. Figure 6.5 is a Matlab margin plot indicating the actual unity gain frequency to be 1.8 kHz with a phase margin of 4.7°. Also, the Matlab analysis indicates an infinite gain margin.

Figure 6.6 shows a PECS implementation of the open loop buck converter system. The input to the modulator is set to 2.1V which results in the target



Figure 6.5: Matlab Uncompensated Bode plot

steady state duty ratio of  $D = \frac{V}{V_g} = \frac{15}{28} = 0.54$  required to set the output voltage at V = 15V for a nominal input voltage of  $V_g = 28$ V.

Figure 6.7 shows the output voltage response of the open loop system shown in Figure 6.6 for voltage steps in  $V_g$  of  $28V \rightarrow 30V \rightarrow 28V$ . The response is indicative of the high resonance Q of 9.5 at the resonant frequency  $f_o=1$ kHz. Note also that at an input voltage of  $V_g=30$ V the output voltage settles at  $V = DV_g = 0.54 \times 30 = 16.2$ V, as shown in Fig. 6.7.



Figure 6.6: PECS Schematic of Open Loop System



Figure 6.7: PECS Simulation of Open Loop System

## 6.4 Dominant Pole Compensation

Dominant pole compensation is one of the simplest and most common forms of feedback compensation. The motivating idea behind this type of feedback control is to shape the loop gain of the system such that two objectives are achieved:

- 1. High gain is achieved at DC and low frequencies. This condition ensures low steady state error. In the case of an integrator where the pole appears at zero frequency, i.e. DC, the error is zero.
- 2. The gain at the plant's lowest frequency pole is less than or equal to 0dB. This condition ensures a positive phase margin and, consequently, stability.

For the case of dominant pole compensation, these objectives are achieved using a compensator consisting of a single pole at a frequency well below those of the plant's poles. For the purposes of this example, an integrator is employed

$$G_c(s) = \frac{\omega_I}{s} \tag{6.8}$$

where  $\omega_I (= 2\pi f_i)$  is an appropriately chosen design constant. Figure 6.8 shows the Bode plot asymptotes for the magnitude and phase of this compensator.



Figure 6.8: Bode Plot of Dominant Pole Compensator

Design of the compensator now consists of selecting an appropriate compensator parameter,  $f_I$ . Following the previously stated criteria, this is a matter of choosing the largest compensator gain such that the total gain at the lowest frequency plant pole(s) is less than 0dB. The loop gain of the system with this compensator is given by

$$T(s) = \frac{\omega_I T_o}{s \left[ 1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_0}\right)^2 \right]}$$
(6.9)

Figure 6.9 shows the graphical construction of the phase asymptotes for the loop gain with the compensator. Note that because the plant's dominant pole is second order, it contributes a phase shift of  $-180^{\circ}$  at high frequencies and a shift of exactly  $-90^{\circ}$  at  $f_o$ . Furthermore, the compensator contributes its own  $-90^{\circ}$  phase shift and does so for all frequencies. Consequently, the total phase shift of the compensated loop gain transfer function is  $-180^{\circ}$  at the dominant pole frequency,  $f_o$ . For this reason it is prudent to design in some additional gain margin. A value of 3dB is initially chosen for this analysis.



Figure 6.9: Graphical Construction of Phase Asymptotes for Dominant Pole Compensated Loop Gain

Figure 6.10 shows how the plant and compensator transfer functions combine to produce the gain of the compensated open loop. To achieve a loop gain that is -3dB at  $f_o$ , we require the magnitude at  $f_o$  to equal 0.7

$$\frac{f_I T_o Q}{f_o} = 0.7 \tag{6.10}$$

For  $T_o = 2.33$  and  $f_o = 1.0$ kHz, we find  $f_I = 32$ .



Figure 6.10: Graphical Construction of Gain Asymptotes for Dominant Pole Compensated Loop Gain

Figure 6.11 shows the Bode plot of the resulting gain and phase asymptotes and Figure 6.12 shows a Matlab margin analysis which confirms the design.

With a compensator designed and verified via Matlab, the next stage is to design a circuit that implements the compensator. Figure 6.13 shows the general



Figure 6.11: Dominant Pole Compensated Loop Gain Asymptotic Bode Plot

form of an operational amplifier in a integrator configuration. The transfer function for this circuit is given by:

$$G(s) = \frac{-1}{(s/\omega_o)} \tag{6.11}$$

where

$$\omega_o = \frac{1}{RC} \tag{6.12}$$

where  $\omega_o$  is the frequency at which the integrator gain is unity.

A capacitor value of 50nF is chosen for C. This value is within the range of low-cost, commercially available ceramic capacitors and is small enough to avoid any op-amp slew rate issues. Equating  $\omega_o$  with the compensator parameter,  $\omega_I$  (=  $2\pi f_I$ ) and solving for R gives

$$R = \frac{1}{\omega_I C} = \frac{1}{2\pi (32)(50\text{nF})} \approx 100\text{k}\Omega$$
 (6.13)



Figure 6.12: Matlab Analysis of Dominant Pole Compensator



Figure 6.13: Op-Amp Integrator Circuit

A PECS simulation is created to verify the time domain performance of the implementation. Figure 6.14 shows the complete PECS circuit model for the design.

Figure 6.15 shows the results of the PECS simulation for a 2V disturbance on the supply voltage,  $V_g$ . The input voltage steps are  $28V \rightarrow 30V \rightarrow 28V$ . The simulation exhibits several undesirable characteristics:

- 1. The regulator does a poor job of rejecting the input voltage disturbance. Nearly all of the input voltage excursion shows up as a transient on the output.
- 2. The regulator exhibits a substantial amount of ringing in response to the



Figure 6.14: PECS Schematic of Dominant Pole Compensated System

input disturbance. Closer examination of the ringing, as shown in Figure 6.16, reveals that the frequency of the oscillations is the same as the resonant frequency of the plant,  $f_o$ , and is not the result of defective control loop design.

It is clear from the simulation results that, although the design is stable and exhibits zero steady-state error, there is much room for improvement, particularly with respect to its transient response.

One additional experiment is performed using the dominant pole compensation scheme. The Q of the plant's dominant pole is reduced by placing a large capacitor in series with a small damping resistance. Figures 6.17 and 6.18 show the PECS circuit schematic and simulation results, respectively.

One can see clearly that the ringing of the previous design has been eliminated. Unfortunately, the poor rejection of input voltage transients remains.

Furthermore, this is probably not an ideal solution from a practical standpoint. The large value capacitor will be relatively expensive in terms of com-



Figure 6.15: PECS Simulation of Dominant Pole Compensated System



Figure 6.16: Pole of Dominant Pole Simulation Showing Oscillation at Resonant Frequency

ponent price and physical space. Alternate compensation schemes still offer the potential for better performance at lower cost.



Figure 6.17: PECS Schematic of Dominant Pole with Damping



Figure 6.18: PECS Simulation of Dominant Pole Compensated System with Added Output Filter Damping

### 6.5 Dominant Pole Compensation with Zero

The dominant pole compensator of the previous section, while stable and having zero steady state error, exhibits several undesirable characteristics including poor rejection of input supply voltage excursions and pronounced ringing in response to transients. One might assume that these issues are related to the minimal, 3dB, gain margin for which the compensator was designed. This section explores that line of reasoning by modifying the compensator of the previous section in order to substantially increase the gain margin.

The dominant pole compensator is modified by adding a zero at the resonant frequency of the plant and by reducing the gain to -10dB. Overall gain margin is improved in two ways:

- 1. by directly increasing the gain margin at the resonant frequency,  $f_o$ , from 3dB to 10dB.
- 2. by shifting the frequency at which the phase reaches  $-180^{\circ}$  beyond the resonant frequency and the gain peak due to the plant's Q.

The form of the modified compensator transfer function is:

$$G_c(s) = \omega_I \frac{1 + s/\omega_z}{s} \tag{6.14}$$

We will use  $\omega_z = \omega_o$  or  $f_z \left(=\frac{\omega_z}{2\pi}\right) = f_o$ . Which results in a loop gain of

$$T(s) = \omega_I \frac{1 + s/\omega_o}{s} \frac{T_o}{1 + \frac{s}{Q\omega_o} + \left(\frac{s}{\omega_o}\right)^2}$$
(6.15)

Figure 6.19 shows the resulting Bode plot asymptotes. We would like to set the gain at  $f_o$  to  $1/\sqrt{10}$  (which corresponds to -10dB). From the magnitude plot we see that we want

$$\frac{f_I T_o Q}{f_o} = \frac{1}{\sqrt{10}}$$
(6.16)

which given  $T_o = 2.33$ , Q = 9.5,  $f_o = 1kHz$ , results in  $f_I = 14.3$ . Figure 6.20 shows a Matlab confirmation of the Bode plot. Note that a gain margin of 11dB is predicted at a phase cross-over frequency of 1.06kHz, slightly higher than the plant's resonant frequency.

Figure 6.21 shows a standard op-amp implementation with the desired transfer function. The transfer characteristics of the circuit are given by:

$$G(s) = -A \frac{1 + s/\omega_1}{\frac{s}{\omega_1}}$$
(6.17)

where:



Figure 6.19: Open Loop System Gain and Phase with pole-zero Compensation (10dB GM)  $\,$ 

$$A = \frac{R_2}{R_1}$$
 and  $\omega_1 = \frac{1}{R_2 C_1}$  (6.18)

Equating  $f_1(=\frac{\omega_1}{2\pi})$  to the plant resonant frequency,  $f_o$  and  $\omega_I$  to  $A\omega_1$  provides two equations with three unknowns. Choosing, somewhat arbitrarily, a value of 100k for R1, leads to the following values.

$$R_2 = \frac{f_I R_1}{f_1} = \frac{(14.3)(100 \mathrm{k}\Omega)}{(1\mathrm{k}\Omega)} = 1.4\mathrm{k}\Omega \tag{6.19}$$

$$C_1 = \frac{1}{\omega_1 R_2} = \frac{1}{2\pi (1 \text{kHz})(1.4 \text{k}\Omega)} = 110 \text{nF}$$
(6.20)



Figure 6.20: Matlab Analysis of Dominant Pole Compensator with Zero



Figure 6.21: op-amp Integrator with Zero

Figure 6.22 shows a PECS circuit implementation of the system with the new compensator. Figure 6.23 shows the response of the system to a transient on the input voltage.

The modified compensator shows little improvement over the original circuit. It still fails to provide good rejection of input voltage transients and the previously observed ringing is still present.


Figure 6.22: PECS Schematic of Dominant Pole with Zero Compensation (10 dB GM)  $\,$ 



Figure 6.23: PECS Simulation of Dominant Pole with Zero Compensation (10 dB GM)  $\,$ 

### 6.6 Lead Compensation

A more sophisticated way to improve the performance of the buck converter is with a lead compensator. The transfer function of this compensator is

$$G_c(s) = G_{c_o} \frac{\left(1 + \frac{s}{\omega_z}\right)}{\left(1 + \frac{s}{\omega_p}\right)} , \qquad (6.21)$$

where  $\omega_z < \omega_p$ . As can be seen from the plot of the transfer function shown in Figure 6.24, the lead compensator provides both a phase boost that is adjustable based on the pole and zero frequencies, and a gain boost at higher frequencies that can result in a higher crossover frequency for a lead-compensated buck converter. Generally, a lead compensator is used to provide a phase boost, the level of which is chosen to improve the phase margin to a desired value. The new crossover frequency can be chosen arbitrarily. The design shown here will be to obtain a 45° phase margin and a crossover frequency of 5 kHz for the loop gain with a lead compensator.



Figure 6.24: Bode Plot of Lead Compensator



Figure 6.25: Bode Plot of Lead Compensated System

When the compensator is placed in the loop, the loop gain of the buck converter system becomes

$$T(s) = T_0 G_{c0} \frac{\left(1 + \frac{s}{\omega_z}\right)}{\left(1 + \frac{s}{\omega_p}\right) \left(1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_0}\right)^2\right)}$$
(6.22)

The asymptotic Bode plot of this loop gain is shown in Fig. 6.25. The expressions shown can be used to place the pole and zero frequencies of the compensator to obtain the desired phase margin and unity-gain crossover frequency. As can be seen, the phase margin of the lead compensated system is given by

$$\phi_M = 45^\circ \log\left(\frac{f_p}{f_z}\right)$$

For a desired phase margin of  $45^{\circ}$  we have

$$45^{\circ} = 45^{\circ} \log\left(\frac{f_p}{f_z}\right)$$

or

$$f_p = 10 f_z$$

Also, the crossover frequency,  $f_c$  will necessarily be the geometric mean of the pole and the zero frequency. Since the phase margin condition gives a relationship between the pole and zero frequencies, this can be used to solve for both.

$$f_c = \sqrt{f_z f_p}$$

$$5 \text{ kHz} = \sqrt{10 f_z^2}$$

$$f_z = \frac{5 \text{ kHz}}{\sqrt{10}}$$

$$f_z = 1.58 \text{ kHz and } f_p = 15.8 \text{ kHz}$$

These relationships result in the pole and zero frequencies for the lead compensator. To complete the design, the required low-frequency gain  $G_{c_o}$  of the compensator to place the unity-gain point at the appropriate frequency must be determined. This can be found by equating the values of the gain asymptotes at  $f_z$ .

$$T_0 G_{c0} \left(\frac{f_0}{f_z}\right)^2 = \frac{f_c}{f_z}$$

Substituting the values of  $f_o$  and  $T_o$  for the example converter, and the values of  $f_z$  and  $f_c$  as previously calculated, the gain  $G_{c_o}$  of the compensator is

$$G_{c_o} = \frac{1}{T_0} \left(\frac{f_z}{f_0}\right)^2 \frac{f_c}{f_z}$$
$$G_{c_o} = \frac{1}{2.33} \left(\frac{1.58 \text{ kHz}}{1 \text{ kHz}}\right)^2 \frac{5 \text{ kHz}}{1.58 \text{ kHz}}$$
$$G_{c_o} = 3.4$$

As seen in previous designs and now in the phase plot of Fig. 6.25, the phase response is asymptotic to  $-180^{\circ}$  at high frequencies and so does not cross through this level which implies an infinite gain margin.

104

In summary, we have designed a lead compensator which, using asymptotic Bode plot approximations, result in a  $45^{c}irc$  phase margin with a unity gain frequency of 5kHz and an infinite gain margin. The Matlab simulation in Figure 6.26 verifies the results, above.



Figure 6.26: Matlab Lead Compensator

With all of the parameters of the lead compensator determined, what remains is to implement the compensator using an op-amp circuit and simulate the closed-loop converter to evaluate its performance. A general circuit that can be used to implement any lead or lag compensator is shown in Fig. 6.27. The transfer function of this circuit is

$$G_c(s) = G_{c_o} \frac{1 + \frac{s}{\omega_z}}{1 + \frac{s}{\omega_p}}$$

$$(6.23)$$

where

$$G_{c_o} = -\frac{R_2}{R_1} \tag{6.24}$$

$$f_z = \frac{\omega_z}{2\pi} = \frac{1}{2\pi R_1 C_1} \tag{6.25}$$

$$f_p = \frac{\omega_p}{2\pi} = \frac{1}{2\pi R_2 C_2} \tag{6.26}$$

The resistor ratio sets the low frequency gain, and the two resistor-capacitor pairs set the pole and zero frequencies. Using standard resistor values of  $R_1 =$ 100 k $\Omega$  and  $R_2 = 330$  k $\Omega$  results in the required low frequency gain of close to  $G_{c_o} = 3.4$ . Using (6.23) we find

$$C_{1} = \frac{1}{2\pi (1.58 \text{ kHz}) (100 \text{ k}\Omega)} \Rightarrow C_{1} = 1.0 \text{ nF}$$
$$C_{2} = \frac{1}{2\pi (15.8 \text{ kHz}) (330 \text{ k}\Omega)} \Rightarrow C_{2} = 33 \text{ pF}$$

It it also necessary to derive a value for the reference voltage on the noninverting input of the op-amp. The sensed voltage from the output will be 5 V in steady-state as before, and the control voltage should be 2.14 V. Using these in combination with the resistor values for the lead compensator, the reference voltage can be found.

$$V_{ref} = \frac{R_2}{R_1 + R_2} V_{sense} + \frac{R_1}{R_1 + R_2} V_{control}$$

$$V_{ref} = \frac{330 \text{ k}\Omega}{100 \text{ k}\Omega + 330 \text{ k}\Omega} (5 \text{ V}) + \frac{100 \text{ k}\Omega}{100 \text{ k}\Omega + 330 \text{ k}\Omega} (2.14 \text{ V}) = 4.33 \text{ V}$$



Figure 6.27: op-amp circuit implementation of lead compensator

Using these values in the PECS simulator (see Figure 6.28 for PECS schematic), the response of the lead-compensated buck converter to a step in the input voltage was simulated as before. The results of the simulation are shown in Figure 6.29. The lead compensator is quite effective in increasing the phase margin of the system. The oscillatory behavior evident in the output voltage of the uncompensated converter is not present, and the magnitude of the steady-state error due to the step is reduced, though not eliminated. Thus, the system with the lead compensator is very stable, but will still exhibit steady-state errors to

106

a step disturbance. To fix this problem, the system type number must be increased by adding a pole at s = 0, as was seen previously. This is the approach taken in the design of the subsequent compensators.



Figure 6.28: PECS Schematic of Lead System

## 6.7 Dominant Pole with Lead Compensation

So far we have seen that with a dominant pole integral compensation a zero steady state error can be achieved at the expense of limited bandwidth with resulting large overshoot in the step response. In contrast lead compensation is able to extend bandwidth thus reducing step response overshoot. However, due to severely curtailed low frequency loop gain, a non-zero steady state error is seen.

In this section a compensator which is a composite of the two previous compensators is examined. The exact form of the compensator is:

$$G_c(s) = \frac{\omega_I \left(1 + \frac{s}{\omega_1}\right) \left(1 + \frac{s}{\omega_z}\right)}{s \left(1 + \frac{s}{\omega_p}\right)} \tag{6.27}$$



Figure 6.29: PECS Simulation of Lead System

Effectively, to the lead compensator design of the previous section we are adding an integrator pole, i.e. a pole at zero frequency, and a zero at  $f_1(=\frac{\omega_1}{2\pi})$ . In the following we will consider two different values for the zero frequency  $f_1$ .

In the first case  $f_1$  will be chosen to be the largest frequency which, based on the phase asymptote, contributes  $+90^{\circ}$  to the crossover frequency  $f_c$ , thus fully canceling the  $-90^{\circ}$  contribution from the integrator pole. This effectively leaves the phase margin unchanged from the lead compensator design of the previous section. From the phase asymptotes plots of a zero, we see that the zero frequency  $f_1$  should be at  $\frac{f_c}{10}$  which is 500Hz.

In the second design considered here we will lower the zero frequency to  $f_1 = 150$ Hz and examine the effect on the closed loop performance.

In either case the expression for the loop gain is

$$T(s) = T_o \frac{\omega_I \left(1 + \frac{s}{\omega_1}\right) \left(1 + \frac{s}{\omega_z}\right)}{s \left(1 + \frac{s}{\omega_p}\right) \left[1 + \frac{s}{Q\omega_o} + \left(\frac{s}{\omega_o}\right)^2\right]}$$
(6.28)

where  $f_1$  is either 500Hz or 150Hz, as discussed above and  $f_I \left(=\frac{\omega_I}{2\pi}\right)$  is the only design variable to be determined.

#### 6.7.1 Design 1: Zero $f_1 = 500$ Hz

As before, asymptotic plots for the loop gain are drawn. As the construction of the phase plot is more involved than that of the magnitude plot, its construction is shown separately in Fig. 6.30. In Fig. 6.30, the top plot is that of the previous lead compensation design, as seen in Fig. 6.25. The plot of the phase of the component  $\frac{1}{s}\left(1+\frac{s}{\omega_1}\right)$  is shown in the center plot where  $f_1 = 500$ Hz. The final phase plot for the new loop gain is shown in the bottom plot. Both magnitude and phase plots for the new loop gain are shown together in Fig. 6.31.

To determine,  $f_I$ , the one unknown variable in the loop gain, we note that at the frequency  $f_1$  the magnitude is set equal to the low frequency loop gain of the lead compensation design of the last section.

$$T_0 \frac{f_I}{f_1} = T_0 \ G_{c_o}|_{lead} \tag{6.29}$$

For  $f_1 = 500$  we find  $f_I = 1770$ . Thus the expression for the compensator is as given in (6.27) with the following values

$$\begin{aligned}
\omega_I &= 2\pi (1770) \\
\omega_1 &= 2\pi (800) \\
\omega_z &= 2\pi (1580) \\
\omega_p &= 2\pi (15800)
\end{aligned}$$
(6.30)

To confirm the accuracy of the design, the Bode plot of the exact loop gain was evaluated using Matlab. This is shown in Fig. 6.32. Our asymptotic design values of crossover frequency  $f_c$  and phase margin of 5kHz and 45°, respectively were determined by Matlab as given by the Matlab "margin" command to be more precisely 5,370Hz and 50.5°, respectively, thus confirming the design procedure.

A compensator which realizes the transfer function is shown in Fig. 6.33 where we find

$$\omega_{I} = \frac{1}{R_{1}(C_{2} + C_{3})}$$

$$\omega_{1} = \frac{1}{R_{2}C_{2}}$$

$$\omega_{z} = \frac{1}{R_{1}C_{1}}$$

$$\omega_{p} = \frac{1}{R_{2}\frac{C_{2}C_{3}}{C_{2} + C_{3}}}$$
(6.31)



Figure 6.30: Bode Plot of Lead Compensator (500 Hz)

Setting  $R_1 = 100$ K and using the approximation  $C_3 \ll C_2$  we find the component values:



Figure 6.31: Bode Plot of System with Lead plus Integral Compensation (500Hz)

$$C_{1} = \frac{1}{\omega_{z}R_{1}} = 2.2 \text{nF}$$

$$C_{2} = \frac{1}{\omega_{I}R_{1}} = 1 \text{nF}$$

$$R_{2} = \frac{1}{\omega_{1}C_{2}} = 330 \text{k}\Omega$$

$$C_{3} = \frac{1}{\omega_{n}R_{2}} = 33 \text{pF}$$
(6.32)

A PECS implementation of the closed loop system is shown in Fig. 6.34. The simulated response of input voltage steps  $26V \rightarrow 30V \rightarrow 28V$  is shown in Fig. 6.35. Clearly seen here is the zero steady state error and a maximum voltage



Figure 6.32: Matlab Lead Compensator with Integrator and Zero at 500Hz



Figure 6.33: Compensator Circuit for Dominant Pole with Lead Compensation

deviation of around 80 mV with a settling time of around 1 ms.

# 6.7.2 Design 2: Zero $f_1 = 150$ Hz

The above design procedure will now be repeated for the case of the zero  $f_1 = 150$  Hz. The resulting asymptotic phase plot construction is shown in Fig. 6.36. The final magnitude and phase asymptotic plots are given in Fig. 6.37. The new  $f_I$  is now found to be from (6.33)



Figure 6.34: PECS Schematic of Lead Compensated System with Zero at 500Hz



Figure 6.35: PECS Simulation of Lead Compensated System with Zero at 500Hz



Figure 6.36: Bode Plot of Lead Compensator (150Hz)

$$f_I = f_1 T_o = 150 \times 3.4 = 351 \tag{6.33}$$

Using the new values of  $f_I = 351$  and  $f_1 = 150$ , a more precise value of crossover frequency and phase margin is found from Matlab to be 5,350Hz and 54.3°, respectively, as seen in Fig. 6.38. Recall that the asymptotic plots indicate 5kHz and 45°, respectively.



Figure 6.37: Bode Plot of System with Lead plus Integral Compensation (150Hz)

The change of  $f_1 = 150$ Hz to  $f_1 = 150$ Hz results in only a change in one capacitor value in the compensator. The resulting PECS implementation is shown in Fig. 6.39 along with the response of input voltage steps of  $28V \rightarrow 30V \rightarrow 28V$ , in Fig. 6.40. We now see that the peak voltage variation has slightly increased to 90 mV but the settling time has tripled to around 3ms.

# 6.8 Extended Bandwidth Design

In the following we examine the performance of a compensator (closely related to the previous two) which is designed to produce an extended loop bandwidth. To this end a unity gain crossover frequency  $f_c = 40$ kHz is, somewhat arbitrarily,



Figure 6.38: Matlab Lead Compensator with Integrator and Zero at 150Hz

chosen. The compensator used is

$$G_c(s) = \frac{\omega_I \left(1 + \frac{s}{\omega_{z_1}}\right) \left(1 + \frac{s}{\omega_{z_2}}\right)}{s}$$
(6.34)

The zeros  $f_{z_1}(=\frac{\omega_{z_1}}{2\pi}$  and  $f_{z_2}=\frac{\omega_{z_2}}{2\pi}$  are simply chosen as follows. Zero  $f_{z_2}$  is set so  $f_{z_2} = f_o$  so as to counter the effects of the plant complex pole pair. The lower frequency zero  $f_{z_1}$  is set so that  $f_{z_1}=\frac{f_o}{10}$  to minimize the phase drop at  $f_o$ . The resulting loop gain expression is given by

$$T(s) = \omega_I T_o \frac{\left(1 + \frac{s}{\omega_{z_1}}\right)\left(1 + \frac{s}{\omega_{z_2}}\right)}{s\left[1 + \frac{s}{Q\omega_o} + \left(\frac{s}{\omega_o}\right)^2\right]}$$
(6.35)

The asymptotic magnitude and phase responses of the resulting loop gain are shown in Fig. 6.41, where the phase contributions of the different factors are individually drawn and then summed at the bottom plot to produce the overall asymptotic loop gain phase plot.

To determine the quantity  $\omega_I (= 2\pi f_I)$  in (6.34) the high frequency asymptotes of the magnitude plot is used. At the crossover frequency  $f_c$  we have



Figure 6.39: PECS Schematic of Lead Compensated System with Zero at 150Hz



Figure 6.40: PECS Simulation of Lead Compensated System with Zero at 150Hz



Figure 6.41: Extended Bandwidth Bode Plot and Phase Construction

$$\frac{T_o f_I}{f_{z_1}} \frac{f_o}{f_c} = 1 \tag{6.36}$$

so that we have

$$f_I = \frac{f_{z_1} f_c}{T_o f_o} \tag{6.37}$$

with the values at hand we find

$$f_I = 172$$
 (6.38)

From the phase asymptotic plot of Fig. 6.41 we can clearly see that the expected phase margin is 90°. Using Matlab we more precisely find with the design values used  $f_c = 40$ kHz and phase margin is 88.6° as shown in Fig. 6.42.



Figure 6.42: Matlab Analysis of Extended Compensator

The resulting PECS implementation is shown in Fig. 6.43 along with the response of input voltage steps of  $28V \rightarrow 30V \rightarrow 28V$ , in Fig. 6.44. We now see that the peak voltage variation has greatly reduced to just 30mV.



Figure 6.43: PECS Schematic of Extended System



Figure 6.44: PECS Simulation of Extended System

# 6.9 Conclusion

The following table shows the summary of all of the results.

Table 6.2: Summary of Compensators Loop Gain  $T(s) = G_c(s) \frac{T_o}{1 + \frac{s}{Q\omega_o} + \left(\frac{s}{\omega_o}\right)^2},$ 

Compensator	Compensator	φ <sub>M</sub>	f.	$\Delta w$
Dosign	Transfor Function	$\varphi_M$	<i>Jc</i> Asymptoto	(mV)
Design	C(a)	(Matlah)	(Matlah)	
	$G_c(s)$	(Matiab)	(Matiab)	
		(degrees)	(KHZ)	
Uncompensated	$G_{c_{\alpha}}$	0	1.5	2,800
Open Loop	$G_{c_o} = 1$	(5)	(1.82)	
Dominant Pole	$\frac{\omega_I}{\alpha}$	90	0.0744	3,700
(3dB gain	$\omega_T = 2\pi(32)$	(90)	(0.0746)	
margin)	$\omega_I = 2\pi (02)$		· · · ·	
	$\omega_I(1+\frac{s}{\omega_I})$			
Dominant Pole		90	0.0333	3,700
+ Zero (10db	$\omega_I = 2\pi (14.3)$	(92)	(0.033)	
gain margin)	$\omega_1 = 2\pi (1,000)$			
	$C^{1+\frac{s}{\omega_{\tau}}}$		<b>.</b>	1.0.0
Lead	$G_{c_o} \frac{s}{1+\frac{s}{2}}$	45	5.0	120
	$\omega_p$	(56)	(5.35)	
	$G_{c_0} = 3.4$			
	$\omega_z = 2\pi(1, 580)$			
	$\omega_p = 2\pi (15, 800)$			
Load	$\frac{\omega_I(1+\frac{\omega_I}{\omega_1})(1+\frac{\omega_Z}{\omega_z})}{\omega_I(1+\frac{\omega_Z}{\omega_z})}$	45	5.0	80
Integrator	$s(1+\frac{s}{\omega_n})$	(51)	(5.27)	00
$7_{\text{ore of } 500\text{Hz}}$	$\omega_I = 2\pi (1,770)$	(31)	(0.01)	
Zero at 500mz	$\omega_1 = 2\pi(500)$			
	$\omega_{z} = 2\pi(1, 580)$			
	$\omega_n = 2\pi(15, 800)$			
	$\omega_I(1+\frac{s}{\omega_I})(1+\frac{s}{\omega_I})$			
Lead +	$\frac{\omega_1 - \omega_2}{s(1+\frac{s}{2})}$	45	5.0	90
Integrator +	$(1 + \omega_p)$	(54)	(5.35)	
Zero at 150Hz	$\omega_I = 2\pi(351)$			
	$\omega_1 = 2\pi(150)$			
	$\omega_z = 2\pi(1, 580)$			
	$\omega_p = 2\pi (15, 800)$			
	$\omega_I(1+\frac{s}{\omega_{z_1}})(1+\frac{s}{\omega_{z_2}})$		10	90
Extended	<u> </u>	90	40	30
Bandwidth	$\omega_I = 2\pi(172)$	(89)	(40)	
	$\omega_{z_1} = 2\pi(100)$			
	$\omega_{z_2} = 2\pi (1000)$			

where  $T_o = 2.33, Q = 9.5, \text{ and } \omega_o = 2\pi (1kHz)$ 

# References

- R. W. Erickson and D. Maksimović, Fundamentals of Power Electronics, 2nd ed. New York, NY: Springer Science+Business Media, LLC, 2001.
- [2] R. Tymerski, "PECS Simulator ©1999-2009," Portland, OR.
- [3] MATLAB, R2012b. Natick, MA: The Mathworks, Inc., 2012.

# Appendix

# 6.9.1 Compensator Circuits

	Control Action	$G(s) = \frac{E_o(s)}{E_i(s)}$	Operational Amplifier Circuits	
1	P Proportional	-A where: $A = \frac{R_2}{R_1}$	$R_1$	
2	I Integral	$-\frac{1}{s/\omega_0}$ where: $\omega_0 = \frac{1}{R_1C_1}$	$\begin{array}{c} C_1 \\ \hline \\ e_i \\ \hline \\ e_a \\ \hline \hline e_a \\ \hline e_a \\ \hline \hline e_a \\ \hline \hline e_a \\ \hline$	
3	PD Proportional-Derivative	$-A(1+\frac{s}{\omega_1})$ where: $A=\frac{R_2}{R_1},  \omega_1=\frac{1}{R_1C_1}$	$\begin{array}{c c} C_1 & R_2 \\ \hline \\ e_i & R_1 \\ \hline \\ e_i & e_o \end{array}$	
4	PI Proportional-Integral	$-A\frac{1+\frac{s}{\omega_1}}{\frac{s}{\omega_1}}$ where: $A = \frac{R_2}{R_1},  \omega_1 = \frac{1}{R_2C_1}$	$R_2$ $C_1$ $R_1$ $R_2$ $C_1$ $e_i$ $e_o$	
5	PID Proportional -Integral- Derivative	$-A\frac{(1+\frac{s}{\omega_1})(1+\frac{s}{\omega_2})}{\frac{s}{\omega_2}}$ where: $A = \frac{R_2}{R_1},  \omega_1 = \frac{1}{R_1C_1},  \omega_2 = \frac{1}{R_2C_2}$	$\begin{array}{c c} C_1 & R_2 & C_2 \\ \hline \\ e_i & R_1 & \hline \\ e_i & e_o \\ \hline \end{array}$	
6	Lead if $\omega_1 < \omega_2$ or Lag if $\omega_1 > \omega_2$	$-A\frac{1+\frac{s}{\omega_1}}{1+\frac{s}{\omega_2}}$ where: $A = \frac{R_2}{R_1},  \omega_1 = \frac{1}{R_1C_1},  \omega_2 = \frac{1}{R_2C_2}$	$\begin{array}{c} C_{2} \\ \hline \\ C_{1} \\ \hline \\ R_{2} \\ e_{i} \\ e_{i} \\ e_{i} \end{array}$	

#### REFERENCES

	Control Action	$G(s) = \frac{E_o(s)}{E_i(s)}$	Operational Amplifier Circuits
7	Lead-Lag	$-A \frac{(1+\frac{s}{\omega_1})(1+\frac{s}{\omega_2})}{(1+\frac{s}{\omega_3})(1+\frac{s}{\omega_4})}$ where: $A = \frac{R_4}{R_3},$ $\omega_1 = \frac{1}{(R_1+R_3)C_1},  \omega_2 = \frac{1}{R_2C_2}$ $\omega_3 = \frac{1}{R_1C_1},  \omega_4 = \frac{1}{(R_2+R_4)C_2}$	$\begin{array}{c c} & C_2 & R_2 \\ \hline & & \\ & \\ & \\ & \\ & \\ & \\ & \\ & \\ &$
8	Integrator with Lead or Lag	where: $\begin{aligned} -\frac{\omega_0}{s} \frac{(1+\frac{s}{\omega_1})}{(1+\frac{s}{\omega_2})} \\ \omega_0 &= \frac{1}{R_1(C_1+C_2)} \\ \omega_1 &= \frac{1}{R_2C_2} \\ \omega_2 &= \frac{1}{R_2} \frac{C_1C_2}{C_1+C_2} \end{aligned}$	$\begin{array}{c} R_2 & C_2 \\ \hline \\ R_1 & \hline \\ e_i & \hline \\ e_i$
9	Integrator with Lead	where: $ \begin{array}{r} -\frac{\omega_0}{s} \frac{(1+\frac{s}{\omega_1})(1+\frac{s}{\omega_2})}{(1+\frac{s}{\omega_3})} \\ \omega_0 = \frac{1}{R_1(C_2+C_3)} \\ \omega_1 = \frac{1}{R_2C_2},  \omega_2 = \frac{1}{R_1C_1} \\ \omega_3 = \frac{1}{R_2} \frac{C_2C_3}{C_2+C_3} \end{array} $	$\begin{array}{c} R_2 & C_2 \\ C_1 & & \\ \hline \\ e_i & \\ e_i & \\ \hline \\ e$
10	Integrator with Lead-Lag	$\begin{aligned} & -\frac{\omega_0}{s} \frac{(1+\frac{s}{\omega_1})(1+\frac{s}{\omega_2})}{(1+\frac{s}{\omega_3})(1+\frac{s}{\omega_4})} \\ \text{where:} & \omega_0 = \frac{1}{R_1(C_2+C_3)} \\ & \omega_1 = \frac{1}{R_2C_2},  \omega_2 = \frac{1}{C_1(R_1+R_3)}, \\ & \omega_3 = \frac{1}{R_3C_1},  \omega_4 = \frac{1}{R_2} \frac{C_2C_3}{C_2+C_3} \end{aligned}$	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$

# 6.10 MATLAB Code

```
1 clear all
2 close all
3
4 f0 = 1000;
5 Q = 9.5;
6 TO = 2.33;
7 w0 = 2*pi*f0;
8
9 s = tf('s');
10 Ts = TO/((s/w0)^2 + s/(Q*w0) + 1);
11
13 % Open loop
14
15 figure(1)
16 margin(Ts)
h = gcr;
18 h.AxesGrid.Xunits = 'Hz';
19 h.AxesGrid.TitleStyle.FontSize = 16;
20 h.AxesGrid.XLabelStyle.FontSize = 12;
21 h.AxesGrid.YLabelStyle.FontSize = 12;
^{22}
24 % Lead compensation
25
Gc0 = 3.4;
27 wz = 2*pi*1500;
28 wp = 2*pi*15000;
29
30 Gcl = Gc0 * (1+s/wz) / (1+s/wp);
31
32 Ts1 = Gc1*Ts;
33
34 figure(2)
35 margin(Tsl)
36 h = gcr;
37 h.AxesGrid.Xunits = 'Hz';
38 h.AxesGrid.TitleStyle.FontSize = 16;
39 h.AxesGrid.XLabelStyle.FontSize = 12;
40 h.AxesGrid.YLabelStyle.FontSize = 12;
41
42
44 % 500
45
46 wi = Gc0*2*pi*500;
47 wz2 = 2*pi*500;
48 wz = 2*pi*1500;
49 wp = 2*pi*15000;
50
51 Gc2 = wi/s*(1+s/wz2)*(1+s/wz)/(1+s/wp);
52 Ts2 = Gc2*Ts;
53
```

```
54 figure(3)
55 margin(Ts2)
56 h = gcr;
57 h.AxesGrid.Xunits = 'Hz';
58 h.AxesGrid.TitleStyle.FontSize = 16;
59 h.AxesGrid.XLabelStyle.FontSize = 12;
60 h.AxesGrid.YLabelStyle.FontSize = 12;
61
62
64 % 150
65
66 wi = Gc0*2*pi*150;
67 wz2 = 2*pi*150;
68 wz = 2*pi*1500;
69 wp = 2*pi*15000;
70
71 Gc3 =wi/s*(1+s/wz2)*(1+s/wz)/(1+s/wp);
72 Ts3 = Gc3*Ts;
73
74 figure(4)
75 margin(Ts3)
76 h = gcr;
77 h.AxesGrid.Xunits = 'Hz';
78 h.AxesGrid.TitleStyle.FontSize = 16;
r9 h.AxesGrid.XLabelStyle.FontSize = 12;
80 h.AxesGrid.YLabelStyle.FontSize = 12;
81
82
84 % Extended bandwidth
^{85}
86 %wi = Gc0*2*pi*100;
87 wi = 2*pi*100*40000/(T0*1000); % fc = 40000
88 wz1 = 2*pi*100;
89 wz2 = 2*pi*1000;
90
91 Gc4 = wi/s*(1+s/wz2)*(1+s/wz1);
92 Ts4 = Gc4*Ts;
93
94 figure(5)
95 margin(Ts4)
96 h = gcr;
97 h.AxesGrid.Xunits = 'Hz';
98 h.AxesGrid.TitleStyle.FontSize = 16;
99 h.AxesGrid.XLabelStyle.FontSize = 12;
100 h.AxesGrid.YLabelStyle.FontSize = 12;
101
103 % Dominant pole
104
105 Gcd0 = 200;
106
107 Gc5 = Gcd0/s;
108
109 Ts5 = Gc5*Ts;
110
```

```
111 figure(6)
112 margin(Ts5)
113 h = gcr;
114 h.AxesGrid.Xunits = 'Hz';
115 h.AxesGrid.TitleStyle.FontSize = 16;
116 h.AxesGrid.XLabelStyle.FontSize = 12;
117 h.AxesGrid.YLabelStyle.FontSize = 12;
118
119 응응응응응응응응응응응응응응응응
120 % Dominant pole with zero
121
122 Gcdz0 = 1/sqrt(10) *w0/(T0*Q); % 89.76
123 wz = 2*pi*1000;
124
125 Gc6 = Gcdz0*(1+s/wz)/s;
126
127 Ts6 = Gc6*Ts;
128
129 figure(7)
130 margin(Ts6)
131 h = gcr;
132 h.AxesGrid.Xunits = 'Hz';
133 h.AxesGrid.TitleStyle.FontSize = 16;
134 h.AxesGrid.XLabelStyle.FontSize = 12;
135 h.AxesGrid.YLabelStyle.FontSize = 12;
```

128

Chapter 7

# Droop and Multi-Loop Control

()

### Abstract

Constant output voltage is an important feature of a DC voltage regulator. This paper describes three compensation techniques including voltage droop, inductor current droop, and voltage compensation to minimize voltage deviation to changes in the output load of the system. Through simulation it is confirmed that droop compensation improves voltage deviation by a factor of two in comparison to traditional voltage compensation.

#### 7.1 Introduction

In DC-DC voltage regulators, it is important to supply a constant voltage, regardless of the current load on the output. The goal of this paper is to describe three feedback compensation techniques for the Buck converter to limit the voltage deviation in response to a current step on the output. The designs to be implemented include a voltage droop compensator [1], an inductor current compensator [2], and a conventional voltage compensation circuit. For this design, resistive losses will be included for the inductor and the capacitor to provide a more complete and accurate analysis.

# 7.2 Design

#### 7.2.1 Passive Droop Compensation

#### Concept of droop control

As discussed in [1], the basic concept behind droop control is to apply compensation to the Buck converter in a way that creates a constant, closed-loop output impedance. By creating a constant output impedance, any variation in load current will result in a change in output voltage to maintain a constant impedance. Knowing the maximum load current requirements, the maximum droop of the system is simply  $\Delta V = \Delta I R$ .

Reviewing the output section of the buck converter including losses, it can be seen that the open loop output impedance at high frequencies is equal to the parasitic resistance of the output capacitor. For this design, the parasitic resistance of the capacitor will be utilized as the value of the output impedance for the compensated Buck converter.

#### Derivation of the closed-loop output impedance

As shown in Figure 7.4, the output voltage variation of a Buck converter is determined based on the variation of the duty cycle, variations in the source



Figure 7.1: Transient Response of System with Droop Control



Figure 7.2: Active Droop Control System Block Diagram

voltage, and variations in the load current. For this example, input voltage variations will be neglected.

By definition,

$$Z_{oc}(s) = \frac{Z_o(s)}{1 + T(s)}$$
(7.1)

Following Figure 7.4,  $T(s) = F_m H G_{vd}(s) G_{con}(s)$ , where  $F_m$  is the PWM comparator effect,  $G_{vd}(s)$  is the control to output transfer function, H is the feedback attentuation, and  $G_{con}(s)$  is the compensation block to be designed.



Figure 7.3: MATLAB Uncompensated Bode plot



Figure 7.4: Buck converter control loop

To find  $Z_{oc}(s)$  it is necessary to first calculate  $Z_o(s)$  (the open loop output impedance) and  $G_{vd}(s)$ . Applying state space averaging methods to calculate the small signal model of  $Z_o(s)$  and  $G_{vd}(s)$ , the functions are realized as shown below.

7.2. DESIGN

$$Z_{o}(s) = r_{l} \frac{(1 + \frac{s}{\omega_{c}})(1 + \frac{s}{\omega_{l}})}{1 + \frac{s}{Q\omega_{0}} + \left(\frac{s}{\omega_{0}}\right)^{2}}$$
(7.2)

$$G_{vd}(s) = V_g \frac{1 + \frac{s}{\omega_c}}{1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_0}\right)^2}$$
(7.3)

Where  $\omega_o \approx \frac{1}{\sqrt{CL}}$ ,  $\omega_c = \frac{1}{r_c C}$ ,  $\omega_l = \frac{r_l}{L}$ ,  $\omega_R = \frac{1}{RC}$ , and  $Q \approx \frac{\sqrt{LC}}{r_l + r_c}$ .

Recalling that our aim is to derive a compensator circuit that will implement a constant output impedance equal to the parasitic resistance of the capacitor,  $Z_{oc}$  is set equal to  $r_c$ .

$$Z_{oc}(s) = \frac{Z_o(s)}{1 + T(s)} = \frac{Z_o(s)}{1 + F_m G_{vd}(s) G_{con}(s)} = r_c$$

Expanding  $Z_o(s)$  and  $G_{vd}(s)$ :

$$r_{c} = \frac{r_{l} \frac{(1+\frac{s}{\omega_{l}})(1+\frac{s}{\omega_{c}})}{1+\frac{s}{Q_{\omega_{c}}}+\frac{s^{2}}{\omega_{c}^{2}}}}{1+\frac{F_{m}(1+\frac{s}{\omega_{c}})V_{g}}{1+\frac{s}{Q_{\omega_{c}}}+\frac{s^{2}}{\omega_{c}^{2}}}G_{con}(s)}$$

Rearranging the equation,

$$r_{c}F_{m}V_{g}(1+\frac{s}{\omega_{c}})G_{con}(s) = r_{l} - r_{c} + \left[\left(\frac{1}{\omega_{l}} + \frac{1}{\omega_{c}}\right)r_{l} - \frac{r_{c}}{Q\omega_{o}}\right]s + \left(\frac{r_{l}}{\omega_{l}\omega_{c}} - \frac{r_{l}}{\omega_{o}^{2}}\right)s^{2}$$

Expanding the  $s^2$  term,

$$\frac{r_l}{\omega_l \omega_c} - \frac{r_c}{\omega_o^2} = \frac{r_l}{\frac{r_l}{L} \frac{1}{r_c C}} - \frac{r_c}{\frac{1}{LC}} = r_c(LC - LC) = 0$$

 $G_{con}(s)$  can then be simplified into the form:

$$G_{con}(s) = K_v \frac{1 + \frac{s}{\omega_{zv}}}{1 + \frac{s}{\omega_{pv}}}$$

$$\tag{7.4}$$

Where  $K_v = \frac{r_l - r_c}{r_c V_g F_m H}, \omega_{pv} = \omega_c$ , and  $\omega_{zv} = \frac{R_l - R_c}{L - R_c^2 C}$ .

Using the circuit parameters defined in the introduction,  $K_v = .1.71$ ,  $\omega_{zv} = 4.1k \frac{\text{rad}}{s}$ , and  $\omega_{pv} = 40k \frac{\text{rad}}{s}$ . For a Matlab calculation of these values, please refer to the MATLAB code provided at the end of the chapter.

Figure 7.5 show the frequency response of the loop gain of the system. Note that in this compensation design, a small gain at low frequencies is implemented, which is contrary to typical feedback designs where nearly infinite DC gain is desired.

133

In Figures 7.6 and 7.7, the open and closed loop output impedance and the system audio susceptibility are shown as a function of frequency. Note that as expected, the closed loop output impedance is approximately a constant -26dB or  $50m\Omega$  over the frequency range.

With the compensator circuit now completely defined, it can be realized using an operational amplifier circuit. As seen in Figure 7.8, the circuit can be implemented using a single op-amp.

Since the loop gain of this system is very low, it is not safe to assume that a reference of 5 V ( $V_oH$ ) will work for this system. Looking at the block diagram, if the duty ratio is known, the output voltage of the amplifier is  $\frac{D}{F_m}$ . Using this value, the value of  $V_{ref}$  can found by applying nodal analysis at  $V_{-}$ . Using the DC value of D ( $\frac{V}{V_g} = .53$ ),  $V_{ref}$  is found to be equal to approximately 3.9 V.

Through simulation of the droop circuit (Figure 7.8), it is found that the system performs exactly as expected for a step in current of 0.1 A to 5.0 A. With an output impedance of  $50m\Omega$ , the voltage change ideally would be equal to  $\Delta V = (4.9A)(50m\Omega) = .245V$ , which is approximately what is seen in Figure 7.8. In the next section, we will expand upon this design to incorporate additional compensation using the inductor current.



Figure 7.5: MATLAB Bode Plot of Loop Gain with Passive Droop Compensation



Figure 7.6: MATLAB Bode Plot of  $Z_o$  for Passive Droop Compensated System



Figure 7.7: MATLAB Bode Plot of  ${\cal G}_{vg}$  for Passive Droop Compensated System



Figure 7.8: PECS Schematic of System with Passive Droop Compensation



Figure 7.9: PECS Simulation of Passive Droop Compensation Response to a Load Current Step


Figure 7.10: PECS Simulation of Passive Droop Compensation Response to a Supply Voltage Disturbance

### 7.2.2 Active Droop Compensation

#### **Concept of Current Sensing Droop Control**

This mode of control implements a constant output impedance equal to the parasitic resistance of the capacitor, similar to that of the previous section. However, this feedback system is composed of two loops. One loop is the voltage loop that was used in the Section 1 design. The second loop is a current sensing loop, which measures the inductor current and provides a feedback voltage proportional to this current. The goal of this design as presented in [2] is to combine these two loops into one compensator to control the deviation in the output voltage. This can be seen in Figure 7.11.

Figure 7.12 shows the current and voltage loops in terms of transfer functions via small-signal block diagram.  $Z_o(s)$ ,  $G_{vd}(s)$ , and  $F_m$  are the same transfer functions used in the voltage droop mode.  $R_i$  is the inductor current sensing gain.  $A_v(s)$  is the transfer function of the feedback compensator, and is synomynous to  $G_{con}(s)$  in the voltage droop mode.  $G_{ii}(s)$  is the transfer function of inductor current to load current.  $G_{id}(s)$  is the transfer function of inductor current to duty cycle. Applying state space averaging methods to calculate the small signal model of  $G_{ii}(s)$  and  $G_{id}(s)$  (see Appendix 1), the functions are realized as shown below.

$$G_{ii}(s) = \frac{1 + \frac{s}{\omega_c}}{1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_0}\right)^2}$$
(7.5)



Figure 7.11: Buck converter with the current sensing mode [2]

$$G_{id}(s) = \frac{V_{in}}{R_o} \frac{1 + \frac{s}{\omega_R}}{1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_0}\right)^2}$$
(7.6)

where  $\omega_o \approx \frac{1}{\sqrt{CL}}$ ,  $\omega_c = \frac{1}{R_c C}$ ,  $\omega_l = \frac{R_l}{L}$ ,  $\omega_R = \frac{1}{RC}$ , and  $Q \approx \frac{\sqrt{LC}}{R_l + R_c}$ .

#### **Design of Current Sensing Droop Control**

To create a feedback compensator  $A_v(s)$  for the current sensing droop control, the first step is realizing the functions for the current loop  $T_i(s)$  and the voltage loop  $T_v(s)$ . This can be achieved by following each loop in Figure 7.12. For a complete diagram including input voltage disturbances, refer to Figure 7.20.

$$T_i(s) = A_v(s)F_m G_{id}(s)R_i \tag{7.7}$$

$$T_v(s) = A_v(s)F_m G_{vd}(s) \tag{7.8}$$

In order to determine a single compensator  $A_v(s)$  for both loops,  $T_i(s)$  and  $T_v(s)$  need to be related. Because the compensator effects both loops, it is important to design the loops with the same characteristics. This allows both loops to be in unison and not work against each other. This can be achieved by designing both loops to have the same crossover frequency. This happens when the ratio of the two loops is set equal to 1.

$$\frac{T_v(s)}{T_i(s)} = \frac{G_{vd}(s)}{R_i G_{id}(s)} = \frac{R(1 + \frac{s}{\omega_c})}{R_i(1 + \frac{s}{\omega_p})}$$
(7.9)



Figure 7.12: Small-signal block diagram of the current sensing mode

It can be seen that this ratio equals 1 when  $R_i = R_c$  and when  $\omega > \omega_c$ , since the zero from the output capacitor is normally much larger than  $\omega_R$ .

The design should be similar to the voltage droop control in terms of having a constant impedance gain equal to the parasitic losses of the output capacitor. The closed-loop output impedance function,  $Z_{oc}(s)$ , is shown below.

$$Z_{oc}(s) = \frac{Z_o(s)(1+T_i(s)) + T_i(s)\frac{G_{vd}(s)G_{ii}(s)}{G_{id}(s)}}{1+T_i(s) + T_v(s)}$$
(7.10)

Setting the above equation equal to the value of  $R_c$  the transfer function of  $A_v(s)$  can be derived. From [2], the current loop should be stable with a phase margin of around 90°. In order to achieve this, a zero,  $\omega_z$ , is needed to compensate for the power stage double pole. The high frequency switching noise should also be filtered. This requires a pole,  $\omega_p$ , placed well before the switching frequency. The current loop should have a crossover frequency that is higher than the parasitic zero of the output capacitor. This can be done by making the gain,  $\omega_i$ , of the compensator sufficiently large. Since infinite DC gain is required, an integrator is used by placing a pole at zero,  $\frac{1}{s}$ . The compensator transfer function can now be realized.



Figure 7.13: Small-signal block diagram of the current sensing mode -General

$$A_v(s) = \omega_i \frac{1 + \frac{s}{\omega_z}}{s(1 + \frac{s}{\omega_p})} \tag{7.11}$$

where  $\omega_z = \omega_o, \, \omega_p = (2\pi)50,000, \, \text{and} \, \omega_i = 100,000$ 

The compensator can now be implemented using an operational amplifier circuit. As seen if Figure 7.17, this circuit can be implemented using a single op-amp. The summing of the two loops is incorporated into the op-amp used by the compensator. Please note the use of a voltage divider in the voltage feedback loop is similar to that in the previous section, only it has been scaled to a ratio of  $\frac{1}{2}$  for component value selection.

The loop gain of this system is a ratio of the current and voltage loops, and once again it's not safe to assume a reference of 5 V will work for this system.  $V_{ref}$  is found to be approximately 3.8 V in this design.

### Loop Gain Analysis

With the design stage complete, the system can be analyzed for stability and crossover frequency verification. The outer loop,  $T_2$ , shown below, determines the system stability.

$$T_2(s) = \frac{T_v(s)}{1 + T_i(s)} \tag{7.12}$$

It can be seen in Figure 7.14 that all three loops have the same crossover frequency. Stability is verified with  $T_2$  having a phase margin of about  $105^{\circ}$ . This is really close to the design of  $90^{\circ}$ , with other poles and zeros from  $T_v$  and  $T_i$  accounting for the slight difference.

It can be observed in Figure 7.15 that the impedance gain is nearly constant. The impedance phase is also nearly constant as it changes only slightly over the entire range of frequencies.

In Figure 7.18, the current sensing droop control was simulated with a step in the load current, the same as was performed Section 1. The results are nearly the same as with the voltage droop control. There are slight transient spikes, but they are small and are on the order of the ripple. These spikes are caused from the slight deviation in the constant output impedance. With the output impedance at  $50m\Omega$ , the ideal voltage change would again be .245 V. Aside from the slight transient spikes, this is what is approximately seen in Figure 7.18. This two loop compensation control can achieve the same results as the simple voltage droop control, yet have the versatility to compensate for both voltage and current. In the next section, a voltage compensation scheme will be presented and compared to the droop control methods.



Figure 7.14: MATLAB Bode Plot of Loop Gains with Active Droop Compensation

#### 7.2.3 Voltage Mode Compensation

#### Concept of voltage compensation

The final design that will be discussed in this report is a traditional voltage compensation design. Back in Figure 7.4, we found for the purposes of droop control that we would design for changes in output current and neglect any disturbances in the input voltage. For this design, the compensation circuit will be designed to reduce the audio susceptibility of the circuit  $(G_{cl}(s) = \frac{\hat{v}}{v_g})$ . This design will then be tested by applying a step disturbance to the load current, and determining the maximum deviation of the output voltage in response to the disturbance.

By following the loop in Figure 7.4, it can be seen by inspection that  $G_{cl}(s) = \frac{G_{vg}(s)}{1+T(s)}$ , where  $T(s) = G_{vd}(s)(Fm)G_{con}(s)$  and  $G_{vd}(s)$  is the same as in Section 1 and Section 2.  $G_{vg}(s)$  can be found to equal the following expression:

$$G_{vg}(s) = D \frac{1 + \frac{s}{\omega_c}}{1 + \frac{s}{Q\omega_0} + \left(\frac{s}{\omega_0}\right)^2}$$
(7.13)



Figure 7.15: MATLAB Bode Plot of  $\mathbb{Z}_o$  for Active Droop Compensated System



Figure 7.16: MATLAB Bode Plot of  ${\cal G}_{vg}$  for Active Droop Compensated System



Figure 7.17: PECS Schematic of System with Active Droop Compensation



Figure 7.18: PECS Simulation of Active Droop Compensated Response to a Load Current Step



Figure 7.19: PECS Simulation of Active Droop Compensated Response to a Supply Voltage Disturbance



Figure 7.20: Complete Small-signal block diagram of the current sensing mode

Where all parameters of the equation are the same as described in the previous sections.

#### **Designing loop compensation**

The goal of this design is to create a compensation block that will maximally reduce the effect of input voltage disturbances on the output. To improve on the basic integrator compensator design, two zeros are added around the crossover frequency to combat the extra  $-90^{\circ}$  of phase shift introduced by the integrator. Two poles are also introduced to ensure that the switching frequency noise will be canceled with the introduction of the zero. The equation for this compensation block is shown below:

$$G_{con}(s) = \frac{\omega_I}{s} \frac{(1 + \frac{s}{\omega_{z1}})(1 + \frac{s}{\omega_{z2}})}{(1 + \frac{s}{\omega_{p1}})(1 + \frac{s}{\omega_{p2}})}$$
(7.14)

where  $\omega_I$  is the constant gain and  $\omega_{z1}$ ,  $\omega_{z2}$ ,  $\omega_{p1}$ , and  $\omega_{p2}$  are the new parameters to be designed.

To gain a better understanding of the system, the system transfer functions are plotted for three different cases of zero placement:



Figure 7.21: Bode Plot Asymptotes for Case 1



Figure 7.22: Bode Plot Asymptotes for Case 2



Figure 7.23: Bode Plot Asymptotes for Case 3

To determine a proper location for the introduced components, it is important to first start by improving the phase margin. This is accomplished by having at least one zero below the natural frequency of the system. By introducing one zero rather than both at this point, it will work to exactly cancel the phase shift introduced by the integrator without dropping the loop gain more than necessary. Introducing the second zero after the natural frequency will help extend the loop gain bandwidth, pushing the crossover frequency further toward higher frequency.

Through careful adjustment of parameter location and system response simulation, the system parameters were calculated as shown below. An optimum crossover frequency is found in terms of improving the phase margin, yet also maximizing loop gain bandwidth at  $f_c = 6.31kHz$ . This will be shown in the system response later in this section.

$$\omega_{z1} = (2\pi)5.06 \frac{krad}{s}$$
$$\omega_{z2} = (2\pi)8.22 \frac{krad}{s}$$
$$\omega_{p1} = \omega_{(z)} = (2\pi)6.37 \frac{krad}{s}$$
$$\omega_{p2} = (2\pi)63.6 \frac{krad}{s}$$
$$\omega_{I} = 17k \frac{rad}{s}$$

Figure 7.24 describe the loop gain of the system as a function of frequency. Note that with the previously discussed changes, high DC gain, switching frequency attenuation, and system stability are all accomplished.

Figure 7.27 is the circuit realization of the compensation scheme designed above. Figure 7.28 shows the simulation results of the circuit in response to the change in output current described in the introduction. Note that the maximum deviation from peak to peak using this voltage compensation scheme is 300 mV. The system shows a spike in voltage when the current is changed, and then quickly reduces to the expected voltage. This clearly shows the difference between this method of design and the constant impedance method, where a constant impedance will have half of the peak to peak voltage deviation; yet, there is a difference in the average output voltage level depending on the load applied. However, since power supply requirements are typically quantified in terms of an output voltage tolerance range, the voltage droop compensation and current droop compensation allow for tighter restrictions on levels, thus making them a better design compared to traditional voltage compensation.



Figure 7.24: MATLAB Bode Plot of Loop Gains with Voltage Mode Compensation



Figure 7.25: MATLAB Bode Plot of  $\mathbb{Z}_o$  for Voltage Mode Compensated System



Figure 7.26: MATLAB Bode Plot of  ${\cal G}_{vg}$  for Voltage Mode Compensated System



Figure 7.27: PECS Schematic of System with Voltage Mode Compensation



Figure 7.28: PECS Simulation of Voltage Mode Compensated Response to a Load Current Step



Figure 7.29: PECS Simulation of Voltage Mode Compensated Response to a Supply Voltage Disturbance

### 7.3 Summary

Through implementation of a voltage droop, inductor current droop, and a voltage compensation circuit, it was found that the voltage and current droop compensation techniques were able to have an output voltage deviation of half the size of the voltage compensation method. This reduction in output voltage deviation is an effect of creating a constant closed loop output impedance on the output of the converter. The only downside to the droop compensation methods is that the output voltage changes to the deviation value, rather than introducing a small transient and returning, as is the case with the voltage compensation.

Overall, due to the fact that regulated voltages are defined over an acceptable output range, the droop control methods both allow the smallest deviation that can fit in a given tolerance window. Ideally the current sensing droop control is the most complete method of compensation due to the two loop compensation. Practically, however, the voltage droop method accurately reduces the output voltage deviation and is the simplest to implement in terms of components.

### 7.4 MATLAB Code

```
clear
 1
2
   close all
   format compact
3
4
   s = tf('s');
5
6
   Vg = 28;
\overline{7}
   R = 3;
8
9
   L = 50e - 6;
   C = 500e - 6;
10
   rl = 0.25;
11
12 rc = 0.05;
13 Vm = 4;
14 Vo = 15;
   D = Vo/Vq;
15
16
17
18 H = 1/3;
19 w0 = 1/sqrt(L*C);
   f0 = w0/(2*pi);
20
21
   wc = 1/(rc*C);
_{22} wr = 1/(R*C);
23 wl = rl/L;
Q = \operatorname{sqrt}(L/C)/(rl+rc);
   PWM = 1/Vm;
25
   T0 = Vg*H*PWM;
^{26}
27
^{28}
```

```
29 f = logspace(1, 6, 1000);
30 w = 2*pi*f;
31
33 %%% Plant Open-loop
^{34}
35 Gvg = D \star (1+s/wc) / (1+s/(Q \star w0) + (s/w0)^2);
36 Gvd = Vg*(1+s/wc)/(1+s/(Q*w0)+(s/w0)^2);
37 Zo = rl*(l+s/wc)*(l+s/wl)/(l+s/(Q*w0)+s^2/w0^2);
38
39 %%% Loop gain
40 T = tf(T0*[1/wc 1], [1/w0^2 1/(Q*w0) 1]);
41
42 figure(1)
43 [mag, phase] = bode(T,w);
44 margin(mag, phase, w)
45
46 h = gcr;
47 h.AxesGrid.Xunits = 'Hz';
48 h.AxesGrid.TitleStyle.FontSize = 16;
49 h.AxesGrid.XLabelStyle.FontSize = 12;
50 h.AxesGrid.YLabelStyle.FontSize = 12;
51
52 \% Zoc = Zo/(1+T);
53 % Gvgc = Gvg/(1+T);
54 %
55 % figure(2)
56 % bode(Zo);
57 % hold
58 % bode (Zoc)
59 % title('');
60 % h = gcr;
61 % h.AxesGrid.Xunits = 'Hz';
62 % h.AxesGrid.TitleStyle.FontSize = 16;
63 % h.AxesGrid.XLabelStyle.FontSize = 12;
64 % h.AxesGrid.YLabelStyle.FontSize = 12;
65 %
66 %
67 % figure(3)
68 % bode(Gvg);
69 % hold
70 % bode (Gvgc)
71 % title('');
72 % h = gcr;
73 % h.AxesGrid.Xunits = 'Hz';
74 % h.AxesGrid.TitleStyle.FontSize = 16;
75 % h.AxesGrid.XLabelStyle.FontSize = 12;
76 % h.AxesGrid.YLabelStyle.FontSize = 12;
77
78
79
80
82 %%% Droop passive
83
84 Kv = (rl-rc) / (rc * Vg * (1/Vm) *H);
85 wzc = (rl-rc) / (L-rc*rc*C);
```

```
86 wpv = wc;
87
88 Gcdroop_p = tf(Kv*[1/wzc 1], [1/wpv 1]);
89
90 Tdroop_p = Gcdroop_p * T;
91
92 figure(4)
93 [mag, phase] = bode(Tdroop_p,w);
94 margin(mag, phase, w)
95 h = qcr;
96 h.AxesGrid.Xunits = 'Hz';
97 h.AxesGrid.TitleStyle.FontSize = 16;
98 h.AxesGrid.XLabelStyle.FontSize = 12;
99 h.AxesGrid.YLabelStyle.FontSize = 12;
100
101
102 Zoc = Zo/(1+Tdroop_p);
103 Gvgc = Gvg/(1+Tdroop_p);
104
105 figure(2)
106 bode(Zo);
107 hold
108 bode(Zoc)
109 title('');
110 h = gcr;
111 h.AxesGrid.Xunits = 'Hz';
112 h.AxesGrid.TitleStyle.FontSize = 16;
113 h.AxesGrid.XLabelStyle.FontSize = 12;
114 h.AxesGrid.YLabelStyle.FontSize = 12;
115
116
117 figure(3)
118 bode(Gvg);
119 hold
120 bode (Gvgc)
121 title('');
122 h = gcr;
123 h.AxesGrid.Xunits = 'Hz';
124 h.AxesGrid.TitleStyle.FontSize = 16;
125 h.AxesGrid.XLabelStyle.FontSize = 12;
126 h.AxesGrid.YLabelStyle.FontSize = 12;
127
128
130 %%% Droop active
131
132 wi_da = 100000;
133 wz_da = w0;
134 wp_da = 2*pi*50000;
135
136 % wi_da = 7.3529e+004;
137 % wz_da = w0;
138 % wp_da = 2*pi*5.4683e+004;
139
140 Gcvdroop_a = tf(wi_da*[1/wz_da 1], conv([1 0], [1/wp_da 1]));
141
142 Tvdroop_a = Gcvdroop_a * T;
```

```
143
144 figure(5)
145 [mag, phase] = bode(Tvdroop_a,w);
146 margin(mag, phase, w)
147
148 hold
149
150 Ti = tf(Vg/R*[1/wr 1], [1/w0^2 1/(Q*w0) 1]);
151 Tidroop_a = PWM * H *Gcvdroop_a * Ti * rc;
152
153 [mag, phase] = bode(Tidroop_a,w);
154 margin(mag, phase, w)
155
156 T2 = Tvdroop_a/(1+Tidroop_a);
157 [mag, phase] = bode(T2,w);
158 margin(mag, phase, w)
159
160 h = gcr;
161 h.AxesGrid.Xunits = 'Hz';
162 h.AxesGrid.TitleStyle.FontSize = 16;
163 h.AxesGrid.XLabelStyle.FontSize = 12;
164 h.AxesGrid.YLabelStyle.FontSize = 12;
165
166 hold off
167
168
169
170
171 Gii=(1+s/wc)/(1+s/(Q*w0)+s^2/w0^2);
172 Gid=(Vg/R)*(1+s/wr)/(1+s/(Q*w0)+s^2/w0^2);
173 Gig=s*C/(1+s/(Q*w0)+s^2/w0^2);
174
175 % Av=wi*(1+s/w1)/(s*(1+s/w2));
176 % Ti= Av*Fm*Gid*H*Ril;
177 % Tv=Av*Fm*H*Gvd;
178 % T2=Tv/(1+Ti);
179 %Gvgc=Gvg/(1+T2);
180
181 Ti = Tidroop_a;
182 Tv = Tvdroop_a;
183
184 Zoc = (Zo*(1+Ti)+Ti*(Gvd*Gii)/Gid)/(1+Ti+Tv);
185 Gvgc = (Gvg*(1+Ti)-Ti*(Gvd*Gig)/Gid)/(1+Ti+Tv);
186
187 figure(9)
188 bode (Zo);
189 hold
190 bode (Zoc)
191 title('');
192 h = gcr;
193 h.AxesGrid.Xunits = 'Hz';
194 h.AxesGrid.TitleStyle.FontSize = 16;
195 h.AxesGrid.XLabelStyle.FontSize = 12;
196 h.AxesGrid.YLabelStyle.FontSize = 12;
197
198
199 figure(10)
```

```
200 bode (Gvg);
201 hold
202 bode (Gvgc)
203 title('');
_{204} h = gcr;
205 h.AxesGrid.Xunits = 'Hz';
206 h.AxesGrid.TitleStyle.FontSize = 16;
207 h.AxesGrid.XLabelStyle.FontSize = 12;
208 h.AxesGrid.YLabelStyle.FontSize = 12;
209
210
211
212
214 %%% Voltage mode
215
_{216} wi = 17000;
217 wz1 = 0.8*w0;
_{218} wz2 = 1.3*w0;
219 wp1 = wc;
220 wp2 = 10*wp1;
221
222 Gcvmode = tf(wi*conv([1/wz1 1], [1/wz2 1]), conv([1 0], ...
       conv([1/wp1 1], [1/wp2 1])));
223
224 Tvmode = Gcvmode * T;
225
226 figure(6)
227 [mag, phase] = bode(Tvmode,w);
228 margin(mag, phase, w)
229 h = gcr;
230 h.AxesGrid.Xunits = 'Hz';
231 h.AxesGrid.TitleStyle.FontSize = 16;
232 h.AxesGrid.XLabelStyle.FontSize = 12;
233 h.AxesGrid.YLabelStyle.FontSize = 12;
234
235 Zoc = Zo/(1+Tvmode);
236 Gvgc = Gvg/(1+Tvmode);
237
238 figure(7)
239 bode (Zo);
240 hold
241 bode (Zoc)
242 title('');
243 h = gcr;
244 h.AxesGrid.Xunits = 'Hz';
245 h.AxesGrid.TitleStyle.FontSize = 16;
246 h.AxesGrid.XLabelStyle.FontSize = 12;
247 h.AxesGrid.YLabelStyle.FontSize = 12;
248
249
250 figure(8)
251 bode (Gvg);
252 hold
253 bode (Gvgc)
254 title('');
255 h = gcr;
```

```
256 h.AxesGrid.Xunits = 'Hz';
257 h.AxesGrid.TitleStyle.FontSize = 16;
258 h.AxesGrid.XLabelStyle.FontSize = 12;
259 h.AxesGrid.YLabelStyle.FontSize = 12;
260
261
262
265 %%% Components
266
267 %%% Droop passive
268 display(' Droop passive ')
269 R1 = 100000;
270 C1 = 1/(R1*wzc);
271 R2 = Kv*R1;
_{272} C2 = 1/(R2*wpv);
273
274 R1
275 R2
276 C1
277 C2
278 display(' ')
279
280 %%% Droop active
281
282 display('Droop active ')
283 C1 = 33e-12;
_{284} R2 = 1/(wp_da*C1);
285 C2 = 1/(R2*wz_da);
286 R1 = 1/(C2*wi_da);
287
288
289 R1
290 R2
291 Cl
292 C2
293 display(' ')
294
295 %%% Voltage mode, R1 >> R3, C1 >> C3
296
297 display('Voltage mode ')
298 C3 = 33e-12;
299 R2 = 1/(C3*wp2);
300 C1 = 1/(R2 * wz1);
301 R1 = 1/(C1*wi);
302 C2 = 1/(R1 * wz2);
303 R3 = 1/(C2*wp1);
304
305 C1
306 C2
307 C3
308 R1
309 R2
310 R3
311
312 %%% Droop passive
```

313 % R1 = 314 % 100000 315 % R2 = 316 % 1.7143e+005 317 % Cl = 318 % 2.4375e-009 319 % C2 = 320 % 1.4583e-010 321 322 323 % Droop active 324 % wi\_da = 70000; 325 % wz\_da = w0; 326 % wp\_da = 70000; 327 % 328 % R1 = 329 % 3.9113e+004 330 % R2 = 331 % 4.3290e+005 332 % C1 = 333 % 3.3000e-011 334 % C2 = 335 % 3.6524e-010 336 337 338 % %%% Droop active 339 % wi\_da = 150000; 340 % wz\_da = w0; 341 % wp\_da = 50000; 342 % R1 = 343 % 2.5554e+004 344 % R2 = 345 % 6.0606e+005 346 % C1 = 347 % 3.3000e-011 348 % C2 = 349 % 2.6089e−010 350 351 352 %%% Voltage mode 353 % wi = 7000; 354 % wz1 = 0.3\*w0; 355 % wz2 = 1.4\*w0; 356 % wpl = wc; 357 % wp2 = 10\*wp1; 358 % 359 % C1 = 360 % 6.9570e−009 361 % C2 = 362 % 5.5000e-009 363 % C3 = 364 % 3.3000e-011 365 % R1 = 366 % 2.3957e+004 367 % R2 = 368 % 7.5758e+004 369 % R3 =

```
370 % 4.5455e+003
371
372
373 % %%% Voltage mode
374 % wi = 17000;
375 % wz1 = 0.8*w0;
376 % wz2 = 1.3∗w0;
377 % wp1 = wc;
378 % wp2 = 10*wp1;
379 %
380 % Cl =
381 % 2.6089e-009
382 % C2 =
383 % 5.3942e-009
384 % C3 =
385 % 3.3000e−011
386 % R1 =
387 % 2.2547e+004
388 % R2 =
389 % 7.5758e+004
390 % R3 =
391 % 4.6346e+003
392
393
394 %%%% Droop active
395 R1 = 50e3;
396 R2 = 593e3;
397 C1 = 5e-12;
398 C2 = 267e-12;
399 wi = 1/(R1*(C1+C2));
400 fz = 1/(2*pi*R2*C2);
401 fp = 1/(2*pi*R2*C1*C2/(C1+C2));
402 display('Droop active - good')
403 Wi
404 fz
405 fp
```

# References

- K. Yao, M. Xu and F. Lee, "Design Considerations for VRM Transient Response Based on the Output Impedance," *IEEE Trans. Power Electron.*, vol. 18, no. 6, pp. 1270–1277, November 2003.
- [2] K. Yao, K. Lee, M. Xu and F. Lee, "Optimal Design of the Active Droop Control Method for the Transient Response," in *IEEE Applied Power Elec. Conf. and Expo.*, vol. 2, 2003, pp. 718–723.

REFERENCES

# Part II Modern Control

### Chapter 8

## Introduction

There are three main problems that can be examined in the study of systems in the controls context: system dynamics, system identification or modeling, and system control. They develop from the three aspects that are present in the block diagram of a basic system: input, system, and output [1]. Typically, two of the three aspects are known, and the third must be determined from the other two.

In system control, the system is known, and the input to the system that produces a desired output must be determined. Part II focuses on the fundamental control problem of regulation for disturbance rejection as it pertains to DC-DC converters, and uses the Ćuk DC-DC converter as the platform for applying the various design steps, leading up to a minimal-order compensator design, demonstrated in Chapter 14. It is assumed that the reader of this part of the book is familiar with the classical control system design techniques presented earlier as the modern control design methods build on a classical foundation. Note that for the regulation problem, the desired output value is fixed, whereas in the servo problem, the desired output is to track a changing setpoint.

The Ćuk DC-DC converter was chosen as an example system for two main purposes. This nonlinear switching circuit can act to raise (boost) or lower (buck) the voltage from input to output, making it a generic DC-DC converter (compared to converters that can only boost or buck the input voltage, but not do both). Also, the circuit contains four energy storage devices leading to a fourth-order system, which creates sufficient complexity in an output feedback compensator to require compensator order reduction. This allows an original idea regarding order reduction to be presented. Boost or buck converters are typically implemented with only two energy storage components, and the resulting simplicity in compensators designed using modern control techniques either does not require model reduction or renders one of the techniques presented in this part of the text practically useless.

Analysis of the Cuk converter circuit begins in Chapter 9. The control system analysis and design procedures use MATLAB from The Mathworks, Inc., and code is presented at the end of each chapter for the relevant chapter material. The nonlinear Ćuk switching circuit is modeled as a small-signal continuous linear time invariant (LTI) system using state space averaging. The LTI model to be used during the design process is validated by transient comparison with a nonlinear circuit simulation to justify the assumption that the small-signal model would be adequate. The open-loop performance characteristics are tested, and a set of performance criteria for the closed-loop controlled system are specified.

Chapter 10 covers pole placement using state feedback. This chapter uses desired poles given by a filter prototype that is optimal with respect to an integral performance index and discusses how to select a weighting parameter that determines the closed-loop pole locations.

Integral augmentation of the state feedback architecture is described in Chapter 11. This allows the closed-loop system to completely eliminate steady state error, which could not be accomplished by state feedback alone.

Chapter 12 discusses state estimation using full- and reduced-order observers to allow for the use of output feedback, as state information is not always available to the designer.

Chapter 13 shows the application of optimal control and estimation using linear quadratic methods. These techniques allow the designer to determine optimal controller and optimal estimator gains. Loop transfer recovery is discussed as a means to recover desirable frequency-domain stability margins that are lost when designing an optimal output feedback compensator.

In order to design compensators that can be constructed from a minimum number of components, Chapter 14 covers order reduction methods. First, a reduced-order optimal compensator with recovered loop gain is designed. This step is followed by applying balanced realization and truncation techniques to eliminate states with little effect on performance, resulting in additional compensator order reduction.

Chapter 15 describes how to implement two of the final compensator designs that were created and shows the difference in analog controller circuit complexity that can arise from only one additional order in the compensator.

Chapter 16 presents the minimal compensator circuit test results from a power electronics simulator that prove the performance of the final controller design exceeded the original design specifications.

Finally, Chapter 17 wraps up Part II of the text with a recap of the methods presented and their results.

# References

 B. A. Ogunnaike and W. H. Ray, Process Dynamics, Modeling, and Control. New York, NY: Oxford University Press, 1994.

REFERENCES

### Chapter 9

# System Analysis

Prior to designing a controller for a system, the control system designer must understand the system's characteristics. For example, is the system open-loop stable? Are there dominant poles? Are there poles that may be neglected during design? Is the system controllable using the selected inputs? Can an estimator be constructed based on the measured outputs? These types of questions should be answered both intuitively and mathematically prior to embarking on an attempt to design a controller for the system.

As stated in Chapter 8, the Ćuk DC-DC converter is used here as the example system for demonstrating the compensator design processes described in Part II. The starting point is the construction of a mathematical model of the system in MATLAB. The model is a mathematical description of some or all of the behavior of the real-world system that is adequate for performing controller design. State space averaging yields a linear small-signal model for the nonlinear switching system [1]. Additionally, a nonlinear circuit model was created in the Power Electronics Circuit Simulator (PECS) software package in order to validate the performance of the assumed linear model. PECS uses a schematicbased circuit editor and features its own plotting tool, PECSPLOT.

A note on notation: the zeros, poles, and gains of systems discussed in Part II are in the Evans form, i.e., the coefficient of the highest power of s in each factored term is unity and the stated gain is not the DC gain of the system. This is in contrast to Bode form, where the constant in each factored term is unity and the DC gain is explicitly stated. Evans form was chosen for convenience, as it is the form used by zpk systems in MATLAB.

### 9.1 The Ćuk Converter

The Čuk converter is a step-down/step-up converter based on a switching boostbuck topology. Essentially, the converter is composed of two sections, an input stage and an output stage. The schematic of the Čuk converter is presented in Figure 9.1, with component values given in Subsection 9.2.3. (The lowercase



Figure 9.1: Cuk converter with inductor equivalent series resistances.

variables indicate small-signal deviations from nominal operating point variables as obtained by linearization.) The input voltage  $v_g$  is fed into the circuit via inductor  $L_1$ . When transistor  $Q_1$  is on, current  $i_1$  builds the magnetic field of the inductor in the input stage. The diode  $CR_1$  is reverse biased, and energy dissipates from the storage elements in the output stage. When  $Q_1$  turns off, inductor  $L_1$  tries to maintain the current flowing through it by reversing polarity and sourcing current as its magnetic field collapses. It thus provides energy to the output stage of the circuit via capacitor  $C_1$ . Both currents  $i_1$  and  $i_2$  must sum to zero in the steady state, since the assumption is that voltage  $v_1$  is essentially constant (given that the voltage across a capacitor cannot change instantaneously and the switching speed of the circuit is high). This provides for the following charge conservation relation:

$$i_1 t_{on} + i_2 t_{off} = 0 (9.1)$$

The inductor currents are the input and output currents, therefore, if the principle of conservation of energy is applied:

$$\frac{v_o}{v_g} = \frac{D_s}{1 - D_s} \tag{9.2}$$

where  $D_s$  is the duty cycle of the switch,  $D_s \stackrel{\Delta}{=} \frac{t_{on}}{t_{on}+t_{off}}$ . Equation 9.2 shows that by controlling the duty cycle of the switch (by small-signal deviation d), the output voltage  $v_o$  can be controlled and can be higher or lower than the input voltage  $v_g$ . By using a controller to vary the duty cycle during operation, the circuit can also be made to reject disturbances, as will be shown.
### 9.2 The Ćuk Converter Model

The Ćuk converter selected was designed with just enough mutual inductance to avoid a nonminimum phase converter structure, a requirement for a controller design method used later in the text.

#### 9.2.1 Analysis of Inductors with Mutual Coupling and Equivalent Series Resistances

The equations for the voltage across two inductors  $L_1$  and  $L_2$  joined by mutual coupling are:

$$v_{L_1} = L_1 \frac{di_1}{dt} + M \frac{di_2}{dt}$$
$$v_{L_2} = M \frac{di_1}{dt} + L_2 \frac{di_2}{dt}$$

The solutions of the two simultaneous equations are:

$$\frac{di_1}{dt} = \frac{L_2}{L_1 L_2 - M^2} v_{L_1} + \frac{-M}{L_1 L_2 - M^2} v_{L_2} \frac{di_2}{dt} = \frac{-M}{L_1 L_2 - M^2} v_{L_1} + \frac{L_1}{L_1 L_2 - M^2} v_{L_2}$$

For the circuit with equivalent series resistances included in the inductor models when  $Q_1$  conducts:

$$\begin{aligned} v_{L_1} &= v_g - i_1 R_1 \\ v_{L_2} &= v_1 - v_2 - i_2 R_2 \end{aligned}$$

therefore:

$$\begin{aligned} \frac{di_1}{dt} &= \frac{M}{\sigma^2} v_2 + \frac{-M}{\sigma^2} v_1 + \frac{MR_2}{\sigma^2} i_2 + \frac{-L_2R_1}{\sigma^2} i_1 + \frac{L_2}{\sigma^2} v_g \\ \frac{di_2}{dt} &= \frac{-L_1}{\sigma^2} v_2 + \frac{L_1}{\sigma^2} v_1 + \frac{-L_1R_2}{\sigma^2} i_2 + \frac{MR_1}{\sigma^2} i_1 + \frac{-M}{\sigma^2} v_g \end{aligned}$$

with  $\sigma^2 = L_1 L_2 - M^2$ .

When  $Q_1$  does not conduct:

therefore:

$$\begin{aligned} \frac{di_1}{dt} &= \frac{M}{\sigma^2} v_2 + \frac{-L_2}{\sigma^2} v_1 + \frac{MR_2}{\sigma^2} i_2 + \frac{-L_2R_1}{\sigma^2} i_1 + \frac{L_2}{\sigma^2} v_g \\ \frac{di_2}{dt} &= \frac{-L_1}{\sigma^2} v_2 + \frac{M}{\sigma^2} v_1 + \frac{-L_1R_2}{\sigma^2} i_2 + \frac{MR_1}{\sigma^2} i_1 + \frac{-M}{\sigma^2} v_g \end{aligned}$$

with  $\sigma^2 = L_1 L_2 - M^2$ .

#### 9.2.2 The State Space Averaged Model

State space averaging is a well-known method used in modeling switching converters. For a system with a single switching component with a nominal duty cycle, a model may be developed by determining the state and measurement equations for each of the two switch states, then calculating a weighted average of the two sets of equations using the nominal values of the time spent in each state as the weights. To develop the state space averaged model, the equations for the rate of inductor current change derived in Subsection 9.2.1 are used along with the equations for the rate of capacitor voltage change that may be derived from the Ćuk converter circuit. For the purposes of modeling, the state vector is given by:

$$x = \begin{bmatrix} v_2 & v_1 & i_2 & i_1 \end{bmatrix}'$$

When  $Q_1$  conducts, the following state space matrices result:

$$A_{1} = \begin{bmatrix} -\frac{1}{RC_{2}} & 0 & \frac{1}{C_{2}} & 0 \\ 0 & 0 & \frac{-1}{C_{1}} & 0 \\ -\frac{L_{1}}{\sigma^{2}} & \frac{L_{1}}{\sigma^{2}} & -\frac{L_{1}R_{2}}{\sigma^{2}} & \frac{MR_{1}}{\sigma^{2}} \\ \frac{M}{\sigma^{2}} & -\frac{M}{\sigma^{2}} & \frac{MR_{2}}{\sigma^{2}} & -\frac{L_{2}R_{1}}{\sigma^{2}} \end{bmatrix}$$
$$B_{1} = \begin{bmatrix} 0 \\ 0 \\ -\frac{M}{\sigma^{2}} \\ \frac{L_{2}}{\sigma^{2}} \end{bmatrix}$$
$$C_{1} = \begin{bmatrix} 1 & 0 & 0 & 0 \end{bmatrix}$$
$$D_{1} = \begin{bmatrix} 0 \end{bmatrix}$$

When  $Q_1$  is not conducting, the circuit model is represented by the following state space matrices:

$$A_{2} = \begin{bmatrix} -\frac{1}{RC_{2}} & 0 & \frac{1}{C_{2}} & 0 \\ 0 & 0 & 0 & \frac{-1}{C_{1}} \\ -\frac{L_{1}}{\sigma^{2}} & \frac{M}{\sigma^{2}} & -\frac{L_{1}R_{2}}{\sigma^{2}} & \frac{MR_{I}}{\sigma^{2}} \\ \frac{M}{\sigma^{2}} & -\frac{L_{2}}{\sigma^{2}} & \frac{MR_{2}}{\sigma^{2}} & -\frac{L_{2}R_{I}}{\sigma^{2}} \end{bmatrix}$$
$$B_{2} = \begin{bmatrix} 0 \\ 0 \\ -\frac{M}{\sigma^{2}} \\ \frac{L_{2}}{\sigma^{2}} \end{bmatrix}$$
$$C_{2} = \begin{bmatrix} 1 & 0 & 0 & 0 \end{bmatrix}$$
$$D_{2} = \begin{bmatrix} 0 \end{bmatrix}$$

By representing the duty cycle of the switch as  $D_s$ , the following results may be obtained for a state space averaged model of the Ćuk converter:

$$D'_{s} \stackrel{\Delta}{=} 1 - D_{s}$$

$$\frac{V_{o}}{V_{g}} = \frac{D_{s}}{1 - D_{s}} = \frac{D_{s}}{D'_{s}}$$

$$A = D_{s}A_{1} + D'_{s}A_{2}$$

$$B = D_{s}B_{1} + D'_{s}B_{2}$$

$$C = D_{s}C_{1} + D'_{s}C_{2}$$

$$D = D_{s}D_{1} + D'_{s}D_{2}$$

$$X = -A^{-1}BV_{g}$$

$$B_{d} = (A_{1} - A_{2})X + (B_{1} - B_{2})V_{g}$$

$$D_{d} = (C_{1} - C_{2})X + (D_{1} - D_{2})V_{g}$$

$$\dot{\tilde{x}} = A\tilde{x} + B\tilde{v}_g + B_d\tilde{d} \tilde{v}_o = C\tilde{x} + D\tilde{v}_g + D_d\tilde{d}$$

where the tilde ( $\tilde{}$ ) indicates a small signal deviation from nominal, and:

$$x = X + \tilde{x}$$
$$v_g = V_g + \tilde{v}_g$$
$$d = D_s + \tilde{d}$$
$$v_o = V_o + \tilde{v}_o$$

$$A = \begin{bmatrix} -\frac{1}{RC_2} & 0 & \frac{1}{C_2} & 0 \\ 0 & 0 & -\frac{D_s}{C_1} & \frac{1-D_s}{C_1} \\ -\frac{L_I}{L_I L_2 - M^2} & \frac{D_s L_I + M - D_s M}{L_I L_2 - M^2} & 0 & 0 \\ \frac{M}{L_I L_2 - M^2} & \frac{-D_s M - L_2 + L_2 D_s}{L_I L_2 - M^2} & 0 & 0 \end{bmatrix}$$

$$B = \begin{bmatrix} 0 \\ 0 \\ -\frac{M}{L_I L_2 - M^2} \\ \frac{L_2}{L_I L_2 - M^2} \end{bmatrix}$$

$$C = \begin{bmatrix} 1 & 0 & 0 & 0 \end{bmatrix}$$

$$D = \begin{bmatrix} 0 \end{bmatrix}$$

$$B_d = \begin{bmatrix} 0 \\ -\frac{D_s V_g}{R(1-D_s)^2 C_I} \\ \frac{V_g (L_I - M)}{(1-D_s)(L_I L_2 - M^2)} \\ \frac{V_g (-M + L_2)}{(1-D_s)(L_I L_2 - M^2)} \end{bmatrix}$$

The equilibrium state vector is:

$$X = \begin{bmatrix} V_2 \\ V_1 \\ I_2 \\ I_1 \end{bmatrix} = \begin{bmatrix} \frac{D_s V_g}{1 - D_s} \\ \frac{V_g}{1 - D_s} \\ \frac{D_s V_g}{R(1 - D_s)} \\ \frac{D_s^2 V_g}{R(1 - D_s)^2} \end{bmatrix}$$

#### 9.2.3 Component Values

Here are the Ćuk converter circuit component values used in the remainder of Part II:

$$\begin{array}{rcl} L_1 &=& 0.5\,mH\\ R_1 &=& 0.01\,\Omega\\ L_2 &=& 7.5\,mH\\ R_2 &=& 0.01\,\Omega\\ M &=& -1.5\,mH\\ C_1 &=& 2.0\,\mu F\\ C_2 &=& 20\,\mu F\\ R &=& 30\,\Omega\\ V_g &=& 12\,V\\ d &=& 0.667\\ f &=& 100\,kHz \end{array}$$

## 9.3 Ćuk Converter Open Loop Performance

Before a controller was designed, the performance of the open-loop Ćuk model was examined. A state space block diagram for the open-loop model is shown in Figure 9.2. The state space equations were determined to be:

$$\dot{x} = Ax + Bv_g + B_d d \qquad (9.3)$$
  

$$v_o = Cx$$
  

$$x = \begin{bmatrix} v_2 & v_1 & i_2 & i_1 \end{bmatrix}'$$



Figure 9.2: State space model of the Ćuk converter.

The state space matrices for the open-loop model from the disturbance input  $v_g$  to the output  $v_o$  are the state space averaged matrices  $\{A, B, C, D\}$ . The state space matrices for the open-loop system from the control input d to the output  $v_o$  are the state space averaged matrices  $\{A, B_d, C, D\}$ . Thus, the model of the Ćuk converter has two inputs (a control input d and a disturbance input  $v_q$ ) and one output  $(v_o)$ .

The MATLAB model open-loop response to a unit step disturbance in  $v_g$  is shown in Figure 9.3. By inspection of the plotted response, it was determined that the system reached lightly damped oscillations around a steady state DC value in approximately 20 ms. The steady state value was 26 V, a value predicted from the gain equation for the Ćuk converter:

$$v_o = \frac{D_s}{1 - D_s} v_g \tag{9.4}$$

With nominal duty cycle  $D_s = 0.667$ , a 1 V step input in  $v_g$  produces a 2 V step in the output voltage  $v_o$ . This shows that the open-loop system does not reject disturbances on the input voltage  $v_g$ . Also, note that the output of the circuit is a lightly damped sinusoid, with an approximate frequency of 1.83 kHz (11.5 krad/s).

The PECS circuit is shown in Figure 9.4. The simulator was set up to check the performance of the nonlinear converter in response to a unit step up in  $v_q$ .



Figure 9.3: Ćuk converter output voltage response to a unit step disturbance in  $v_g.$ 



Figure 9.4: The Ćuk converter simulated in PECS.

The PECS plot of these transients is shown in Figure 9.5. Comparison of the MATLAB and PECS plots reveals that the linear model used in MATLAB is an acceptable model of the plant to use for control system design.



Figure 9.5: Unit step response of the Ćuk converter in PECS.

The pole-zero plot of  $T_{v_od}$  is shown in Figure 9.6. All poles and zeros are in the LHP, therefore the Ćuk converter is a stable minimum-phase system. The locations for the zeros and poles are:

where the zeroes and poles have units of rad/s. The 1.83 kHz ringing in the output transient caused by the unit step disturbance is due to the frequency associated with the dominant pole pair at  $-40 \pm j11500$  rad/s.



Figure 9.6: Map of the pole and zero locations of  $T_{v_a v_a}$ .

#### 9.4 Controllability and Stabilizability

The idea of controllability refers to the ability of the input control u to affect the system dynamics. Controllability is defined as the ability to move the state of a system from an initial value  $x_0$  to any arbitrary state  $x_f$  within a finite time period t using the input signal u. (Note that controllability says nothing about the magnitude of the input signal u, i.e., the control effort, nor the time t required to accomplish this transition.) Essentially, it is a test to determine if the closed-loop system poles may be arbitrarily placed in the complex plane.

The controllability matrix  $M_c$  is constructed from (A, B) in the following manner:

$$M_c = \begin{bmatrix} B & AB & A^2B & \dots & A^{n-1}B \end{bmatrix}$$
(9.5)

where n is the order of the system. If  $M_c$  is a full rank matrix, the system is fully controllable. The rank deficiency of  $M_c$  tells the designer how many modes are uncontrollable. There is no rank deficiency in  $M_c$  for the Ćuk converter model, therefore the system is fully controllable.

#### 9.5 Observability and Detectability

Observability refers to the ability to determine any initial state  $x_0$  using only a finite record of the output y between an initial time and a final time. The observability matrix  $M_o$  is constructed from (A, C) in the following manner:

$$M_o = \begin{bmatrix} C \\ CA \\ CA^2 \\ \vdots \\ CA^{n-1} \end{bmatrix}$$
(9.6)

where n is the order of the system. If  $M_o$  is a full rank matrix, the system is fully observable. The rank deficiency of  $M_o$  tells the designer how many modes are unobservable. The Ćuk converter model is fully observable.

#### 9.6 Controlling the Cuk Converter

The model used in controller design is a small-signal model, since, like many other methods of linearization, the state-space averaging method only holds for small deviations from the nominal operating point. Most of the equations and figures that follow refer to deviations from the nominal operating point of the system unless otherwise stated or identifiable from context.

The control system designer must always begin with a set of design specifications when starting a project. The specifications are a set of goals for the behavior of the controlled system, and may need to change during the design process if not achievable or as new information becomes available. Specifications generally consider both transient behavior (e.g., rise time, settling time, percent overshoot) and stability margins (e.g., relative stability, gain margin, phase margin).

#### 9.6.1 Time Domain Specifications

Time domain constraints are given by the system performance specifications. The transient response of a regulated system is typically limited in terms of both maximum amplitude deviation from the nominal output and settling time in response to a transient. The goal for the Ćuk converter controller design example is to control the output voltage to within 1% of nominal (i.e., 23.76 to 24.24 V) in response to unit step voltage disturbances in the input. This matches the 1% regulation of standard industrial power supplies sold by a major control system equipment manufacturer. Also, the controller should be able to maintain the nominal output voltage within tolerances as the input varies over a range of 9 to 14 V, though this shall be considered a steady-state, not transient, operating requirement. As a final specification, steady-state error in the output voltage shall be eliminated within 20 milliseconds of the start of a transient.

#### 9.6.2 Frequency Domain Specifications

The frequency response of the transfer function  $T_{v_od}$  should be high at low frequencies for proper regulation and low at high frequencies for adequate noise

rejection. The example system base switching frequency is 100 kHz ( $6.28 \times 10^5$  rad/s). As the small signal model breaks down above half of the switching frequency, the loop gain at any frequency above 50 kHz ( $3.14 \times 10^5$  rad/s) should be less than 0 dB. Indeed, there should be a design margin left between this frequency and the gain crossover frequency. A gain margin of at least 20 dB and a phase margin of at least 50° will be sought to ensure stability.

#### 9.6.3 Control Effort Constraints

The Ćuk converter nominal duty cycle is related to the steady-state gain of the converter G by Equation 9.4. Neglecting circuit losses, Equation 9.4 may be rearranged to calculate the duty cycle as a function of the output operating point and input voltages,  $v_o$  and  $v_g$ :

$$D_s = \frac{v_o}{v_o + v_g} \tag{9.7}$$

Therefore, the nominal duty cycle at the operating point of 24 V for an input of 12 V is determined to be 0.667. However, the purpose of controller design is to ensure the output voltage remains within 1% of 24 V despite disturbances in the input voltage. Since a deviation model is used, the difference between the nominal operating duty cycle and the duty cycle required to keep the output at exactly 24 V may be approximated, and this is shown in Figure 9.7.



Figure 9.7: The small-signal duty cycle required over the full input voltage range to maintain nominal output voltage.

It is this change in duty cycle that the controller must provide, as the deviation in duty cycle is the small-signal control input of the Ćuk converter. Thus, it can be predicted from Equation 9.7 or Figure 9.7 that the the controller must change the duty cycle by -0.018 to maintain the output at 24 V for a step disturbance input on  $v_g$  from the nominal 12 V to 13 V. This value of -0.018 will be used to verify the correct steady-state control effort in controller design. (Note that Equation 9.7 does not account for any voltage losses within the circuit, so the duty cycle will actually be slightly higher from the calculated value when any resistances are included in the circuit.) The duty cycle is limited to  $0 \leq D_s \leq 1$ , therefore if the control effort plus the nominal value of 0.667 exceeds these limiting values, the compensator design is not acceptable. This leads to hard limits on the small-signal control effort of [-0.667, 0.333], though the inclusion of a design margin to these limits may be desirable. It is up to the individual designer to choose constraints on the control effort range as possible.

## 9.7 MATLAB Code

```
1 % SSA Model of Minimum-Phase Cuk Converter
2
3 % Define physical inputs
4 clear
5 close all
6
7 Vg = 12;
8 Vo = 24;
9 r = 28;
10 c1 = 2 \times 10^{-6};
11 c2 = 2 \times 10^{-5};
12 d = Vo/(Vg+Vo);
13 11 = 5 \times 10^{-4};
14 r1 = 0.01;
15 12 = 7.5×10<sup>-3</sup>;
16 r2 = 0.01;
17 m = -1.5 \times 10^{-3};
18
19 % Calculate state variables for each switch position
20 s2 = 11*12-m^2;
_{21} A1 = [-1/(r*c2) 0
                            1/c2
                                         0;
                   0
^{22}
         0
                             -1/c1
                                         0;
        -l1/s2 l1/s2 -l1*r2/s2 m*r1/s2;
m/s2 -m/s2 m*r2/s2 -l2*r1/s
23
                                         -l2*r1/s2];
24
25 B1= [0; 0; -m/s2; 12/s2];
26 B2 = B1;
27 A2 = [-1/(r*c2) 0]
                           1/c2
                                          0;
                           0
        0 0
                                         1/c1;
28
         -l1/s2 m/s2 -l1*r2/s2 m*r1/s2;
29
        m/s2
                  -12/s2 m*r2/s2
                                         -12*r1/s2];
30
31 C1 = [1 0 0 0];
32 C2 = C1;
33 D = 0;
34
35 % Calculate combined state variables given duty cycle d
36 d1 = 1-d;
37 A = d*A1+d1*A2;
38 B = d \cdot B1 + d1 \cdot B2;
39 C = d \cdot C1 + d1 \cdot C2;
40
41 % Calculate B matrix for control input - Bd
42 X = -A^{-1}*B*Vg;
43 Bd = (A1-A2) *X;
^{44}
_{45}\, % Define the state space model from vg to vo
46 SYS = ss(A, B, C, D);
47
48 % Define the state space model from d to vo
49 SYSd = ss(A, Bd, C, D);
50
_{51} % Unit step response from disturbance input vg to vo
52 figure;
53 [y t] = step(SYS, 0.03);
```

```
54 plot(t, Vo+y);
ss xlabel('Time (s)');
56 ylabel('Amplitude (V)');
57 grid on
58
59 % Pole-zero map from d to vo
60 figure;
61 pzmap(SYSd);
62 h = gcr;
63 h.AxesGrid.TitleStyle.FontSize = 10;
64 h.AxesGrid.XLabelStyle.FontSize = 10;
65 h.AxesGrid.YLabelStyle.FontSize = 10;
66 grid on
67
68 % Open-loop Bode Plot from d to vo
69 figure;
70 margin(SYSd);
71 h = gcr;
72 h.AxesGrid.Xunits = 'Hz';
73 h.AxesGrid.TitleStyle.FontSize = 10;
74 h.AxesGrid.XLabelStyle.FontSize = 10;
75 h.AxesGrid.YLabelStyle.FontSize = 10;
76
77 clear A1 A2 B1 B2 C1 C2% X s2 r c1 c2 l1 l2 m d1
```

```
1 % Duty Cycle vs. Vg for Cuk Converter
2
3 % Define the plant using an external file
4 cuk_parameters;
5
6 % Define the range of input voltage to sweep
7 vg = 9:0.01:14;
8
9 d_new = Vo./(vg + Vo);
10 \Delta_d = d_{new-d};
11
12 % Plot change in duty cycle as vg is swept to keep Vo at 24 V
13 figure;
14 plot(vg, Δ_d);
15 xlabel('Input Voltage (V)');
16 ylabel('\Delta Duty Cycle');
17 axis([9 14 -0.04 0.08]);
18 grid on
19
_{\rm 20}~ % Plot duty cycle as vg is swept to keep Vo at 24 V
21 figure;
22 plot(vg, d_new);
23 xlabel('Input Voltage (V)');
24 ylabel('Duty Cycle');
25 axis([9 14 0.62 0.74]);
26 grid on
```

# References

 G. C. Verghese, "Dynamic modeling and control in power electronics," in *The Control Handbook*, W. S. Levine, Ed. Boca Raton, FL: CRC Press LLC, 1996, ch. 78.1, pp. 1413–1424.

REFERENCES

## Chapter 10

# **Pole Placement**

For a system that is completely controllable and where all the states are accessible, feedback of all of the states through a gain matrix can be used to place the poles at any desired location in the complex plane. The control law used for state feedback is:

$$u = -Kx \tag{10.1}$$

which uses the matrix K to place the poles of the system at desired locations [1]. This type of compensator is said to employ full state feedback (FSFB). A FSFB regulator is shown in Figure 10.1.



Figure 10.1: State feedback regulation.

#### 10.1 Pole Placement via Ackermann's Formula

Ackermann's formula may be used with single-input, single-output (SISO) systems like the Ćuk converter. Ackermann's formula is:

$$K = \begin{bmatrix} 0 & 0 & \dots & 1 \end{bmatrix} M_c^{-1} (A^n + \alpha_1 A^{n-1} + \dots + \alpha_{n-1} A + \alpha_n I) \quad (10.2)$$

This method of determining K may be used with the system in any representation. It is this method of pole placement that is used in the designs of the state feedback controllers that follow.

### 10.2 Cuk Converter with State Feedback Compensator

One problem with pole placement is how to go about selecting desirable pole locations. Two main methods of design are commonly followed [2]:

- Select pole locations such that a dominant complex pole pair exists. This technique is generally used when designing tracking systems, for which the transient time domain requirements (e.g., rise time, overshoot, settling time, etc.) are able to be recast into desired dominant pole locations.
- Select pole locations that have been determined to give a prototype timedomain response, e.g., filter pole locations.

The latter method is used in this chapter for pole placement with full state feedback control.

Graham and Lathrop [3] discuss assigning the system poles of higher-order systems to prototype locations that minimizes a performance index (or cost function) known as the integral of the time-weighted absolute error (ITAE) to an input signal:

$$J_{ITAE} = \int_0^\infty t \left| e(t) \right| dt \tag{10.3}$$

By placing poles in an ITAE filter pattern to minimize  $J_{ITAE}$ , the designer achieves a response that is optimized with respect to deviation from setpoint (provided by the absolute error) and settling time (errors that occur later in the time history contribute more to the  $J_{ITAE}$  cost). Since the goal of the control system designer is to regulate the Ćuk converter output voltage with respect to input voltage disturbances,  $J_{ITAE}$  provides a scalar figure of merit by which to judge controller performance. For regulator problems, the desired output is rejection of disturbance deviations from the nominal operating point. The error between the desired output and the plant output is defined as e(t) = r(t) - y(t). Since r(t) = 0 for all time t in a regulator problem, the error e(t) is simply -y(t).

#### 10.2. CUK CONVERTER WITH STATE FEEDBACK COMPENSATOR191

The frequency-normalized pole locations for minimum ITAE response are given in Table 10.1 up through order five (so that a full-order state feedback controller with an integrator may be applied to the Ćuk converter), where  $\omega$ is a multiplier that multiplies each pole location in the array of poles listed to convert from frequency-normalized pole locations to desired pole locations<sup>1</sup>. The frequency multiplier  $\omega$  moves the poles outward along radii extending from the origin of the complex plane since it multiplies each real and complex value in a given pole by the same amount, increasing the natural frequency of each pole. The control system designer must determine the value of  $\omega$  that places the poles in such a way as to achieve the desired time domain response. A computer program (e.g., MATLAB from The Mathworks with the Control Systems Toolbox) can be used to iteratively design and test state feedback controllers over a range of values for the scalar multiplier frequency  $\omega$  using a simple search algorithm. where all pole values are in rad/s. By using the steady state error

Table 10.1: Frequency-Normalized Pole Locations for ITAE Response

Order	Factored Pole Locations with Multiplier
1	$\omega[-1]$
2	$\omega[-0.7071 \pm j0.7071]$
3	$\omega[-0.7081, -0.521 \pm j1.068]$
4	$\omega[-0.424 \pm j1.263, -0.626 \pm j0.4141]$
5	$\omega[-0.8955, -0.3764 \pm j1.292, -0.5758 \pm j0.5339]$

as a measurement metric for each iteration during the design, m can be chosen that produces a steady state error within the performance specification of 1%. Figure 10.2 shows a plot of steady-state error vs.  $\omega$ , and this figure was used to select a value of  $\omega$  that corresponded to 0.24 V (1% voltage regulation). Initially, a wide range of frequencies was selected with a large increment, then the range and the increment were made smaller in order to narrow in on the first frequency with less than 0.24 V of steady state error, which occurs at  $\omega$ = 10115. This prevents moving the poles farther into the left half of the complex plane than necessary to achieve the desired performance. Moving poles too far results in increases in control effort that may see the control effort hit a saturation limit in actual systems, e.g., if the duty cycle were to try to go below 0 or above 1, it could not. The unit step disturbance response of the system with a full state feedback controller designed in this manner is shown in Figure 10.3. Note that there is no more than 0.24 V of maximum error to the 1 V step disturbance in input voltage, indicating that the disturbance is rejected to within the performance specifications. The amplitude and settling time of the transient meet design specifications, so this controller has very desirable time-domain response characteristics. The loop gain of the regulated system is

<sup>&</sup>lt;sup>1</sup>Frequency-normalization in this case refers to the fact that the minimum natural frequency given by the pole locations for any of the *nth*-order set of poles listed (without the frequency multiplier  $\omega$ ) is equal to 1 rad/s



Figure 10.2: Maximum absolute error of unit step disturbance as frequency multiplier is swept.



Figure 10.3: Response to unit step disturbance of input voltage.

#### 10.2. ĆUK CONVERTER WITH STATE FEEDBACK COMPENSATOR193

shown in Figure 10.4, where the loop is broken at the large X shown on the control input d in Figure 10.5.



Figure 10.4: Loop gain with the full state feedback controller.



Figure 10.5: The full state feedback controller applied to the Ćuk converter.

MATLAB calculations give the gain margin as  $\infty$  and a phase margin of 66.7°, which are very desirable frequency-domain response characteristics.

Finally, the control effort of the design should be examined. Once again, the control input to the Ćuk converter is the change in duty cycle d used to turn on and off Q1. The control effort is plotted in Figure 10.6, and it can be seen that the effort is not approaching the limits assigned to d.



Figure 10.6: Control effort with the full state feedback controller.

It can also be seen that the steady-state deviation control effort is approximately -0.0163, which corresponds roughly to calculations using Equation 9.7.

### 10.3 MATLAB Code

```
1 % Full State Feedback Compensator
2
3 % Define the plant using an external file
4 cuk_parameters;
5
6 % Define ITAE normalized pole positions
7 ITAE_4 = [-0.4240+1.2360i, -0.4240-1.2360i, ...
8 -0.6260+0.4141i, -0.6260-0.4141i];
9
10 % Sweep scaling multiplier and find first multiplier that gives ...
       max abs error
11 ~\% \leq 0.24 ~V
w0 = [10000:1:10200];
13 w0_length = length(w0);
14 maxerr = zeros(size(w0));
15
16 wb = waitbar(0,'Sweeping ITAE Filter Scaling Multiplier...');
17
18 for index = 1:length(w0);
19
       P = w0(index) * ITAE_4;
       k = place(A, Bd, P);
^{20}
^{21}
       Abar = [A-Bd \star k];
       SYS1 = ss(Abar, B, C, D);
22
       [y t] = step(SYS1, 0.003);
^{23}
       maxerr(index) = max(abs(y));
^{24}
25
       waitbar(index/w0_length, wb)
26 end
27 close(wb);
^{28}
29 % Plot the maximum absolute error as a function of the frequency ...
       multiplier
30 figure;
31 h = plot(w0,maxerr);
32 xlabel('Frequency Multiplier \omega');
33 ylabel('Maximum Absolute Error (V)');
34 grid on
35
36 % Determine vector of scaling values that results in max abs ...
       error \leq 0.24 V
z = find(maxerr \le 0.24);
   % Select first element in that vector to use as scaling function
38
w = w0(z(1,1));
40 sprintf('ITAE pole scaling multiplier selected, FSFB: %4.0f',w)
41
42 % Use first scaling frequency with steady state error \leq 0.24 to ...
       scale the
43 % ITAE filter pole positions
44 P = w * ITAE_4;
45 k = place(A, Bd, P);
46 Abar = [A-Bd \star k];
47 SYS_FSFB = ss(Abar, B, C, D);
48
49 % Plot closed-loop system response to a unit step disturbance input
```

```
50 [y t x] = step(SYS_FSFB, 0.002);
51 figure;
52 plot(t, Vo+y);
ss xlabel('Time (s)');
54 ylabel('Amplitude (V)');
55 grid on
56
57 % System Loop Gain Plot
58 figure;
59 margin(A, Bd, k, 0);
60 h = gcr;
61 h.AxesGrid.TitleStyle.FontSize = 10;
62 h.AxesGrid.XLabelStyle.FontSize = 10;
63 h.AxesGrid.YLabelStyle.FontSize = 10;
64
65 % Control Effort Plot
66 figure;
67 plot(t, -k*x'+d);
68 xlabel('Time (s)');
69 ylabel('Duty Cycle');
70 grid on
```

# References

- R. T. Stefani, B. Shahian, C. J. Savant, Jr., and G. H. Hostetter, *Design of Feedback Control Systems*, 4th ed. New York, NY: Oxford University Press, 2002.
- [2] G. F. Franklin, J. D. Powell, and A. Emami-Naeini, Feedback Control of Dynamic Systems, 3rd ed. Boston, MA: Addison-Wesley, 1993.
- [3] D. Graham and R. C. Lathrop, "The synthesis of optimum transient response: Criteria and standard forms," *Trans. AIEE*, vol. 72, pp. 273–288, Nov. 1953.

REFERENCES

## Chapter 11

# Integral Action

The previous state feedback design for the Ćuk converter resulted in a maximum error of 0.24 V of due to the 1 V disturbance in input voltage, which is just within design specifications. The steady state error was 0.22 V. Additional gain could reduce this error, though it could never be eliminated, as the Ćuk converter is a type 0 system, which means that there will always be some finite steady-state error to a unit step disturbance or setpoint change, even in a controlled system, no matter how high the gain. However, it is desirable to eliminate steady-state error to the unit step entirely if possible. The only way to do this is to have the controller raise the type number<sup>1</sup>. Full state feedback does not introduce an integrator into the closed loop, therefore does not change the type number.

### 11.1 Adding Integrators

In order to eliminate any steady-state offset that may occur, an integrating controller may be added to the controlled system. Integral control is a method of output feedback, as shown in Figure 11.1.

<sup>&</sup>lt;sup>1</sup>The concept of type number goes hand-in-hand with the internal model principle, which states that a loop must contain a transfer function that has a model of the signal it is trying to reject. For example, if trying to reject a unit step  $\frac{1}{s}$ , at least one transfer function in the loop must contain  $\frac{1}{s}$ .



Figure 11.1: Generic system controlled with a FSFB regulator and output integral feedback.

The integrating controller integrates the error between any reference signal and the output e(t) = r(t) - y(t) and adds it to the state feedback control effort to eliminate steady-state error. The equation for the integrator is  $x_i = \int edt$ , or  $\dot{x}_i = e$ . Since each row in the state space representation is a first-order linear differential equation, and the integrator adds one new differential equation to the system  $\dot{x}_i = -y = -Cx$ , one new state  $x_i$  must be added to the state vector to raise the Ćuk system from type 0 to type 1. The augmented state vector is  $[x x_i]'$  and the new state space quadruple is:

$$A = \begin{bmatrix} A & 0 \\ -C & 0 \end{bmatrix}$$

$$B = \begin{bmatrix} B & 0 \end{bmatrix}'$$

$$C = \begin{bmatrix} C & 0 \end{bmatrix}$$

$$D = 0$$
(11.1)

The control law for this augmented system is  $u = -kx - k_i x_i$ . From the above modifications, the desired poles (with an added desired closed-loop pole location to account for the pole associated with the integrator) can be used to determine the state feedback gain, which has the structure  $K = [k \ k_i]$ .

## 11.2 Ćuk Converter with State Feedback and Integral Compensator

The augmented controlled system of the Ćuk converter is shown in Figure 11.2. This control method is described as full state feedback with an integrator (FSFBI).



Figure 11.2: System controlled with a FSFBI regulator.

The state quadruple for the system augmented with the new state and controlled with the new control law may be derived from the block diagram.

$$\dot{x} = (A - B_d k) x - B_d k_i x_i + B v_g$$

$$v_o = C x$$
(11.2)

along with the augmented closed-loop state space matrices

$$\bar{A} = \begin{bmatrix} A - B_d k & -B_d k_i \\ -C & 0 \end{bmatrix}$$
(11.3)  
$$\bar{B} = \begin{bmatrix} B & 0 \end{bmatrix}'$$
  
$$\bar{C} = \begin{bmatrix} C & 0 \end{bmatrix}$$
  
$$\bar{D} = \begin{bmatrix} D \end{bmatrix}$$

The controlled system then becomes:

$$\dot{x} = \bar{A}x + \bar{B}v_g$$
 (11.4)  
 $v_o = \bar{C}x$ 

A frequency-sweep search technique similar to that used for the FSFB controller was used to determine the pole placement for the system augmented with an integrator, and the results are shown in Figure 11.3. The frequency multiplier was swept and the first frequency multiplier value with a maximum absolute error determined to occur at  $\omega = 7536$ .



Figure 11.3: ITAE pole frequency multiplier determination.

The step disturbance transient is shown in Figure 11.4.



Figure 11.4: Unit step disturbance response of system with FSFBI controller.

The loop gain of the controlled system may be seen in Figure 11.5, where the loop is broken at the large X shown on the control input d in Figure 11.2. MATLAB calculations give the gain margin as  $\infty$  and a phase margin of 77.5°.



Figure 11.5: Loop gain of Ćuk converter controlled by FSFBI.

Figure 11.6 shows the change in duty cycle effected by the FSFBI controller

to control the Ćuk converter. Note that the final value of the control effort is -0.018. This is the approximate change in duty cycle that is necessary to completely reject the unit step disturbance in  $v_q$  as shown in Figure 9.7.



Figure 11.6: Control effort of FSFBI compensator.

From this point forward in this paper, all of the example compensator designs will include an integrator term to completely reject the effects of the step disturbance in  $v_g$ , and though sometimes not explicitly stated in the compensator name, terms related to the integrator will appear in the state equations as well as the block diagrams relating to control of the Ćuk converter.

### 11.3 MATLAB Code

```
1 % Full State Feedback Compensator with Integration
2
3 % Define the plant using an external file
4 cuk_parameters;
5
6 % Define ITAE normalized pole positions
7 ITAE_5 = [-0.8955, -0.3764+1.2920i, -0.3764-1.2920i,...
8 -0.5758+0.5339i, -0.5758-0.5339i];
9
10 % Sweep scaling multiplier and find first multiplier that gives ...
       max error
11 ~\% \leq 0.24 ~V
w0 = [7500:1:7600];
13 w0_length = length(w0);
14 maxerr = zeros(size(w0));
15
16 wb = waitbar(0,'Sweeping ITAE Filter Scaling Multiplier...');
17
18 for index = 1:length(w0);
19
       P = w0(index) * ITAE_5;
       A_prime = [A zeros(size(B)); C zeros(size(D))];
^{20}
       Bd_prime = [Bd; 0];
21
       K = place(A_prime,Bd_prime,P);
22
       k = K(1:4);
^{23}
       ki = K(end);
^{24}
       Abar = [A-Bd*k, -Bd*ki; C, 0];
^{25}
       Bbar = [B; 0];
^{26}
       Cbar = [C 0];
27
       SYS1 = ss(Abar,Bbar,Cbar,D);
^{28}
29
       [y t] = step(SYS1,0.005);
30
       maxerr(index) = max(abs(y));
^{31}
       waitbar(index/w0_length, wb)
32 end
33
34 close(wb);
35
_{36}\, % Plot the maximum absolute error as a function of the frequency \ldots
       multiplier
37 figure;
38 h = plot(w0,maxerr);
xlabel('Frequency Multiplier \omega');
40 ylabel('Maximum Absolute Error (V)');
41 grid on
^{42}
43 % Determine vector of scaling values that results in max error \leq ...
       0.24 V
44 z = find(maxerr \le 0.24);
45 % Select first element in that vector to use as scaling multiplier
46 W = WO(z(1,1));
47 sprintf('ITAE pole scaling multiplier selected, FSFBI: %4.0f',w)
^{48}
49 % Scale the ITAE filter pole positions
50 P = w * ITAE_5;
```

```
51 A_prime = [A zeros(size(B));-C zeros(size(D))];
52 Bd_prime = [Bd; 0];
53 K = place(A_prime,Bd_prime,P);
_{54} k = K(1:4);
55 ki = K(end);
56
57 Abar = [A-Bd*k, -Bd*ki; -C, 0];
58 Bbar = [B; 0];
59 Cbar = [C 0];
60 SYS_FSFBI = ss(Abar, Bbar, Cbar, D);
61
_{62}\, % Plot closed—loop system response to a unit step disturbance input
63 [y t x] = step(SYS_FSFBI, 0.002);
64 figure;
65 plot(t, Vo+y);
66 xlabel('Time (s)');
67 ylabel('Amplitude (V)');
68 grid on
69
70 % System Loop Gain Plot
71 figure;
72 margin(A_prime, Bd_prime, K, 0);
73 h = gcr;
74 h.AxesGrid.TitleStyle.FontSize = 10;
75 h.AxesGrid.XLabelStyle.FontSize = 10;
76 h.AxesGrid.YLabelStyle.FontSize = 10;
77
78 % Control Effort Plot
79 figure;
80 plot(t, -K*x'+d);
81 xlabel('Time (s)');
82 ylabel('Duty Cycle');
83 grid on
```

## Chapter 12

## State Estimation

Since an *n*-th order system requires *n* states be fed back to the gain matrix K to allow pole placement anywhere in the complex plane, this requires at least *n* measurements of the state variables. This can be prohibitively expensive or complex. In some cases, the internal system states may not even be measurable. In general, only the input and output of a system are available to the control system designer. However, if the system is fully observable, a state estimator (also known as an observer) may be used to provide estimated state values for use in feedback control. The use of an observer requires that the state estimates converge to the actual state values (if starting from different initial states) more rapidly than the system itself responds. The control law used is then:

$$u = -K\hat{x} \tag{12.1}$$

where  $\hat{x}$  indicates that the states fed back into the system are estimates.

In order to quickly force the state estimate to converge to the actual values of the state from arbitrary initial conditions, a correction term must be applied to the estimator dynamics such that the error dynamics approach zero rapidly.

#### 12.1 Full-Order State Estimators

A state estimator may be constructed from the same system state space model used for control law gain determination as long as the system is fully observable. The output of the estimator  $C\hat{x}$  can be compared to the output of the system, and any difference between them may be multiplied by a gain vector and fed back to the state estimator dynamics. Therefore:

$$e = y - C\hat{x}$$
(12.2)  
$$= C(x - \hat{x})$$

Multiplying this error by a gain vector L, the desired state error correction term is formed, which can then be added to the dynamics of the estimator to form:

$$\dot{\hat{x}} = A\hat{x} + Bu - LC(x - \hat{x})$$

$$= (A - LC)\hat{x} + Bu + LCx$$
(12.3)

When L is chosen such that the eigenvalues of A - LC lie in the left half of the complex plane, the estimator error  $e \to 0$  as  $t \to \infty$ . Since the state estimate must converge to the controlled state faster than the state itself can change, the eigenvalues of A - LC should be placed farther to the left than the eigenvalues of A - BK. A good rule of thumb is to make the estimator dynamics at least twice as fast as the controlled system dynamics.

To form an output feedback compensator based on an estimator, the separation principle of controller design holds, which states that the controller gain K and the observer gain L can be found independently. The proof of this is in many other references (e.g., [1]), so it shall not be repeated here, but application shall be made of the principle in the design examples to follow.

When paired with the linear state feedback control law, the estimator-based compensator is formed. For the case of state feedback without an integral state added, the compensator is given by:

$$\dot{\hat{x}} = (A - BK - LC)\hat{x} + Ly \qquad (12.4)$$
$$u = -K\hat{x}$$

Where the state of the system has been augmented by an integrator state, the compensator is given by:

$$\begin{bmatrix} \dot{\hat{x}} \\ \dot{x}_i \end{bmatrix} = \begin{bmatrix} A - Bk - LC & -Bk_i \\ 0 & 0 \end{bmatrix} \begin{bmatrix} \hat{x} \\ x_i \end{bmatrix} + \begin{bmatrix} L \\ -1 \end{bmatrix} y \quad (12.5)$$
$$u = \begin{bmatrix} -k & -k_i \end{bmatrix} \begin{bmatrix} \hat{x} \\ x_i \end{bmatrix}$$

#### 12.2 Full-Order Estimator-Based Compensator

The block diagram for the Ćuk converter controlled with a full-order state estimator with linear control law and integral action is shown in Figure 12.1, and was used to derive the following closed-loop state equations:

$$\dot{x} = Ax - B_d k \hat{x} - B_d k_i x_i + B v_g$$
(12.6)  

$$\dot{x}_i = -Cx$$
  

$$\dot{\hat{x}} = LCx - B_d k_i x_i + (A - B_d k - LC) \hat{x}$$
  

$$v_o = Cx$$
and the associated state space matrices:

$$\bar{A} = \begin{bmatrix} A & -B_d k_i & -B_d k \\ -C & 0 & 0 \\ LC & -B_d k_i & A - B_d k - LC \end{bmatrix}$$
(12.7)  
$$\bar{B} = \begin{bmatrix} B & 0 & 0 \end{bmatrix}'$$
  
$$\bar{C} = \begin{bmatrix} C & 0 & 0 \end{bmatrix}$$
  
$$\bar{D} = \begin{bmatrix} D \end{bmatrix}$$



Figure 12.1: An estimated state feedback compensator with integral action.

The step disturbance transient is shown in Figure 12.2. There is more oscillatory behavior in the initial part of the transient response compared to the response under FSFBI control. This is likely caused by the initial estimation of states and their convergence to the actual state values. Comparison of the settling times shows that they are approximately the same, and the only transient differences occur early in the transient.



Figure 12.2: Unit step disturbance response of Ćuk converter with ESFBI compensator.

The loop gain of the controlled system may be seen in Figure 12.3, where the loop is broken at the large X shown on the control input d in Figure 12.1. MATLAB calculations give the gain margin as 5.97 dB and a phase margin of 26.3°. These are significantly lower than the stability margins of previous controllers designed, and these clearly do not meet the design specifications.



Figure 12.3: Loop gain of Ćuk converter controlled by ESFBI compensator.

Figure 12.4 shows the control effort of the ESFBI controller.



Figure 12.4: Control effort of ESFBI compensator.

Since the Ćuk converter has four states, the observer itself will be a fourthorder system. Along with the integral state, the compensator becomes a fifthorder system. When evaluating desired observer pole locations, keep in mind that the poles of the observer must be placed to the left of the poles of the compensated plant by a large margin to ensure that the state estimator dynamics are faster than those of the plant. Similarly to the use of fifth-order ITAE pole locations for the plant under state feedback, fourth-order ITAE pole locations may be used to place the poles of the observer. However, examination of the frequency-normalized fifth-order and fourth-order ITAE pole locations from Table 10.1 shows that the fifth-order poles have a minimum pole frequency greater than the maximum pole frequency of the fourth-order poles. Thus, if the designer intends to place the all of the fourth-order ITAE observer poles to the left of the fifth-order ITAE pole locations selected using  $\omega$  by at least a factor of n, the designer must scale the fourth-order pole locations such that the lowest pole frequency of the fourth-order system must be first moved out to the largest pole frequency of the fifth-order system. This can be done by multiplying the fourth-order frequency-normalized poles by the ratio of the maximum pole frequency of the fifth-order poles to the minimum pole frequency of the fourth-order poles. The resulting fourth-order pole locations can then each be multiplied by n to move them radially by a factor of n farther into the left half of the complex plane than the fifth-order normalized pole locations, then they can be multiplied by the value of  $\omega$  used to select the desired fifth-order pole locations. Thus, the desired fourth-order pole locations have been deteremined.

#### **12.3** Reduced-Order State Estimators

If some of the states appear directly in the output as a function of the measurement equation (i.e., are not a linear combination of other states), those states do not need to be estimated. Hence, a reduced-order estimator may be constructed that only estimates the unmeasured states.

If C is a full rank matrix, a nonsingular linear transformation matrix can be formed by choosing a matrix T of dimension  $(n - r) \ge n$  and forming:

$$P = \begin{bmatrix} C \\ T \end{bmatrix}$$
(12.8)

The matrix T may be any arbitrary matrix that produces a nonsingular P matrix, as P must be invertible.

Applying the standard linear transformation x = Px with Equation (12.8) puts the system into an equivalent representation where C is of the form:

$$I_r \quad 0 \tag{12.9}$$

(I is a square identity matrix with dimension  $r \ge r$ , r < n). It can be assumed that this representation exists without loss of generality since it is the result of a linear transformation.

The system and feedback gain matrix can now be partitioned into measured

and unmeasured portions:

$$\begin{bmatrix} \dot{x}_m \\ \dot{x}_u \end{bmatrix} = \begin{bmatrix} A_{11} & A_{12} \\ A_{21} & A_{22} \end{bmatrix} \begin{bmatrix} x_m \\ x_u \end{bmatrix} + \begin{bmatrix} B_1 \\ B_2 \end{bmatrix} u \qquad (12.10)$$
$$\begin{array}{c} y = x_m \\ K = [k_m k_u] \end{array}$$

Since  $x_m$  corresponds to the states that appear in the output of the measurement equation,  $x_u$  represents the remaining unmeasured states. As  $x_m$  is present in the output, these states do not require estimation. This means that a reduced-order state estimator can be constructed that allows the estimation of  $x_u$  in such a manner that all states (either measured or estimated) are available for feedback via a linear control law:

$$u = -k_m x_m - k_u \hat{x}_u \tag{12.11}$$

In order to ensure that the reduced-order observer dynamics converge to the true state values of x, the error dynamics must converge to zero. A full-order observer uses a correction term to perform this, which is a gain matrix that multiplies the error between plant output and observer output. Unfortunately, since only the  $x_m$  states appear in the plant output, using the plant output contributes no information about the unmeasured states to the estimator and therefore has no dynamic effect on the estimate  $\hat{x}_u$ . However, a variable change can be performed:

$$\hat{x}_u = Ly + z \tag{12.12}$$

where z is the output of a system of order r < n:

$$\dot{z} = Ez + Fy + Gu \tag{12.13}$$

with E, F, and G and the observer gain L yet to be determined.

Since observer design is concerned with elimination of the error between the actual state and its estimate, the estimation error can be defined as  $e_u = x_u - \hat{x}_u$  and the error dynamics will converge to zero if  $\hat{x}_u \to x_u$ .

Using the partitioned format of  $x_u$  from Equation 12.10 along with  $\hat{x}_u$  determined from the block diagram in Figure 12.5, it can be shown that:

$$\hat{x}_u = L(A_{11}x_m + A_{12}x_u + B_1u) + E(\hat{x}_u - Lx_m) + Fx_m + Gu(12.14)$$

$$\hat{x}_u = A_{21}x_m + A_{22}x_u + B_2u$$



Figure 12.5: Reduced-order estimator construction.

Adding zero to the right side of  $\dot{x}_u$  in the form of  $Ex_u - Ex_u$ :

$$\dot{x}_u = (LA_{11} - EL + F)x_m + (LA_{12} + E)x_u \dots$$

$$+ (LB_1 + G)u + E(x_u - \hat{x}_u)$$
(12.15)

This gives the following equation for the estimator error dynamics when substituted into the time derivative of the unmeasured error  $\dot{e}_u = \dot{x}_u - \dot{x}_u$ :

$$\dot{e}_u = (A_{21} - LA_{11} + EL - F)x_m + (A_{22} - LA_{12} - E)x_u \dots (12.16) + (B_2 - LB_1 - G)u + Ee_u$$

In order for the estimator error dynamics to be independent of the state x, plant output y, and the input u, the first three terms on the right side of Equation 12.16 must be zero. This is accomplished by selecting:

$$E = A_{22} - LA_{12}$$
(12.17)  

$$F = A_{21} - LA_{11} + EL$$
  

$$G = B_2 - LB_1$$

This leaves  $\dot{e}_u = Ee_u$ , which converges to zero when E is an asymptotically stable matrix. Thus, the error dynamics die out, leaving an estimate that equals the state. This means that L must be selected such that  $A_{22} - LA_{12} \rightarrow 0$  as  $t \rightarrow \infty$ , i.e., the poles of E must lie in the left half of the complex plant. As with the full-order observer, the reduced-order observer poles should be placed such that the estimator dynamics are much more rapid than the controlled plant dynamics. When paired with the properly-partitioned linear state feedback control law, the reduced-order estimator-based compensator is formed. For the case of state feedback without an integral state added, the reduced-order compensator is given by:

$$\dot{z} = (E - Gk_u)z + (F - Gk_uL - Gk_m)y$$
(12.18)  
$$u = -k_uz + (-k_uL - k_m)y$$

Where the state of the system has been augmented by an integrator state, the reduced-order compensator is given by:

$$\begin{bmatrix} \dot{z} \\ \dot{x}_i \end{bmatrix} = \begin{bmatrix} E - Gk_u & -Gki \\ 0 & 0 \end{bmatrix} \begin{bmatrix} z \\ x_i \end{bmatrix} + \begin{bmatrix} F - Gk_u L - Gk_m \\ -1 \end{bmatrix} y \quad (12.19)$$
$$u = \begin{bmatrix} -k_u & -k_i \end{bmatrix} \begin{bmatrix} z \\ x_i \end{bmatrix} + (-k_u L - k_m) y$$

## 12.4 Reduced-Order Estimator-Based Compensator

For the Ćuk converter model, matrix C is of the form  $C = \begin{bmatrix} I & 0 \end{bmatrix}$  therefore  $v_2$  is a measured state, and the unmeasured states are  $v_1$ ,  $i_2$ , and  $i_1$ . This means that a reduced order observer may be designed that estimates only the three unmeasured states. The block model for a system controlled by a compensator made of a reduced-order estimator and a linear state feedback law is shown in Figure 12.6, and was used to derive the following state equations:

$$\dot{x} = (A - B_d k_u LC - B_d k_m C) x - B_d k_i x_i - B_d k_u z + B v_g \quad (12.20)$$
  

$$\dot{x}_i = -Cx$$
  

$$\dot{z} = (FC - Gk_m C - Gk_u LC) x - Gk_i x_i + (D - Gk_u) z$$
  

$$v_o = Cx$$

from which were determined the matrices:

$$\bar{A} = \begin{bmatrix} A - B_d k_m C - B_d k_u L C & -B_d k_i & -B_d k_u \\ -C & 0 & 0 \\ F C - G k_m C - G k_u L C & -G k_i & E - G k_u \end{bmatrix}$$
(12.21)  
$$\bar{B} = \begin{bmatrix} B & 0 & 0 \end{bmatrix}'$$
  
$$\bar{C} = \begin{bmatrix} C & 0 & 0 \end{bmatrix}$$
  
$$\bar{D} = \begin{bmatrix} D \end{bmatrix}$$

where

$$E = A_{22} - LA_{12}$$
(12.22)  

$$F = EL + A_{21} - LA_{11}$$
  

$$G = B_{d_2} - LB_{d_1}$$



Figure 12.6: A state feedback regulator with integral action based on a reduced-order estimator.

To determine estimator pole placement, the same type of iterative algorithm used for the full-order observer was implemented. The reduced-order observer poles were placed to have faster dynamics than the poles of the controlled system.

The step disturbance transient is shown in Figure 12.7.



Figure 12.7: Unit step disturbance response of Ćuk converter with ROESFBI compensator.

The loop gain of the controlled system may be seen in Figure 12.8, where the loop is broken at the large X shown on the control input d in Figure 12.6. MATLAB calculations give the gain margin as -24.9 dB and a phase margin of  $36.5^{\circ}$ . These clearly do not meet the design specifications, and uncertainty in the system model may make the controlled system unstable.



Figure 12.8: Loop gain of Ćuk converter controlled by ROESFBI compensator.

### 12.5 MATLAB Code

```
1 % Estimated State Feedback Compensator with Integration
2
3 % Define the plant using an external file
4 cuk_parameters;
5
6 % Define ITAE normalized pole positions
7 ITAE_5 = [-0.8955, -0.3764+1.2920i, -0.3764-1.2920i,...
8 -0.5758+0.5339i, -0.5758-0.5339i];
9 ITAE_4 = [-0.4240+1.2360i, -0.4240-1.2360i, ...
10 -0.6260+0.4141i, -0.6260-0.4141i];
11
12 % Find the ratio of the maximum natural frequency of a normalized
13 % fifth-order ITAE filter to the minimum natural frequency of a
14 % normalized fourth-order ITAE filter.
15
16 ra54 = max(abs(ITAE_5))/min(abs(ITAE_4));
17
_{18}\, % Define the desired ratio of the minimum natural frequency of the
19 % estimator poles to the maximum natural frequency of the ...
       controller poles
20 \text{ rra} = 3;
^{21}
22 % Sweep scaling multiplier and find first multiplier that gives ...
      max error
23 ~\% \leq 0.24 ~V
24 w0 = [5400:1:5600];
25 w0_length = length(w0);
26 err_ITAE = zeros(size(w0));
^{27}
28 wb = waitbar(0, 'Sweeping ITAE Filter Scaling Multiplier...');
  for index = 1:length(w0);
^{29}
30
       % Sweep frequency to scale the ITAE filter pole positions for
       % the controller
31
32
       Pk = w0(index) * ITAE_5;
33
34
       % Set the minimum natural frequency of the ITAE filter pole ...
           positions
35
       % for the estimator to a multiple of the maximum natural ...
           frequency of
       \% the controller poles to make the estimator converge faster \ldots
36
           than the
37
       % controller responds
38
       Pl = rra * ra54 * w0(index) * ITAE_4;
39
       A_prime = [A zeros(size(B));-C zeros(size(D))];
40
       Bd_prime = [Bd; 0];
C_prime = [C 0];
41
42
       K = place(A_prime,Bd_prime,Pk);
^{43}
44
       k = K(1:4);
       ki = K(end);
^{45}
       L = place(A', C', Pl)';
^{46}
       Abar = [A, -Bd*ki, -Bd*k;
47
^{48}
              -C, 0, zeros(1,length(A));
```

```
L*C, --Bd*ki, A--Bd*k--L*C];
49
        Bbar = [B; 0; zeros(4,1)];
50
        Cbar = [C \ 0 \ zeros(size(C))];
51
        SYS_ESFBI = ss(Abar,Bbar,Cbar,D);
52
        [y t] = step(SYS\_ESFBI, 0.003);
53
54
        maxerr(index) = max(abs(y));
        waitbar(index/w0_length, wb)
55
56 end
57 close(wb);
58
_{59}\, % Plot the maximum absolute error as a function of the frequency \ldots
       multiplier
60 figure;
61 plot(w0,maxerr);
62 axis tight
63 xlabel('Scalar Multiplier \omega');
64 ylabel('Maximum Error (V)');
65 grid on
66
_{67} % Determine vector of scaling values that results in max error \leq ...
       0.24 V
68 z = find(maxerr \le 0.24);
69 % Select first element in that vector to use as scaling multiplier
70 W = WO(z(1,1));
71 sprintf('ITAE pole scaling multiplier selected, ESFBI: %4.0f',w)
72
73 % Use frequency of minimum ITAE to scale the ITAE filter pole ...
       positions for
74 % the controller
75 Pk = w * ITAE_5;
76
77 % Set the minimum natural frequency of the ITAE filter pole ...
       positions for
78 % the estimator to a multiplier of the maximum natural frequency ...
       of the
79 % controller poles to make the estimator converge faster than the
80 % controller responds
81
82 Pl = rra * ra54 * w * ITAE_4;
83 A_prime = [A zeros(size(B));-C zeros(size(D))];
84 Bd_prime = [Bd; 0];
85 C_prime = [C 0];
86 K = place(A_prime,Bd_prime,Pk);
k = K(1:4);
88 ki = K(end);
89 L = place(A', C', Pl)';
90 Abar = [A, -Bd*ki, -Bd*k;
           -C, 0, zeros(1,length(A));
91
          L*C, -Bd*ki, A-Bd*k-L*C];
92
93 Bbar = [B; 0; zeros(4,1)];
94 Cbar = [C 0 zeros(size(C))];
95 SYS_ESFBI = ss(Abar, Bbar, Cbar, D);
96
97 % Plot controller poles and observer poles
98 figure;
99 plot(Pk, 'bx')
100 hold on
```

```
101 plot(Pl, 'r+')
102 hold off
103 legend('Controller poles', 'Observer poles')
104 xlabel('Real')
105 ylabel('Imaginary')
106 grid on
107
108 % Plot closed-loop system response to a unit step disturbance input
109 [y t x] = step(SYS_ESFBI, 0.002);
110 figure;
111 h = plot(t, Vo+y);
112 xlabel('Time (s)');
113 ylabel('Amplitude (V)');
114 grid on
115
116 figure;
117 plot(t, x);
118 xlabel('Time (s)');
119 ylabel('States');
120 grid on
121 legend('v_2','v_1','i_2','i_1','x_i','v_{2e}','v_{1e}', ...
122 'i_{2e}', 'i_{1e}', 'Location', 'SouthEast');
123
124 % System Loop Gain Plot
125 A1 = [A, zeros(4,1), zeros(4,4);
         -C, 0, zeros(1,4);
126
127
        L*C, --Bd*ki, A--Bd*k--L*C];
128 Bd1 = [Bd;0;zeros(4,1)];
129 C1 = [zeros(1,4), ki, k];
130 D1 = 0;
131 sys1 = ss(A1, Bd1, C1, D1);
132 figure(5);
133 margin(sys1)
134 h = qcr;
135 h.AxesGrid.Xunits = 'Hz';
136 h.AxesGrid.TitleStyle.FontSize = 10;
137 h.AxesGrid.XLabelStyle.FontSize = 10;
138 h.AxesGrid.YLabelStyle.FontSize = 10;
139
140 % Control Effort Plot
141 figure;
142 h = plot(t, -[zeros(1,4), ki, k]*x'+d);
143 xlabel('Time (s)');
144 ylabel('Duty Cycle');
145 grid on
```

```
1 % Reduced-Order Estimated State Feedback Compensator with ...
Integration
2
3 % Define the system using an external file
4 cuk_parameters;
5
6 % Partition the matrices for reduced-order estimator design
7 All = A(1,1);
8 Al2 = A(1,2:4);
9 A21 = A(2:4,1);
```

```
10 A22 = A(2:4,2:4);
11
12 B1 = B(1);
13 B2 = B(2:4);
14
15 Bd1 = Bd(1);
16 \quad Bd2 = Bd(2:4);
17
18 % Define ITAE normalized pole positions
19 ITAE_5 = [-0.8955, -0.3764+1.2920i, -0.3764-1.2920i, ...
20 -0.5758+0.5339i, -0.5758-0.5339i];
21 ITAE_3 = [-0.7081, -0.5210+1.068i, -0.5210-1.068i];
22
23 % Find the ratio of the maximum natural frequency of a normalized
24 % fifth-order ITAE filter to the minimum natural frequency of a
25 % normalized third-order ITAE filter.
26
27 ra53 = max(abs(ITAE_5))/min(abs(ITAE_3));
28
29 % Define the desired ratio of the minimum natural frequency of the
_{\rm 30}\, % estimator poles to the maximum natural frequency of the \ldots
      controller poles
31 rra = 2;
32
33 % Sweep scaling multiplier and find first multiplier that gives ...
       max error
34 % ≤ 0.24 V
35 w0 = [5700:1:5900];
36 w0_length = length(w0);
37 maxerr = zeros(size(w0));
38
39 wb = waitbar(0, 'Sweeping ITAE Filter Scaling Multiplier...');
40
41 for index = 1:length(w0);
        % Scale the controller pole positions using a search
^{42}
       Pk = w0(index) * ITAE_5;
43
^{44}
       \ensuremath{\$} Set the minimum natural frequency of the ITAE filter pole \ldots
45
           positions
^{46}
        % for the estimator to a multiple of the maximum natural ...
           frequency of
47
       % the controller poles to make the estimator converge faster ...
           than the
       % controller responds
^{48}
49
       Pl = rra * ra53 * w0(index) * ITAE_3;
50
       A_prime = [A zeros(size(B));-C zeros(size(D))];
51
       Bd_prime = [Bd; 0];
52
       C_{prime} = [C \ 0];
53
       K = place(A_prime,Bd_prime,Pk);
54
       km = K(1);
55
56
       ku = K(2:4);
       ki = K(end);
57
       L = place(A22', A12', Pl)';
58
59
       E = A22 - L \star A12;
60
       F = E \star L + A21 - L \star A11;
61
```

```
G = Bd2 - L \star Bd1;
62
63
        Abar = [A-Bd*km*C-Bd*ku*L*C, -Bd*ki, -Bd*ku;
64
65
               -C, zeros(1,4);
               F*C-G*km*C-G*ku*L*C, -G*ki, E-G*ku];
66
67
        Bbar = [B; 0; zeros(3,1)];
        Cbar = [C \ 0 \ zeros(1,3)];
68
69
        SYS1 = ss(Abar,Bbar,Cbar,D);
70
        [y t] = step(SYS1,0.003);
71
        maxerr(index) = max(abs(y));
72
        waitbar(index/w0_length, wb)
73 end
74 close(wb);
75
76 % Plot the maximum absolute error as a function of the frequency ...
       multiplier
77 figure;
78 plot(w0,maxerr);
79 axis tight
80 xlabel('Scalar Multiplier \omega');
s1 ylabel('Maximum Error (V)');
82 grid on
83
84 % Determine vector of scaling values that results in max error \leq ...
        0.24 V
s5 z = find(maxerr \le 0.24);
86 % Select first element in that vector to use as scaling multiplier
87 W = WO(z(1,1));
ss sprintf('ITAE pole scaling multiplier selected, ESFBI: %4.0f',w)
89
90 % Determine controller and observer gains
91 Pk = w * ITAE_5;
92
93 % Set the minimum natural frequency of the ITAE filter pole ...
        positions for
94 % the estimator to a multiplier of the maximum natural frequency ...
        of the
_{95}\, % controller poles to make the estimator converge faster than the
96 % controller responds
97
98 Pl = rra * ra53 * w * ITAE_3;
99 A_prime = [A zeros(size(B));-C zeros(size(D))];
100 Bd_prime = [Bd; 0];
101 C_prime = [C 0];
102 K = place(A_prime,Bd_prime,Pk);
103 km = K(1);
104 ku = K(2:4);
105 ki = K(end);
106 L = place(A22', A12', Pl)';
107
108 E = A22 - L \star A12;
109 F = E \star L + A21 - L \star A11;
110 G = Bd2 - L * Bd1;
111
112 Abar = [A-Bd*km*C-Bd*ku*L*C, -Bd*ki, -Bd*ku;
           -C, zeros(1,4);
113
            F*C-G*km*C-G*ku*L*C, -G*ki, E-G*ku];
114
```

```
115 Bbar = [B; 0; zeros(3,1)];
116 Cbar = [C 0 zeros(1,3)];
117 SYS_ROESFBI = ss(Abar, Bbar, Cbar, D);
118
119 % Plot controller and observer pole locations
120 figure;
121 plot(Pk, 'bx')
122 hold on
123 plot(Pl,'r+')
124 hold off
125 legend('Controller poles', 'Observer poles')
126 xlabel('Real')
127 ylabel('Imaginary')
128
129 % Plot closed-loop system response to a unit step input
130 [y t x] = step(SYS_ROESFBI, 0.003);
131 figure;
132 plot(t, Vo+y);
133 xlabel('Time (s)');
134 ylabel('Amplitude (V)');
135 grid on
136
137 % System Loop Gain Plot
138 A1 = [A, zeros(4,1), zeros(4,3);
139
         -C, 0, zeros(1,3);
        F*C-G*ku*L*C-G*km*C, -G*ki, E-G*ku];
140
141 Bd1 = [Bd; 0; zeros(3,1)];
142 C1 = [km*C+ku*L*C, ki, ku];
143 D = 0;
144 sys1 = ss(A1, Bd1, C1, D);
145 figure;
146 margin(sys1);
147 h = gcr;
148 h.AxesGrid.TitleStyle.FontSize = 10;
149 h.AxesGrid.XLabelStyle.FontSize = 10;
150 h.AxesGrid.YLabelStyle.FontSize = 10;
151
152 % Control Effort Plot
153 figure;
154 h = plot(t, -[km, zeros(1,3), ki, ku] * x'+d);
155 xlabel('Time (s)');
156 ylabel('Duty Cycle');
157 grid on
```

# References

R. T. Stefani, B. Shahian, C. J. Savant, Jr., and G. H. Hostetter, *Design of Feedback Control Systems*, 4th ed. New York, NY: Oxford University Press, 2002.

REFERENCES

# Chapter 13

# Linear Quadratic Optimal Control

Linear quadratic optimal control uses penalties on state transients x and control effort u to optimize system performance with respect to a figure of merit determined by a cost function. There is typically a classical trade-off designed into the cost function: one cannot have tight control over state transients with small control effort. In other words, small output transients require large controller gains (and therefore control effort). Additionally, quadratic forms are used to ensure that only the magnitude and not the sign of the transient contributes to the cost determined by the penalty function.

#### 13.1 Linear Quadratic Regulators

To optimally control state transients and control effort within performance specifications, a compensator is sought that seeks to provide a control effort u that minimizes a Lagrangian cost function:

$$J = \int_0^\infty (x^T Q x + u^T R u) dt \tag{13.1}$$

subject to the constraint of the state equation:

$$\dot{x} = Ax + Bu \tag{13.2}$$

This is known as the linear quadratic regulator (LQR) problem. The weight matrix Q is an  $n \times n$  positive semidefinite matrix (for a system with n states) that penalizes variation of the state from the desired state. The weight matrix R is an  $m \times m$  positive definite matrix that penalizes control effort. Solutions for the constrained optimal system can be found in [1], [2], and [3]. The well-published time invariant solution to this problem is:

$$K = R^{-1}B^T P \tag{13.3}$$

where P is the unique, symmetric, positive definite solution to the steady-state algebraic Riccati equation (ARE):

$$PA + A^T P - PBR^{-1}B^T P + Q = 0 (13.4)$$

The minimum value of the cost function is based on the initial state  $x_0$ , and is given by:

$$J_{min} = x_0^T P x_0 \tag{13.5}$$

The LQR designed for a SISO system can be shown to possess very desirable stability properties: it always has a gain margin between  $\{-6 \text{ dB}, \infty\}$  and a phase margin of at least 60°. However, it has a high frequency roll-off rate of only 20 dB per decade so the open loop frequency response shows susceptibility to high frequency noise.

Since the weight matrices Q and R are both included in the summation term within the cost function, it is really the relative size of the weights within each quadratic form which are important. Simple inspection of the cost function shows that multiplying both weight matrices by the same real constant (e.g.,  $\kappa$ ) will not affect their ratio. The multiplier  $\kappa$  may be factored out of the integral, thus returning the cost function to its original form. Thus, the problem of minimizing  $\kappa J$  becomes the same as minimizing J. Therefore, holding one weight matrix constant while varying either the individual elements or a scalar multiplier of the other is an acceptable technique for iterative design. It is good for the designer to maintain an understanding of the effects of manipulating individual weights, however. In general, raising the effective penalty a single state or control input by manipulating its individual weight will tighten the control over the variation in that parameter, however it may do so at the expense of larger variation in the other states or inputs.

#### 13.2 Cuk Converter with LQR Compensator

The fifth-order system formed by augmenting the Ćuk converter with an integral state requires that Q be a five-by-five matrix. To review, the state vector is  $[v_2 v_1 i_2 i_1 x_i]'$ , where  $x_i$  corresponds to the integral of the reference error e. Since the states have physical significance in this model, it is easy to see that each voltage, current, or error transient may be individually penalized using the diagonal elements of the Q matrix. As the objective of controlling the Ćuk converter is to regulate the output  $v_o = v_2$  in the face of disturbances to  $v_g$ , penalizing transients that occur on state  $v_2$  is a logical choice, as is penalizing the state  $x_i$  associated with the reference error integral as the integral of that error should be minimized to provide for good regulation. Hence, the Q matrix chosen for design of the LQR has two positive entries corresponding to the first  $(Q_{11})$  and last  $(Q_{55})$  entries along the diagonal to ensure it is positive semidefinite. The Ćuk converter has only a single control input, and for initial design R was set equal to 1 arbitrarily. If the control effort exceeds the limitations put on it

(refer to Section 9.6), the value of R may need to be increase to penalize the control effort.

After proceeding through an iterative process where  $Q_{11}$  and  $Q_{55}$  were varied with R fixed, a finalized design was determined. The step disturbance response of the controlled Ćuk converter is shown in Figure 13.1



Figure 13.1: Unit step disturbance response of the Ćuk converter controlled by LQR.

The loop gain of the controlled system is shown in Figure 13.2, where the loop is broken at the large X shown on the control input d.



Figure 13.2: Loop gain of Ćuk converter controlled by LQR compensator.

Figure 13.3 shows the control effort produced by the optimal controller.



Figure 13.3: LQR control effort.

Note that the time of the unit step disturbance transient with the LQR compensator was significantly longer than the settling times of the previously designed compensators. However, the amplitude deviation was significantly

smaller. This is an acceptable design tradeoff since the performance specifications were still met.

#### 13.3 Linear Quadratic Gaussian Regulators

The LQR problem requires that full state feedback be used. This is not always possible, as was discussed in Section 12. The Kalman-Bucy filter is the dual to the LQR problem; it forms an optimal state estimator in the presence of process and measurement noise for a system that is observable. The presence of noise introduces stochastic effects on the state trajectory, therefore, the optimal state estimator must deal with these stochastic effects appropriately by removing them. Since the process of removing noise from a signal is commonly known as filtering, the optimal observer became known as the Kalman filter, or Kalman-Bucy filter, after its creator(s). The Kalman filter is based on essentially the same mathematics as the LQR and, as such, has come to be known as a linear quadratic estimator (LQE). The cost function  $J_0$  that is minimized is the error variance between the state vector and its estimate. LQE calculates the solution to an ARE (which happens to be the error covariance) and uses it to determine L, the estimator gain vector, along the lines of the same equations given for the LQR gain K.  $Q_0$ , the covariance matrix of the process noise, and  $R_0$ , the covariance matrix of the sensor noise, have to be selected for optimal determination of the observer gain vector L.

When combined, the linear quadratic controller and estimator form a structure known as a linear quadratic Gaussian (LQG) compensator. Once the state variables have been estimated, they are fed back through the controller gain Kto close the loop. The separation principle previously mentioned still holds true for LQG design: the LQR and LQE problems can be solved independently via two algebraic Riccati equations.

Adding process disturbances and measurement noise to the state space system description results in:

$$\dot{x} = Ax + Bu + \omega$$

$$y = Cx + \nu$$
(13.6)

where  $\omega$  is the disturbance signal (typically modeled by Gaussian white noise of spectral density  $Q_0$ ) and  $\nu$  is additive measurement noise (Gaussian white noise, with spectral density  $R_0$ ). Note that the fact that neither  $\omega$  or  $\nu$  has a coefficient implies a coefficient of I, meaning each state and output has its own distinct noise [4]. The time invariant solution to the optimal estimator problem is then:

$$L = P_0 C^T R_0^{-1} \tag{13.7}$$

where P (known as the estimation error variance) is the unique, symmetric, positive definite solution to the steady-state algebraic Riccati equation:

$$AP_0 + P_0 A^T - P_0 C^T R_0^{-1} C P_0 + Q_0 = 0 (13.8)$$

Since the spectral density of the process and measurement noise in a system is typically unknown, designers frequently treat  $Q_0$  and  $R_0$  as additional design parameters that can be manipulated. The bandwidth of the open-loop system frequency response can be controlled using these matrices. This can allow reduction of the susceptibility of the controlled system to noise at higher frequencies.

### 13.4 Ćuk Converter with LQG Compensator

The unit step response of the Ćuk converter controlled by a LQG compensator is shown in Figure 13.4.



Figure 13.4: Unit step disturbance response of Ćuk converter controlled by LQG compensator.

A comparison of the loop gains of the LQR and LQG controlled systems is shown in Figure 13.5, where the loop is broken at the control input d. Loss of gain and phase margins has clearly occurred, and the negative gain margin indicates that the system will no longer be closed-loop stable.



Figure 13.5: Loop gain of Ćuk converter controlled by LQR vs. LQG.

Figure 13.6 shows the control effort produced by the LQG controller.



Figure 13.6: LQG control effort.

Minimal discussion is given to this design as it requires the improvements described in the next section.

#### 13.5 Control with LQG/LTR Compensators

Newcomers to the world of optimal control might think that the pairing of the optimal controller formed by the solution of the LQR problem and the optimal estimator formed by the construction of a Kalman filter would have optimal properties. This is not necessarily the case. Doyle [5] provided an example to show that the LQG design loses the guaranteed stability margins of the LQR design when feeding back estimated states. Doyle and Stein [6] then showed how this problem could be addressed. In order to recover the good stability margins and sensitivity properties of an LQR design, an iterative procedure known as loop transfer recovery (LTR) may be performed during the LQG design<sup>1</sup>. The Doyle-Stein method of LTR is performed by iteratively increasing the intensity of the noise covariance matrices used in Kalman filter design. LTR causes the open loop frequency domain characteristics associated with the LQR design to be either exactly or asymptotically recovered as an input noise matrix weighting parameter q is increased. As  $q \to \infty$ , the properties of the LQR are recovered. Essentially, LTR produces a state estimator whose estimates  $\hat{x}$  are independent of the control input u (or only weakly depended on u) and dependent only on the input provided by the plant output y.

Performing the Doyle-Stein method of asymptotic loop transfer recovery on a full-order compensator requires:

- The system must be minimum-phase and strictly proper.
- $R_o = 1$  and  $Q_o = q^2 B B'$

The fact that the plant must be minimum-phase (all poles and zeros in the left half of the complex plane and no pure delays) prevents the compensator designed from being unstable, since the LTR technique moves some of the compensator poles toward the plant zeros where pole-zero cancellation makes them unobservable. (Other LTR methods may be used with nonminimum-phase systems by using subspace [8] or loop-shaping techniques [9].) The remainder of the poles (an excess of poles exists because the plant is strictly proper) move toward infinity in the left-half of the complex plane in a Butterworth filter pattern [10].

The effect of loop transfer recovery is to essentially decouple the observer from the control input u by raising the observer gain L so that the state estimate  $\hat{x}$  depends only on the plant output y. This is illustrated in Figure 13.7. The decoupling is accomplished by the increasing noise intensity on u, which causes L to increase such that y has a larger contribution to the state estimate.

<sup>&</sup>lt;sup>1</sup>A variety of other methods for LTR have been presented in the controls literature, including several which require employment of subspace methods or special coordinate bases [7], [8], but these techniques are beyond the scope of this work.



Figure 13.7: Input decoupling effect of loop transfer recovery.

In order to accomplish LTR, the loop is broken at the large X on the control input shown in Figure 12.1. The loop is explicitly shown in Figure 13.8. The frequency response of the loop from d to d' is driven to asymptotically approach the frequency response of the system with LQR control.



Figure 13.8: The loop to be recovered during loop transfer recovery with a full-order observer.

Figure 13.9 shows the LQGI/LTR iterative design process applied to the  $\acute{C}uk$ 

converter. Initial LQGI design resulted in a gain margin reduction from infinity to -5.7 dB and a loss of phase margin from  $65.4^{\circ}$  to  $36.4^{\circ}$ . The iterative loop transfer recovery process resulted in a controlled system gain margin of 30.2 dB and phase margin of  $61.7^{\circ}$ . Iteration was stopped at that point since these margins are adequate. Further iterations would result in larger observer gains that may be undesirable during implementation, and recovery of the undesirable high frequency characteristics of the LQR compensator has already begun.



Figure 13.9: Loop transfer recovery of an LQGI compensator.

## 13.6 MATLAB Code

```
1 % Linear Quadratic Regulator Compensator with Integration
2
3 % Define the plant using an external file
4 cuk_parameters;
5
6 % Define the weighting matrices for the integral performance ...
       index, with
\tau % weights on the capacitor voltage and the output error
s Cq = [C 0];
9 Q = Cq' * Cq;
10 Q(1, 1) = 1;
11 Q(2,2) = 0;
12 \quad Q(3,3) = 0;
13 Q(4, 4) = 0;
14 Q(5,5) = 100000;
15 R = 1;
16
17 A_prime = [A zeros(size(B));-C zeros(size(D))];
18 Bd_prime = [Bd; 0];
19 B_prime = [B;0];
20 C_prime = [C 0];
^{21}
22 % LQR System design
23 K = lqr(A_prime,Bd_prime,Q,R);
_{24} k = K(1:4);
25 ki = K(end);
^{26}
27 Abar = [A-Bd*k, -Bd*ki; -C, 0];
28 Bbar = [B; 0];
29 Cbar = [C 0];
30
31 SYS_LQR = ss(Abar,Bbar,Cbar,D);
32
33 % LQR Step Response
34 [y t x] = step(SYS_LQR, 0.02);
35 figure;
36 plot(t, Vo+y, 'b');
37 xlabel('Time (s)');
38 ylabel('Amplitude (V)');
39 grid on
40
41 % LQR Loop Gain Plot
42 figure;
43 margin(A_prime, Bd_prime, K, 0);
44 h = gcr;
45 h.AxesGrid.TitleStyle.FontSize = 10;
46 h.AxesGrid.XLabelStyle.FontSize = 10;
47 h.AxesGrid.YLabelStyle.FontSize = 10;
^{48}
49 % Control Effort Plot
50 figure;
51 plot(t, -K*x'+d);
52 xlabel('Time (s)');
```

53 ylabel('Duty Cycle'); 54 grid on

```
1 % Linear Quadratic Gaussian Compensator with Integration
2
3 % Design the LQR compensator
4 lqri;
5
6 % LQG Design
7 Q0 = 1e8*eye(size(A));
10 [L,P,E] = lqe(A,eye(size(A)),C,Q0,R0);
11
12 % Construct the closed-loop system for time-domain response testing
13 Abar = [A, -Bd*ki, -Bd*k;
14 -C, 0, zeros(1,4);
           L*C, --Bd*ki, A--Bd*k--L*C];
15
16 Bbar = [B; 0; B];
17 Cbar = [C 0 zeros(size(C))];
18 SYS_LQG = ss(Abar, Bbar, Cbar, D);
19
20 % LQG Step Response
21 [y t x] = step(SYS_LQG, 0.02);
22 figure;
23 plot(t, Vo+y, 'b');
24 xlabel('Time (s)');
25 ylabel('Amplitude (V)');
26 grid on
27
28 % LQR vs. LQG System Loop Gain Plot
29 A1 = [A, zeros(4,1), zeros(4,4);
        -C, 0, zeros(1,4);
30
31
       L*C, --Bd*ki, A--Bd*k--L*C];
32 B1 = [Bd;0;zeros(4,1)];
33 C1 = [zeros(1,4), ki, k];
34 D1 = 0;
35 figure;
36 sys_lqr = ss(A_prime, Bd_prime, K, 0);
37 sys_lqg = ss(A1, B1, C1, D1);
38 margin(sys_lqr)
39 hold on
40 margin(sys_lqg)
41 h = gcr;
42 h.AxesGrid.TitleStyle.FontSize = 10;
43 h.AxesGrid.XLabelStyle.FontSize = 10;
44 h.AxesGrid.YLabelStyle.FontSize = 10;
45 hold off
46 legend('LQRI', 'LQGI')
47
48 % Control Effort Plot
49 figure;
50 h = plot(t, -[zeros(1,4), ki, k]*x'+d);
51 xlabel('Time (s)');
52 ylabel('Duty Cycle');
53 grid on
```

L

\_\_\_\_\_

# References

- B. N. Datta, Numerical Methods for Linear Control Systems. San Diego, CA: Elsevier Academic Press, 2004.
- [2] R. C. Dorf and R. H. Bishop, *Modern Control Systems*, 10th ed. Upper Saddle River, NJ: Pearson Prentice Hall, 2005.
- [3] B. D. O. Anderson and J. B. Moore, Optimal Control: Linear Quadratic Methods. Englewood Cliffs, NJ: Prentice Hall, Inc., 1990.
- [4] G. M. Siouris, An Engineering Approach to Optimal Control and Estimation Theory. New York, NY: Wiley, 1996.
- [5] J. C. Doyle, "Guaranteed margins for LQG regulators," *IEEE Trans. Automat. Contr.*, vol. 23, pp. 756–757, Aug. 1978.
- [6] J. C. Doyle and G. Stein, "Robustness with observers," *IEEE Trans. Automat. Contr.*, vol. 24, pp. 607–611, Aug. 1979.
- [7] B. M. Chen, "Theory of loop transfer recovery for multivariable linear systems," Ph.D. dissertation, Washington State Univ., Pullman, WA, Dec. 1991.
- [8] A. Saberi and P. Sannuti, "Observer design for loop transfer recovery and for uncertain dynamical systems," *IEEE Trans. Automat. Contr.*, vol. 35, pp. 878–897, Aug. 1990.
- [9] G. Stein and M. Athans, "The LQG/LTR procedure for multivariable feedback control design," *IEEE Trans. Automat. Contr.*, vol. 32, pp. 105–114, Feb. 1987.
- [10] B. Friedland, Control System Design: An Introduction to State-Space Methods. New York, NY: McGraw-Hill, 1986.

REFERENCES

# Chapter 14

# Compensator Order Reduction

With the advent of computer control of systems, high-order system models can be created that allow model-based control methods (such as observer-based compensators) to be easily implemented. These digital controller implementations have many advantages over analog controllers, which may be considered to be outdated. However, analog control can often still be performed at the circuit level with a few discrete components and may be more cost-effective to implement when compared to a microprocessor and its associated support circuitry and programming. Thus, this section examines the idea of controller order reduction for use with analog circuitry. It focuses first on reducing the order of an LQGI/LTR compensator using model reduction techniques, then design of an LQGI/LTR compensator using a reduced-order Kalman filter (ROKF), and finally, application of model reduction techniques to the ROKF-based compensator. This final two-step order reduction technique has not been previously seen in the literature.

## 14.1 Model Reduction of the LQGI/LTR Compensator

Model reduction (MR) may be accomplished by creating a balanced realization (i.e., equal and diagonal controllability and observability Gramian matrices) of the system to be reduced using a linear transformation such as the *balreal* command in MATLAB [1]. Examination of the eigenvalues of the Gramian matrix of the balanced realization allows the designer to identify states that are weakly coupled to both the input and output of the compensator. These states, which are at once both weakly controllable and weakly observable, have small Hankel singular values associated with them. Hankel singular values are determined by taking the square root of the product of the eigenvalues of the controllability and observability Gramian matrices. In a balanced realization, the Hankel singular values are the diagonal entries of the common controllability/observability Gramian matrix, and the states are ordered from highest to lowest Hankel singular value [2]. Compensator states with small Hankel singular values may be eliminated with little impact to the performance of the compensator using the *modred* command in MATLAB.

In this case, the system to be reduced is the compensator. The *balreal* command identifies only two states that may be eliminated from the LQGI/LTR compensator designed previously without significant loss of accuracy, as may be predicted by the information provided from the pole-zero plot in Figure 14.1. Model reduction resulted in the addition of a high-frequency zero for this particular compensator. This zero was a simulation artifact created by the *modred* command, therefore it was removed by truncation.

Examination of the LQGI/LTR compensator poles, zeros, and gain of the transfer function yields:

$$p = \begin{bmatrix} -1490 \pm j9000 & -1129500 \pm j1129500 & 0 \end{bmatrix}$$
(14.1)  

$$z = \begin{bmatrix} -32410 & -319 & -1440 \pm j9090 \end{bmatrix}$$
  

$$k = 7.195 \times 10^{7}$$



Figure 14.1: Pole-zero plot of the LQGI/LTR compensator.

By comparing the frequencies at which the poles and zeros occur and their complex plane locations, it can be seen that a complex pair of zeros at  $-1490 \pm j9000$  essentially cancels out a complex pair of poles at  $-1440 \pm j9090$ . This is more readily viewed in the close-up view of the pole-zero plot in Figure 14.2.


Figure 14.2: Compensator pole-zero plot showing likely pole-zero pair cancellation.

Examination of the compensator after model reduction methods yields:

$$pr = \begin{bmatrix} 0 & -1126800 \pm j1132300 \end{bmatrix}$$
(14.2)  

$$zr = \begin{bmatrix} -319.5 & -33035 \end{bmatrix}$$
  

$$kr = 7.18 \times 10^{7}$$

where all poles and zeros are in rad/s.

Once model reduction has been accomplished, validation must occur to verify that significant differences do not exist between the full-order and model-reduced compensators. Comparison of the full-order and model-reduced compensator frequency responses is shown in Figure 14.3. Based on this diagram, it is readily apparent that the model-reduced compensator may be used to replace the fullorder compensator without significant difference, thus reducing the controller order. The MRLQGI/LTR compensator can then be achieved with less analog circuitry than the LQGI/LTR yet still perform adequately, and therefore may be selected for implementation.

Care must be taken when performing model reduction to ensure desirable stability margins are not lost. Comparable frequency responses between the full-order and model-reduced compensators tell the designer that margins will probably not change appreciably during model reduction. Verification of margins was performed for system with the MRLQGI/LTR compensator; no change in gain margin resulted but phase margin was reduced to  $61.2^{\circ}$ , a loss of  $0.5^{\circ}$ , which is not a significant difference.

The step disturbance response for the model-reduced compensator is shown



Figure 14.3: Compensator frequency response comparison following model reduction.

in Figure 14.4. The step disturbance input is attenuated well, with a maximum deviation of just over 20 mV. This would be a perfectly acceptable controller for the Ćuk converter, however, additional order reduction (though impossible to achieve in this controller incarnation without significantly impacting performance) would be desirable and is explored in the next section.



Figure 14.4: Unit step disturbance response of Ćuk converter - MRLQGI/LTR compensator.

#### 14.2 A Reduced-Order LQGI/LTR Compensator

The model-reduced compensator designed in Section 14.1 is based on pole-zero cancellation in a balanced state-space realization of the Kalman filter and truncation to remove a high-frequency zero. However, a compensator based on a LQRI paired with a reduced-order Kalman filter (ROKF) can be designed and the LTR technique applied during the design process in order to develop a ROLQGI/LTR compensator. Madiwale and Williams [3] described the mathematics necessary for performing loop transfer recovery with reduced-order linear quadratic compensators and provided proofs that the equations used in this section achieve LTR.

The design of the ROLQGI/LTR compensator begins with construction of a linear quadratic regulator. Once the regulator gain K has been determined, the system matrices and K are partitioned to form a reduced-order observer as in Equation 12.10.

Consider a minimum phase system with process noise  $\omega$  (with positive definite Gaussian spectral density matrix V) that is distributed into the state dynamics by W and let the system be free from measurement noise in the measured state vector  $x_m$ :

$$\dot{x} = Ax + Bu + W\omega$$
(14.3)  
$$y = x_m$$

Process noise characteristics are usually difficult to determine or unknown. Thus, both W and the corresponding noise spectral density V are manipulated as design parameters for determining the optimal reduced-order estimator gain L in a manner similar to the manipulation of  $Q_0$  and  $R_0$  in full-order estimator design methods. Both W and V are also partitioned as in Equation 12.10 in order to form the reduced-order Kalman filter. Let:

$$V_{11} = W_1 V_1 W_1' + q^2 B_1 V_2 B_1' \tag{14.4}$$

$$V_{12} = W_1 V_1 W_2' + q^2 B_1 V_2 B_2' \tag{14.5}$$

$$V_{22} = W_2 V_1 W_2' + q^2 B_2 V_2 B_2' \tag{14.6}$$

Then with:

$$\bar{A} = A_{22} - V_{12}' V_{11}^{-1} A_{12}$$

$$\bar{V} = V_{22} - V_{12}' V_{11}^{-1} V_{12}$$
(14.7)

where  $V_{11}$  is nonsingular, the following ARE is solved for for  $Q_o$ :

$$\bar{A}Q_o + Q_o\bar{A}' - Q_oA'_{12}V_{11}^{-1}A_{12}Q_o + \bar{V} = 0$$
(14.8)

The Kalman filter gain L can then be determined from:

$$L = (Q_o A'_{12} + V'_{12}) V_{11}^{-1}$$
(14.9)

Now, as q is increased in Equations 14.4-14.6, the target feedback loop of the LQR controller is recovered.

Once again, the loop is broken at the large X on the control input as shown in Figure 12.6. The open loop is shown explicitly in Figure 14.5. The frequency response of the loop from d to d' is again driven to asymptotically approach the frequency response of the system with LQR control as shown in Figure 14.6, which is a plot of the iterative LTR process for this reduced-order compensator and the Ćuk converter.



Figure 14.5: Loop transfer recovery with a reduced-order observer.



Figure 14.6: Loop transfer recovery of a ROKF-based LQGI compensator.

During simulation, it was found that the original matrices selected to represent the process noise had values that were too large. The initial results showed loop transfer recovery had already occurred, therefore the noise values had to be made smaller to verify that LTR was taking place. For the model of the Ćuk converter to be controlled, the following partitions of the W and V matrices were used to simulate the fictitious noise:

$$W_{1} = \begin{bmatrix} 1 \times 10^{-4} & 0 & 0 \end{bmatrix}, W_{2} = \begin{bmatrix} 1 \times 10^{-5} & 0 & 0 \\ 0 & 1 \times 10^{-5} & 0 \\ 0 & 0 & 1 \times 10^{-5} \end{bmatrix}$$
$$V_{1} = \begin{bmatrix} 1 \times 10^{-5} & 0 & 0 \\ 0 & 1 \times 10^{-5} & 0 \\ 0 & 0 & 1 \times 10^{-5} \end{bmatrix}, V_{2} = 1 \times 10^{-5}$$

The scalar q was allowed to vary from  $1\times 10^{-10}$  to  $1\times 10^{-7}$  during the recovery process.

Examination of the ROLQGI/LTR compensator transfer function yields:

$$pr = \begin{bmatrix} -1490.0 \pm j9000.0 & -2466000.0 & 0.0 \end{bmatrix}$$
(14.10)  

$$zr = \begin{bmatrix} -32990.0 & -319.2 & -1442.0 \pm j9087.0 \end{bmatrix}$$
  

$$kr = 70.74$$

where the poles and zeros are given in rad/s. This transfer function shows a pole-zero pair that could possibly be canceled via model reduction methods. The balanced realization approach to model reduction discussed in Section 14.1 was applied. Comparison of the Hankel singular values produced by the *balreal* command revealed that only two states could be eliminated without significant loss of accuracy in the controller model. Elimination of these states resulted in a second-order compensator that had the following characteristics for its transfer function:

$$pr = \begin{bmatrix} 0.0 & -246900.0 \end{bmatrix}$$
(14.11)  

$$zr = \begin{bmatrix} -319.4 & -33570.0 \end{bmatrix}$$
  

$$kr = 70.76$$

where the poles and zeros are given in rad/s. This model-reduced compensator has a pole at the origin and two zeros on the negative real axis left of the pole, which is a classical PID controller. It also has another pole on the negative real axis beyond the zeros, which corresponds to high frequency low-pass filtering. It may therefore be thought of as a feedback PID compensator with the derivative term acted upon by a first-order low-pass filter. This type of filtered derivative action is typically included in PID controllers to reduce the bandwidth of the controller and associated undesirable amplification of high-frequency noise, as well as to make them implementable (the ideal PID equation is non-causal due to the fact that there is an excess of zeros). This PID controller is very simple to implement with a single inverting operational amplifier configuration. A second inverter buffer stage is needed to eliminate the undesired inversion caused by the first stage.

A frequency response comparison of the two compensators designed in this section is shown in Figure 14.7. There is excellent correlation between the Bode plots, showing that the MRROLQGI/LTR compensator performance will be almost exactly the same as the ROLQGI/LTR compensator.



Figure 14.7: Comparison of compensator frequency response - ROLQGI/LTR and MRROLQGI/LTR.

Initial ROLQGI design resulted in no gain margin reduction from infinity but had a loss of phase margin from  $65.4^{\circ}$  to  $56.3^{\circ}$ . The iterative loop transfer recovery process resulted in a controlled system phase margin of  $63.7^{\circ}$ . Further iterations would result in larger observer gains that may be undesirable during implementation. Verification of margins was performed for system with the MRROLQGI/LTR compensator; no change in gain margin resulted but phase margin was reduced to  $63.3^{\circ}$ , a loss of  $0.4^{\circ}$ . Again, this is not a significant difference.

The step disturbance response for the model-reduced compensator is shown in Figure 14.8. The step disturbance input is attenuated well, with a maximum deviation of less than 20 mV. This is a perfectly acceptable controller for the Ćuk converter.



Figure 14.8: Unit step $v_g$  response of Ćuk converter - MRROLQGI/LTR compensator

#### 14.3 MATLAB Code

```
1 % LQGI/LTR and MRLQGI/LTR Compensators
2 clc
3
4 % Design the LQR compensator
5 lqri;
6
7 % Define one of the Kalman filter weight matrices
8 R0 = 1;
9
10 % Plot the magnitude of the open loop LQR
11 h=figure;
12 bode(A_prime, Bd_prime, K, 0);
13 hold on
14
15 % Loop transfer recovery
16 q = [1, 1e2, 1e4, 1e6];
17 for n = 1:length(q)
       Q0 = q(n) * Bd * Bd';
18
       [L, P, E] = lqe(A, eye(size(A)), C, Q0, R0);
19
20
       Aol = [ A, zeros(4,1), zeros(4,4);
               -C,
                           0, zeros(1,4);
^{21}
                       -Bd*ki, A-Bd*k-L*C];
^{22}
              L*C,
       Bol = [Bd; 0; zeros(4,1)];
23
       Col = [zeros(1,4), ki, k];
^{24}
       sysol = ss(Aol,Bol,Col,D);
25
^{26}
27
       \ Plot the frequency response of the open loop LQGI/LTR
      margin(Aol, Bol, Col, D);
28
29 end
30 hold off
31 childrenHnd =get(h, 'Children')
32 axes(childrenHnd(3))
ss legend('LQRI','q=10^{0}','q=10^{2}','q=10^{4}','q=10^{6}', ...
       'Location', 'SouthWest')
34
35 h = gcr;
36 h.AxesGrid.TitleStyle.FontSize = 10;
37 h.AxesGrid.XLabelStyle.FontSize = 10;
38 h.AxesGrid.YLabelStyle.FontSize = 10;
39
40 % Compensator
41 Ao = [A-Bd*k-L*C, -Bd*ki;
42
        zeros(1,4),
                      01;
43 LO = [L; -1];
44 focomp = ss(Ao,Lo,K,0);
45 [zc,pc,kc]=ss2zp(Ao,Lo,K,0);
46 focomp = zpk(zc,pc,kc)
47
48 % Pole-zero plot of full-order compensator
49 [P,Z] = pzmap(focomp);
50 figure;
51 h = plot(real(P), imag(P), 'x', real(Z), imag(Z), 'bo');
52 ylabel('Imaginary Axis');
53 xlabel('Real Axis');
```

```
54 grid on
55
56 % Close-up of pole-zero plot
57 figure;
58 h = plot(real(P), imag(P), 'x', real(Z), imag(Z), 'bo');
59 ylabel('Imaginary Axis');
60 xlabel('Real Axis');
61 axis([-4e4, 0.5e4, -1.5e4, 1.5e4]);
62 grid on
63
64 % Reduce the order of the compensator
65 [focomp,g] = balreal(focomp);
66 g;
67 elim = (g<5e-2);
68 mrcomp = modred(focomp,elim);
69 [zrc prc krc] = ss2zp(mrcomp.a,mrcomp.b,mrcomp.c,mrcomp.d);
70 % An added high-frequency zero results from model reduction.
71~ % Restore the system gain prior to removing the high frequency zero
72 % using truncation.
73 krc = krc*abs(zrc(1,1));
74 zrc = zrc(2:3,1);
75 mrcompzp = zpk(zrc,prc,krc)
r6 [mrcomp.a,mrcomp.b,mrcomp.c,mrcomp.d] = zp2ss(zrc,prc,krc);
77
78 % Compensator Comparison Bode Plot
79 figure;
80 bode(focomp,mrcomp);
s_1 h = gcr;
82 h.AxesGrid.TitleStyle.FontSize = 10;
83 h.AxesGrid.XLabelStyle.FontSize = 10;
84 h.AxesGrid.YLabelStyle.FontSize = 10;
85 legend('LQGI/LTR', 'MRLQGI/LTR', 'Location', 'NorthWest');
86
87 % Plot step disturbance response with MRLQGI/LTR compensator
ss figure;
89 sys = ss(A, [B, Bd], C, D);
90 syscl = feedback(sys,mrcomp,[2],[1]);
91 [y,t,x] = step(syscl,0.02);
92 plot(t, Vo+y(:,1,1));
93 grid on
```

```
1 % ROLQGI/LTR and MRROLQGI/LTR Compensators
2
3 % Design the LQR compensator
4 lqri;
5
6 % Partition the system in terms of measured and unmeasured states
7 All = A(1,1);
8 Al2 = A(1,2:4);
9 A21 = A(2:4,1);
10 A22 = A(2:4,2:4);
11
12 Bd1 = Bd(1);
13 Bd2 = Bd(2:4);
14
15 % Partition the gain vector determined by linquadreg.m
```

```
16 k = K(1:4);
17 \text{ km} = K(1);
18 ku = K(2:4);
19 ki = K(end);
20
21 % Form the open-loop LQR system and plot the frequency response
22 olsys = ss(A_prime, Bd_prime, K, 0);
23 [gml pml wgcl wpcl] = margin(A_prime,Bd_prime,K,0);
24 gml = 20*log10(gml);
25 h=figure;
26 bode(olsys,{le1,le7});
27 hold on
^{28}
29 % Noise distribution matrices
so F1 = 1e - 4 \cdot eye(1, 3);
31 F2 = 1e-5*diag([1,1,1]);
32
33 % White noise vector intensity
34 V1 = 1e-5*diag([1,1,1]);
V2 = 1e - 5 \times 1;
36
37 % Loop transfer recovery
38 q = [1e-10, 1e-9, 1e-8, 1e-7];
39 for n = 1:length(q);
^{40}
        V11 = F1*V1*F1'+q(n)^2*Bd1*V2*Bd1';
        V12 = F1*V1*F2'+q(n)^2*Bd1*V2*Bd2';
41
^{42}
        V22 = F2 * V1 * F2' + q(n)^{2} * Bd2 * V2 * Bd2';
43
        Abar = A22-V12'*inv(V11)*A12;
44
^{45}
        Vbar = V22-V12'*inv(V11)*V12;
46
        [Q,M,X] = care(Abar',A12',Vbar,V11);
^{47}
^{48}
        L = (Q * A12' + V12') * inv(V11);
49
50
        E = A22 - L \star A12;
51
        F = E * L + A21 - L * A11;
52
        G = Bd2-L*Bd1;
53
54
        % Build open loop system with plant, observer, and feedback law
55
        Aol = [A, zeros(4, 1), zeros(4, 3);
56
57
               -C, 0, zeros(1,3);
              F*C-G*km*C-G*ku*L*C, -G*ki, E-G*ku];
58
        Bol = [Bd; 0; zeros(3,1)];
59
        Col = [km*C+ku*L*C, ki, ku];
60
        sysol = ss(Aol,Bol,Col,D);
61
62
        % Plot the frequency response of the open loop system
63
64
        margin(sysol);
65 end
66 hold off
67 childrenHnd =get(h, 'Children');
68 axes(childrenHnd(3))
69 legend('LQRI', 'q=10^{-10}', 'q=10^{-9}', 'q=10^{-8}',...
70 'q=10^{-7}', 'Location', 'SouthWest')
71 h = gcr;
72 h.AxesGrid.TitleStyle.FontSize = 10;
```

```
73 h.AxesGrid.XLabelStyle.FontSize = 10;
74 h.AxesGrid.YLabelStyle.FontSize = 10;
75
76 % Define the reduced order compensator design
77 Ar = [E-G*ku, -G*ki;
78
          zeros(1,3), 0];
79 Br = [F-G*ku*L-G*km; -1];
80 Cr = [ku ki];
81 Dr = ku*L+km;
82 [zr pr kr] = ss2zp(Ar, Br, Cr, Dr);
83 rocomp = zpk(zr,pr,kr);
84
85 % Apply model reduction techniques
86 [rocomp,g] = balreal(rocomp);
87 g
ss elim = (g<5e-2)
89 mrrocomp = modred(rocomp,elim);
90 [zrr prr krr] = ss2zp(mrrocomp.a,mrrocomp.b,mrrocomp.c,mrrocomp.d);
91 mrrocompzp = zpk(zrr,prr,krr)
92
93 % Compensator Comparison Bode Plot
94 figure;
95 bode(rocomp,mrrocomp);
96 h = gcr;
97 h.AxesGrid.TitleStyle.FontSize = 10;
98 h.AxesGrid.XLabelStyle.FontSize = 10;
99 h.AxesGrid.YLabelStyle.FontSize = 10;
100
101 % Plot step disturbance response
102 figure;
103 sys = ss(A, [B, Bd], C, D);
104 syscl = feedback(sys,mrrocomp,[2],[1]);
105 [y,t,x] = step(syscl,0.02);
106 plot(t, 24+y(:,1,1));
107 xlabel('Time (s)');
108 ylabel('Amplitude (V)');
109 grid on
110
111 % Calculate component values for the MRROLQGI/LTR compensator
112 % There are five free parameters to find and four equations.
113 % Arbitrarily assign R3, calculate the remaining component values.
114 R3 = 100000
115 R2 = R3/krr
116 C2 = 1/(R3 \times abs(zrr(1,1)))
117 R1 = R2*abs(prr(2,1))/abs(zrr(2,1))-R2
118 C1 = 1/(R1 \times abs(zrr(2, 1)))
```

## References

- [1] MATLAB Control Systems Toolbox 6.0 User's Guide, The Mathworks, 2004.
- [2] R. S. Sánchez-Peña and M. Sznaier, Robust Systems: Theory and Applications. New York, NY: Wiley, 1998.
- [3] A. N. Madiwale and D. E. Williams, "Some extensions of loop transfer recovery," in *Proc. of the American Control Conference (ACC'85)*, Boston, MA, Jun. 1985, pp. 790–795.

REFERENCES

#### Chapter 15

### **Compensator Implementation**

At this point, four optimal compensator designs that rely on output feedback and state estimation have been developed. The initial design of the optimal compensator began with a fifth-order controller, with estimated states for each of the four states in the plant and an augmented integral state (LQGI/LTR). Model reduction techniques applied directly resulted in a third-order controller (MRLQGI/LTR), which was a significant improvement in terms of minimizing the circuitry for implementation. The final design began with a fourth-order compensator based on three states from a reduced-order observer augmented by an integral state (ROLQGI/LTR), to which model reduction techniques were applied to form a second-order transfer function (MRROLQGI/LTR). This final regulator had the form of a classical PID controller. The final design had a significant reduction in circuitry yet maintained excellent performance in both the time and frequency domains.

The reduced-order compensators developed in Chapter 14 using model reduction techniques can be implemented with analog circuits using operational amplifiers. The goal is to use the minimum amount of components and circuitry for control (to minimize manufacturing costs) while maintaining adequate controller performance.

#### 15.1 MRLQGI/LTR Compensator Construction

The model-reduced compensator designed in Section 14.1 has two zeros on the negative real axis, a LHP pair of complex poles, and a pole at the origin. This compensator can be implemented by a PI compensator cascaded with a Tow-Thomas biquadratic filter as seen in Figure 15.1. The Tow-Thomas filter is a general second-order filter able to implement low-pass, high-pass, band-pass, notch, and all-pass filters with appropriate choices of coefficients of the filter transfer function [1]:

$$T_b(s) = \frac{a_2 s^2 + a_1 s + a_0}{b_2 s^2 + b_1 s + b_0}$$
(15.1)

The biquad filter section is used to implement the second-order denominator term with a simple zero by setting  $a_2 = 0$ . The PI section is used to implement the other real zero and the pole at the origin. For both sections, it is desirable to keep the poles and zeros within a certain frequency tolerance of each other to keep the component values reasonable in size.



Figure 15.1: The MRLQGI/LTR compensator implemented using operational amplifiers.

The transfer function of the PI section is given by:

$$T_p(s) = -\frac{\frac{C_1}{C_2}(s + \frac{1}{C_1R_1})}{s}$$
(15.2)

The transfer function of the biquad filter section is given by:

$$T_b(s) = -\frac{\frac{1}{C_3R_2}s + \frac{1}{C_3^2R_4R_5}}{s^2 + \frac{1}{C_2R_2}s + \frac{1}{C_2^2R_2}}$$
(15.3)

#### 15.2 MRROLQGI/LTR Compensator Construction

A practical example of the MRROLQGI/LTR compensator requires fewer components to implement than the MRLQGI/LTR circuit. It is simply an analog PID controller with a filtered derivative term [2]. Consider the circuit in Figure 15.2. With the inverting opamp configuration and some algebraic manipu-



Figure 15.2: The analog MRROLQGI/LTR compensator implementation.

lation, the transfer function is shown to be:

$$T(s) = \frac{\frac{R_3}{R_2} \left(s + \frac{1}{C_2 R_3}\right) \left(s + \frac{1}{R_1 C_1}\right)}{s\left(s + \frac{R_2 + R_1}{R_1 R_2 C_1}\right)}$$
(15.4)

which shows the following zeros, poles, and gain:

$$poles = \begin{bmatrix} 0 & \frac{-(R_2 + R_1)}{R_1 R_2 C_1} \end{bmatrix}$$
(15.5)  

$$zeros = \begin{bmatrix} \frac{-1}{C_2 R_3} & \frac{-1}{R_1 C_1} \end{bmatrix}$$
  

$$gain = \frac{R_3}{R_2}$$

Component values may be determined by equating the expressions in Equation 15.5 with the compensator values given in Equation 14.11. Since there are fewer equations than unknowns, one of the component values must be fixed before the other component values may be determined. The final design used the component values given in Table 15.1.

Table 15.1: Component values for MRROLQGI/LTR compensator implementation.

Component	Value
$R_1$	$100 \ k\Omega$
$R_2$	$1.4 \ k\Omega$
$R_3$	$100 \ k\Omega$
$C_1$	0.29 nF
$C_2$	31.3 nF

# References

- [1] R. C. Jaeger, *Microelectronic Circuit Design*. Boston, MA: McGraw-Hill, 1997.
- [2] W. J. Palm, Control Systems Engineering. New York, NY: Wiley, 1986.

REFERENCES

### Chapter 16

# Power Electronic Circuit Simulation

The MRROLQGI/LTR compensator required the least amount of circuitry and was therefore selected for implementation and testing in PECS. The PECS environment provides for relatively short run times compared to SPICE-based circuit simulation environments since power electronics circuits can typically be simulated with simpler component models than other types of analog circuits.

# 16.1 Simulating the Controlled Ćuk Converter in PECS

The PECS implementation of the MRROLQGI/LTR compensator design from Section 15.2 connected to the Ćuk converter can be seen in Figure 16.1.



Figure 16.1: PECS simulation of Ćuk converter - MRROLQGI/LTR compensator.

First, the small-signal operation was tested using a step disturbance in  $v_g$  as was used during controller design. A simulation was set up to provide for input voltage steps up and down from the nominal 12 V using a unit step to 13 V on the Ćuk input. The simulation used a time step of 1  $\mu$ s and a run time of 0.1 s. The results of this simulation are shown in Figure 16.2.



Figure 16.2: Unit step  $v_g$  disturbances and  $v_o$  response - MRROLQGI/LTR compensator.

The maximum deviation in the output voltage is only 0.022 V in response to a step input of 1 V. (Note that ripple voltage exists in the simulation which is not present in the state space averaged model simulations in MATLAB. Neglecting the ripple did not pose a problem, however, during the control system design process.)

Next, a large-signal simulation was set up to provide for input voltage steps up and down from the nominal 12 V through a specified operating range of 9-14 V on the Ćuk input. The results of the large-signal simulation are shown in Figure 16.3.



Figure 16.3: Large signal  $v_g$  disturbances and  $v_o$  response - MRROLQGI/LTR compensator.

The maximum deviation of 0.11 V in the output voltage occurred when the input voltage drops sharply from 14 V to 9 V but is rapidly brought back under control. This value is well within the 0.24 V tolerance that was specified for controller performance.

Finally, a simulation was set up to provide for 25% load current steps (0.214 A) around the nominal load current of 0.857 A. The results of this simulation are shown in Figure 16.4.



Figure 16.4: Load current disturbance and  $v_o$  response - MRROLQGI/LTR compensator.

The maximum deviation of 0.175 V in the output voltage occurred when the load current dropped sharply from 1.071 A to 0.643 A, but this is within the transient design specification of regulation to within 1% of the nominal output voltage.

The ability to reject large scale input voltage and load disturbances shows that the compensator design is excellent. The MRROLQGI/LTR controller allowed the system to not only meet the performance specifications, but to exceed them, and achieved these results after two separate reduction of order techniques (reduced-order observer and model reduction) were applied during the design process.

### Chapter 17

### Conclusion

Part II demonstrated the process of applying modern control design methods to regulator design for DC-DC converters, and prototypically, to a Ćuk DC-DC converter. Full state feedback control for pole placement was applied - first without integral effort, then with an integrator added. Output compensation using state estimation techniques with full- and reduced-order observers was discussed and simulated. LQRI and LQGI/LTR techniques were then used to design compensators that were optimized with respect to quadratic performance indices based on state and control effort transients. Balanced realization of the LQGI/LTR compensator identified weakly controllable/observable states, which were then removed using truncation to create a third-order compensator (MR-LQGI/LTR) that could be implemented with a combination PI/Tow-Thomas biquad circuit.

The steps up to this point were typical application of modern state space control methods found in most textbooks. The method that followed (in Section 14.2) resulted in a minimal-order compensator. Namely, when the reducedorder Kalman filter-based compensator design (ROLQGI/LTR) was combined with model reduction using a balanced realization, the result was a second-order compensator (MRROLQGI/LTR) that could be implemented by an analog PID circuit. This MRROLQGI/LTR controller was applied to the Ćuk converter in a power electronics modeling environment and showed excellent input voltage and load current disturbance rejection abilities. The two-step order reduction combination of reduced-order observer design and truncated balanced realization is a novel design method that, while applied to one of the more complex DC-DC converters, appears to be applicable to compensator design in general.